

# Ruijie Reyee RG-NBS5200-24GT4XS-P-V2 Switch

## Implementation Cookbook



Document Version: V1.1 Date: May 13, 2025

Copyright © 2025 Ruijie Networks

#### Copyright

Copyright © 2025 Ruijie Networks

All rights are reserved in this document and this statement.

Without the prior written consent of Ruijie Networks, any organization or individual shall not reproduce, extract, back up, modify, or propagate the content of this document in any manner or in any form, or translate it into other languages or use some or all parts of the document for commercial purposes.



All other trademarks or registered trademarks mentioned in this document are owned by their respective owners.

#### **Disclaimer**

The products, services, or features you purchase are subject to commercial contracts and terms, and some or all of the products, services, or features described in this document may not be available for you to purchase or use. Except for the agreement in the contract, Ruijie Networks makes no explicit or implicit statements or warranties with respect to the content of this document.

The names, links, descriptions, screenshots, and any other information regarding third-party software mentioned in this document are provided for your reference only. Ruijie Networks does not explicitly or implicitly endorse or recommend the use of any third-party software and does not make any assurances or guarantees concerning the applicability, security, or legality of such software. You should choose and use third-party software based on your business requirements and obtain proper authorization. Ruijie Networks assumes no liability for any risks or damages arising from your use of third-party software.

The content of this document will be updated from time to time due to product version upgrades or other reasons, Ruijie Networks reserves the right to modify the content of the document without any notice or prompt.

This manual is designed merely as a user guide. Ruijie Networks has tried its best to ensure the accuracy and reliability of the content when compiling this manual, but it does not guarantee that the content of the manual is completely free of errors or omissions, and all the information in this manual does not constitute any explicit or implicit warranties.

### **Preface**

#### **Intended Audience**

This document is intended for:

- Network engineers
- Technical support and servicing engineers
- Network administrators

#### **Technical Support**

- The official website of Ruijie Reyee: <a href="https://reyee.ruijie.com">https://reyee.ruijie.com</a>
- Technical Support Website: <a href="https://reyee.ruijie.com/en-global/support">https://reyee.ruijie.com/en-global/support</a>
- Case Portal: <a href="https://www.ruijie.com/support/caseportal">https://www.ruijie.com/support/caseportal</a>
- Community: <a href="https://community.ruijienetworks.com">https://community.ruijienetworks.com</a>
- Technical Support Email: <a href="mailto:service\_rj@ruijie.com">service\_rj@ruijie.com</a>
- Online Robot/Live Chat: <a href="https://reyee.ruijie.com/en-global/rita">https://reyee.ruijie.com/en-global/rita</a>

#### Conventions

#### 1. GUI Symbols

Interface symbol	Description	Example
Boldface	Button names     Window names, tab name, field name and menu items     Link	<ol> <li>Click OK.</li> <li>Select Config Wizard.</li> <li>Click the Download File link.</li> </ol>
>	Multi-level menus items	Select System > Time.

#### 2. Signs

This document also uses signs to indicate some important points during the operation. The meanings of these signs are as follows:



Warning

An alert that calls attention to important rules and information that if not understood or followed can result in data loss or equipment damage.



Note

An alert that calls attention to essential information that if not understood or followed can result in function failure or performance degradation.

#### Instruction

An alert that contains additional or supplementary information that if not understood or followed will not lead to serious consequences.

Specification

An alert that contains a description of product or version support.

#### 3. Instruction

This manual is used to guide users to understand the product, install the product, and complete the configuration.

- The example of the port type may be different from the actual situation. Please proceed with configuration according to the port type supported by the product.
- The example of display information may contain the content of other product series (such as model and description). Please refer to the actual display information.
- The routers and router product icons involved in this manual represent common routers and layer-3 switches running routing protocols.



## **Overview**

This cookbook consists of two independent volumes, introducing the installation, deployment, and web-based configuration of the RG-NBS5200-24GT4XS-P-V2 switch, including:

- 01- Installation Guide
- 02- ReyeeOS 2.341 Configuration Guide

## **Contents**

1 Overview	1
1.1 About the RG-NBS5200-24GT4XS-P-V2	1
1.2 Package Contents	1
1.3 Product Appearance	2
1.3.1 Front Panel	2
1.3.2 Rear Panel	4
1.4 Cooling	4
1.5 Technical Specifications	4
2 Preparing for Installation	7
2.1 Safety Guidelines	7
2.1.1 General Precautions	7
2.1.2 Chassis-Lifting Guidelines	7
2.1.3 Electricity Safety	7
2.1.4 Preventing ESD Damage	8
2.1.5 Laser Safety	9
2.2 Site Requirements	9
2.2.1 Floor Loading	9
2.2.2 Space	9
2.2.3 Temperature and Humidity	9
2.2.4 Cleanliness	10
2.2.5 Grounding	11
2.2.6 Surge Protection	11

	2.2.7 EMI12
	2.2.8 Installation Site
	2.3 Rack Requirements12
	2.4 Tools
3	Installing the Switch14
	3.1 Installation Procedure
	3.2 Before You Begin14
	3.3 Precautions
	3.4 Mounting a Switch15
	3.4.1 Mounted in a Rack15
	3.5 Connecting the Switch to Earth Ground
	3.6 Connecting Cables19
	3.6.1 Precautions19
	3.6.2 Steps19
	3.7 Bundling Cables
	3.7.1 Precautions20
	3.7.2 Bundling Steps21
	3.8 Verifying the Installation21
4	Networking Configuration22
	4.1 Power-on
	4.1.1 Checklist Before Power-on22
	4.1.2 Checklist After Power-on22
	4.2 Configuring the Switch through Web Login or QR Code Scanning22
	4.2.1 Configuring the Switch through Web Login22

5	Common Troubleshooting	23
	5.1 Troubleshooting Flowchart	23
	5.2 Common Faults	23
6	Appendix	25
	6.1 Interfaces, Interface Connectors, and Media	25
	6.1.1 10/100/1000BASE-T Ports	25
	6.1.2 SFP and SFP+ Ports	26
	6.2 SFP and SFP+ Transceivers	26
	6.2.1 SFP Transceivers	27
	6.2.2 SFP+ Transceivers	29
	6.3 Surge Protection	31
	6.3.1 Installing AC Power Arrester (Power Strip with Surge Protection)	31
	6.3.2 Installing the Ethernet Port Arrester	32
	6.4 Cabling Recommendations	34
	6.4.1 Requirement for the Minimum Bend Radius of Cables	34
	6.4.2 Requirement for the Minimum Bend Radius of Optical Cables	34
	6.4.3 Precautions for Cable Binding	34
	6.5 Site Selection	37
	6.6 Cleaning the Ontical Cable Connector and End Face	38

## 1 Overview

### 1.1 About the RG-NBS5200-24GT4XS-P-V2

The RG-NBS5200-24GT4XS-P-V2 is a next-generation Ethernet switch developed by Ruijie Networks. The switch features high performance, high security, and multi-service integration. It adopts an efficient hardware architecture design for more table entries, higher hardware performance, and more convenient experience.

The RG-NBS5200-24GT4XS-P-V2 provides sound end-to-end service quality and rich security settings for the medium- and small-sized networks in an extremely cost-effective manner. The switch can meet requirements of enterprise networks for high speed, security, and intelligence.

Table 1-1 Switch Specifications

Model	10/100/1000BASE- T Port	GE SFP Transceiver	10GE SFP+ Transceiver	Console Port	Power Module	Fan
RG-NBS5200- 24GT4XS-P-V2	24 (support for PoE/PoE+)	/	4	/	Fixed power module	2 x fixed fan modules

## 1.2 Package Contents

Table 1-2 Package Contents

No.	Item	Quantity
1	RG-NBS5200-24GT4XS-P-V2 switch	1
2	Rack-mount bracket	2
3	Rubber pad	4
4	User Manual	1
5	Warranty Card	1
6	M4 x 8 mm cross recessed countersunk head screw	6
7	Power cord	1
8	Power cord retention clip	1
9	Grounding wire	1

#### Note

The package contents are subject to the purchase contract, and actual delivery may vary. Please check the items carefully against the package contents or purchase contract. If you have any questions, please contact the distributor.

## 1.3 Product Appearance

The RG-NBS5200-24GT4XS-P-V2 provides 24 x 10/100/1000BASE-T ports, 4 x SFP+ ports, 1 x Reset button, 1 x LED Mode button, 1 x SYS LED, and 1 x LED Mode LED on the front panel, and 1 x power input port, 1 x grounding stud, and 2 x power cord retention clip holes on the rear panel. The following figures show the product appearance.

Figure 1-1 RG-NBS5200-24GT4XS-P-V2 Appearance



#### 1.3.1 Front Panel

Figure 1-2 Front Panel




Table 1-3 **Components on the Front Panel** 

No.	Component	Description	
		<ul> <li>Press and hold the button for less than 2 seconds. Release the button to restart the system.</li> </ul>	
1	Reset button	<ul> <li>Press and hold the button for more than 5 seconds. Release the button after the system LED starts blinking. Then, the web password is restored to the default value, and the system restores to factory settings and restarts after the configuration file is saved.</li> </ul>	

No.	Component	Description	
		<ul> <li>Press and hold the button for 2 to 5 seconds. The system is not responding.</li> </ul>	
		Press and hold the button for more than 3 seconds to switch the mode of	
		the 10/100/1000BASE-T port status LEDs. The LED Mode LED status is	
		described as follows:	
2	LED Mode button	Off: The 10/100/1000BASE-T port status LEDs (indicated by No. 6 in the figure) show the Link/ACT status.	
		Solid green: The 10/100/1000BASE-T port status LEDs (indicated by No. 6 in the figure) show the PoE status.	
		Off: The switch is not powered on.	
		Fast blinking green (10 Hz): The system is starting or upgrading.	
		Slow blinking green (0.5 Hz): The system is operating normally,	
		but is not connected to Ruijie Cloud.	
3	SYS LED	Solid green: The system is operating normally, and is connected to Ruijie Cloud.	
		Blinking yellow: The system has an alarm due to insufficient total	
		PoE power.	
		Blinking red: A system fault, switch loop, or PoE fault occurs.	
4	LED Made LED	Off: The 10/100/1000BASE-T port status LEDs (indicated by No. 6 in the figure) show the Link/ACT status.	
4	LED Mode LED	Solid green: The 10/100/1000BASE-T port status LEDs (indicated by No. 6 in the figure) show the PoE status.	
5	10/100/1000BASE- T ports	10/100/1000BASE-T ports with auto-negotiation, connected to Cat5e cables	
		Link/ACT status:	
		Off: The port is not connected.	
		<ul> <li>Solid green: The port is operating at 10 Mbps, 100 Mbps, or 1000 Mbps, but is not receiving or sending data.</li> </ul>	
6	10/100/1000BASE- T port status LEDs	o Blinking green: The port is operating at 10 Mbps, 100 Mbps, or 1000 Mbps, and is receiving or sending data.	
		PoE power status:	
		o Off: PoE is disabled.	
		o Solid green: PoE is enabled.	
		Blinking green: PoE overload occurs.	
7	Nameplate	The nameplate is located at the bottom of the switch.	
8	SFP+ ports	The ports can work with 10GE SFP+ or 1GE SFP modules, and support hot swapping.	
		Off: The port is not connected.	
9	SFP+ port status LED	Solid green: The port is operating at 10 Gbps or 1 Gbps, but is not receiving or sending data.	
		Blinking green: The port is operating at 10 Gbps or 1 Gbps, and is receiving or sending data.	

#### 1.3.2 Rear Panel

Figure 1-3 Rear Panel




Table 1-4 Components on the Rear Panel

No.	Component Description		
1	Power input port	Connected to an external AC power supply.	
2	Power cord retention clip hole	You can secure the power cord retention clip to the holes.	
3	Grounding stud	You can secure the terminal of a grounding wire to the grounding stud to connect the chassis to earth ground.	

## 1.4 Cooling

The RG-NBS5200-24GT4XS-P-V2 switch adopts the left-to-right airflow design to ensure that the switch works properly in the specified environment. Maintain sufficient clearance on both sides of the chassis (according to the reserved values indicated in the specific installation section) for air circulation. Dust the switch every three months to avoid blocking the ventilation openings on the housing. The following figure shows the cooling.

Figure 1-4 Cooling



## 1.5 Technical Specifications

- Warning
- Operation of this equipment in a residential environment could cause radio interference.
- This equipment is not suitable for use in locations where children are likely to be present.

• Double pole/neutral fusing. Risk of electric shock. The circuit breaker is on the neutral wire of the grid power supply. Cut off the grid power supply to disconnect each phase conductor.



#### Caution

- When a fixed power module of the RG-NBS5200-24GT4XS-P-V2 is repaired, do not replace the original circuit breaker. Otherwise, the device loses the overload and short-circuit protection functions.
- The RG-NBS5200-24GT4XS-P-V2 switch has a built-in lithium battery to keep the real-time clock running when external power source is unavailable. To replace the lithium battery, please contact Ruijie Networks Customer Service Technical Support to have it replaced with a lithium battery of the same specifications.
- Risk of fire or explosion or defeat the safeguard of equipment if the battery is replaced by an incorrect type. Replace only with the same or equivalent type.
- Leaving the battery in an extremely high temperature and/or low air pressure surrounding environment that can result in an explosion or the leakage of flammable liquid or gas.
- Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion.

Table 1-5 Technical Specifications

Model	RG-NBS5200-24GT4XS-P-V2	
CPU	Built-in single-core CPU, each core with the clock speed of 800 MHz	
Flash Memory	256 MB	
Memory	512 MB	
Port	<ul> <li>24 x 10/100/1000BASE-T ports, supporting PoE/PoE+</li> <li>4 x 10GE SFP+ transceivers</li> </ul>	
Supported Optical	For details, see 6.2 SFP and SFP+ Transceivers. Copper cables are not supported.	
Transceiver and	The module types may update without prior notification. Please contact Ruijie	
Cable Module	Networks for details.	
Types		
	1 x SYS status LED	
LED	1 x LED Mode LED	
	● 24 x 10/100/1000BASE-T port status LEDs	
	4 x SFP+ port status LEDs	
	220 V AC power supply:	
Power Module	Voltage range: 100 V AC to 240 V AC	
	Frequency: 50/60 Hz	
	Maximum input current: 6 A	
РоЕ	PoE/PoE+ (IEEE 802.3af/at)	

	Maximum PoE output power per port: 30 W	
	Overall maximum PoE output power: 370 W	
	• PoE power pins: 1–2 (+), 3–6 (–)	
EEE	Supported	
Overall Maximum	30 W (with no PoE load)	
Power	430 W (with full PoE load)	
Temperature Alarm	Not supported	
Fan	2 x fixed fan modules	
	Fan monitoring: not supported	
	Fan speed adjustment: support for intelligent speed adjustment	
Cooling	Air cooling, left-to-right ventilation	
Altitude	Operating altitude: 0 m to 5,000 m (0 ft. to 16,404.20 ft.)	
7 iiiiddo	• Storage altitude: 0 m to 5,000 m (0 ft. to 16,404.20 ft.)	
Operating	0°C to 50°C (32°F to 122°F)	
Temperature		
Storage	-40°C to +70°C (-40°F to +158°F)	
Temperature		
Operating Humidity	10% to 90% RH (non-condensing)	
Storage Humidity	5% to 95% RH (non-condensing)	
Surge Dretection	Service ports: common mode (±6 kV)	
Surge Protection	Power port: common mode (±6 kV), differential mode (±6 kV)	
Certification	CE	
Dimensions (W x D x H)	440 mm x 222.6 mm x 44 mm (17.32 in. x 8.76 in. x 1.73 in.)	
Product Weight	2.88 kg (6.35 lbs., excluding packaging materials)	
Shipping Weight	4.00 kg (8.82 lbs., including packaging materials)	

## **2** Preparing for Installation

## 2.1 Safety Guidelines



#### Note

- To avoid personal injury or equipment damage, review the safety guidelines in this chapter before you begin the installation.
- The following safety guidelines may not include all the potentially hazardous situations.

#### 2.1.1 General Precautions

- Install the equipment in a standard 19-inch rack.
- Cut off all power supplies and unplug all cables before mounting the equipment in a rack or removing it from a rack.
- Never operate the equipment in a wet environment, and avoid any liquids inside it. Keep the chassis clean and dust-free.
- Keep the equipment away from heat sources.
- Ensure that the rack and power distribution system are properly grounded.
- Keep the equipment away from walk areas.
- During installation and maintenance, do not wear loose clothing or ornament that may get caught in the chassis.
- Keep tools and accessories away from walk areas.

#### 2.1.2 Chassis-Lifting Guidelines

- Avoid moving the equipment frequently.
- Turn off all power supplies and disconnect all cables before lifting or moving the equipment.
- Keep balance and prevent personal injuries when lifting or moving the equipment.

#### 2.1.3 Electricity Safety



#### Warning

- Any deviation from standard or improper electrical operations can result in accidents such as fires or electric shocks, potentially causing severe or even fatal harm to both individuals and equipment.
- Direct or indirect touch through a wet object on high-voltage and mains supply can bring a fatal danger.
- Always observe the local regulations and standards. Only qualified personnel should be allowed to operate
  the equipment.
- Carefully check the work area for potential hazards, including ungrounded power system, absent safety grounds, and damp floors.
- Locate the emergency power-off switch in the room before installation. In the case of an accident, cut off the

power supply immediately.

- Do not assume that the power supply is turned off. Never assume that power is disconnected from a circuit.
   Always check.
- Select the right leakage protector (also called "leakage current switch" or "leakage current breaker") for the
  power supply system. This equipment automatically disconnects the power supply in the event of leakage
  and the risk of electric shock. A leakage protector should meet the following requirements:
  - o The rated leakage action current of each leakage protector is greater than twice the theoretical maximum leakage current of all the power supplies in the system.

For example, if a system is equipped with 16 identical power supplies, and the leakage current of each power supply is equal to or less than 3.5 mA, then the leakage current of the system totals 56 mA. A leakage protector with a rated leakage action current of 30 mA supports no more than four power supplies (that is, action current of the leakage protector/2/Maximum leakage current of each power supply =  $30/2/3.5 \approx 4.28$ ). In this case, 16 power supplies in the system require at least four leakage protectors with a rated action current of 30 mA, with each leakage protector supporting four power supplies.

Although the number of power supplies in a system differs in models, the rated leakage action current of each leakage protector divided by two must be greater than the sum of the maximum leakage current of all the power supplies.

o The rated leakage non-action current of a leakage protector should be 50% of the leakage action current.
If the non-action current value is too small, the high sensitivity level can cause the circuit to break, leading to power cutoff and service interruption, even if the leakage current value is normal.

For example, if a leakage protector has a rated leakage action current of 30 mA, the rated leakage non-action current should be 15 mA. The leakage protector will not activate unless the leakage current exceeds 15 mA.

#### Caution

- To ensure personal safety, each leakage protector in the system must have a rated leakage action current equal to or below 30 mA, which is the recognized safety threshold for the human body current. If the total leakage current of the system exceeds twice the 30 mA limit, the system must be equipped with two or more leakage protectors to maintain safety.
- The leakage current values vary with equipment. For the leakage current value of each equipment model, see the technical specifications in 1.5 Technical Specifications.

#### 2.1.4 Preventing ESD Damage

- Ensure that the grounding stud on the rear panel of the equipment is grounded.
- Ensure that the AC power socket is a single-phase three-core power socket with protective earthing conductors (PE).
- Keep the site as dust free as possible.
- Maintain appropriate humidity conditions.
- Before installing any pluggable modules, wear an anti-ESD wrist strap and make sure that it is properly grounded.

#### 2.1.5 Laser Safety

The equipment with optical ports supports various types of optical transceivers, which are Class I laser products. Pay attention to the following:

- When an optical transceiver is working, ensure that its port is connected to an optical cable or covered by a
  dust cap to keep out dust and prevent it from burning your eyes.
- When an optical transceiver is working, do not stare into its port after removing the optical fiber. Otherwise, your eyes may be hurt.

Figure 2-1 Laser Product ID



#### 0

#### Warning

Do not approach or stare into an optical port under any circumstances. This may cause permanent damage to your eyes.

## 2.2 Site Requirements

The equipment must be installed indoors for normal operation and prolonged service life. The installation site must meet the following requirements.

#### 2.2.1 Floor Loading

Assess the combined weight of the equipment and its accessories, such as rack and cables, and verify that the floor under the rack can bear the weight.

#### 2.2.2 Space

You are advised to have a pathway of at least 0.8 meters (2.62 ft.) wide in the equipment room. This space ensures that you can move the chassis and swap the modules easily.

Do not install the equipment against a wall. Instead, maintain a minimum clearance (as indicated in the installation section) around the equipment for heat dissipation and equipment maintenance.

#### 2.2.3 Temperature and Humidity

To ensure normal operation and prolonged service life of the equipment, maintain appropriate temperature and humidity conditions in the equipment room. Prolonged exposure to inappropriate temperature and humidity conditions can cause damage to the equipment.

• In an environment with high relative humidity, insulating materials are prone to poor insulation or even

electricity leakage.

- In an environment with low relative humidity, insulating gaskets may shrink, resulting in screw loosening.
- In a dry environment, static electricity is more likely to occur, posing a risk to the internal circuits of equipment.
- A high temperature can accelerate the aging process of insulation materials, greatly reducing the availability of the equipment and severely affecting its service life.



#### Note

The operating temperature and humidity of the equipment are measured at the point that is 1.5 m (4.92 ft.) above the floor and 0.4 m (1.31 ft.) before the equipment when there is no protective plate in front or at the back of the equipment.

#### 2.2.4 Cleanliness

Dust poses a significant hazard to the equipment. Dust on the enclosure causes electrostatic adhesion, leading to poor contact of the metallic joints. Electrostatic adhesion is more likely to occur in an indoor environment with relatively low humidity, not only affecting the service life of the equipment, but also causing communication faults. The following table lists the requirements for dust concentration and particle size in the equipment room.

Table 2-1 **Requirements for Dust** 

Particle Diameter	Unit	Concentration
≥ 0.5 µm	Particles/m <sup>3</sup>	≤ 3.5 x 10 <sup>6</sup>
≥ 5 µm	Particles/m <sup>3</sup>	≤ 3 x 10 <sup>4</sup>

Apart from dust, there are also requirements on the salt, acid, and sulfide in the air of the equipment room. These harmful substances will accelerate metal corrosion and component aging. Therefore, the equipment room should be properly protected against harmful gases, such as sulfur dioxide, hydrogen sulfide, nitrogen dioxide, chlorine gas, and so on. The following table lists the limits on harmful gases.

Table 2-2 **Requirements for Gases** 

Gas	Average (mg/m³)	Maximum (mg/m³)
Sulfur dioxide (SO <sub>2</sub> )	0.3	1.0
Hydrogen sulfide (H₂S)	0.1	0.5
Nitrogen dioxide (NO <sub>2</sub> )	0.5	1.0
Chlorine gas (Cl <sub>2</sub> )	0.1	0.3



#### Note

Average refers to the average value of harmful gases measured in a week. Maximum refers to the upper limit of harmful gases measured in a week for up to 30 minutes every day.

#### 2.2.5 Grounding

A proper grounding system is crucial for ensuring stable and reliable operation, as well as preventing lightning strikes and interference. Carefully check the grounding conditions at the installation site according to the grounding requirements, and complete grounding properly based on the site situation.

#### **Safety Grounding**

Ensure that the equipment is securely grounded using grounding wires if the equipment uses the AC power supply. Otherwise, electric shocks may occur when the insulation resistance between the power module and the chassis decreases.

#### Caution

- The building should provide a protective ground connection to ensure that the equipment is connected to a protective ground.
- The O&M personnel should verify that the AC socket is reliably connected to the protective grounding system of the building. If not, the O&M personnel should use a protective grounding wire to connect the protective grounding lug of the AC socket to the protective grounding system of the building.
- The power socket should be installed near the equipment and easily accessible.
- During the installation, the ground connection must always be made first and disconnected last.
- The cross-sectional area of the protective grounding cable should be at least 0.75 mm2 (18 AWG).
- Install the equipment by using 3-core power cords, with a minimum cross-sectional area of 0.75 mm2 or 18 AWG per pin.

#### **Lightning Grounding**

The lightning protection system is an independent system composed of a lightning rod, a downlead conductor, and a connector connected to the grounding system. The grounding system is typically used for power reference grounding and safety grounding of the rack. Lightning grounding is required only for facilities and is not required for the equipment.



#### Note

For surge protection, see <u>6.3</u> Surge Protection.

#### **EMC Grounding**

Electromagnetic compatibility (EMC) grounding includes shielded grounding, filter grounding, noise and interference suppression, and level reference, which contribute to the overall grounding requirements. The grounding resistance should be smaller than 1 ohm. The RG-NBS5200-24GT4XS-P-V2 switch provides one grounding stud on the back panel.

#### 2.2.6 Surge Protection

- Ensure that the neutral point of the AC power socket is in good contact with the ground.
- Install a power arrester in front of the power input end to enhance surge protection for the power supply.
- When an AC power cord is introduced from outdoors and directly connected to the power port of the switch, the AC power port must be connected to an external power strip with surge protection to protect the switch against lightning strokes. Connect the mains AC power cord to the power strip with surge protection, and then connect the equipment to the power strip with surge protection. This prevents the current of high-voltage

lightning from directly passing through the switch along the mains cable.



#### Note

- Power strips with surge protection are customer-supplied.
- For details on how to use a power strip with surge protection, see the related user guide.

#### 2.2.7 EMI

All interference sources, either from outside or inside of the equipment or application system, affect the equipment by capacitive coupling, inductive coupling, or electromagnetic waves. Electromagnetic interference (EMI) occurs due to radiated interference or conducted interference, depending on the transmission path. When the energy, often RF energy, from a component arrives at a sensitive component through the space, the energy is known as radiated interference. The interference source can be either a part of the interfered system or a completely electrically isolated unit. Conducted interference occurs when interference is transferred from one unit to another unit through cables, which are usually electromagnetic wires or signal cables connected between the source and the sensor. Conducted interference often affects the power supply of the equipment, but can be controlled by a filter. Radiated interference may affect any signal path in the equipment, and is difficult to shield.

The requirements for the equipment anti-interference are as follows:

- Take interference prevention measures for the power supply system.
- Keep the switch away from the grounding system or surge protection grounding system of the power facility.
- Keep the equipment far away from high-frequency current equipment such as high-power radio transmitting stations and radar stations.
- Take electromagnetic shielding measures when necessary.

#### 2.2.8 Installation Site

Regardless of whether the equipment is installed in a rack or on a workbench, ensure that the following conditions are met:


- Maintain a proper clearance around the air inlets and outlets for heat dissipation.
- The installation site has a good cooling and ventilation system.
- The installation site is sturdy enough to support the weight of the chassis and its components.
- The installation site is properly grounded.

## 2.3 Rack Requirements

The RG-NBS5200-24GT4XS-P-V2 switch can be installed in a 19-inch EIA rack. If you want to install the equipment in a rack, make sure that the rack observes the following requirements:

- Use a four-post 19-inch cabinet.
- The left and right square-hole rack posts are 465 mm (18.31 in.) apart.

Figure 2-2 19-Inch Rack



- The square-hole rack post is at least 180 mm (7.09 in.) from the front door, and the front door is at most 25 mm (0.98 in.) thick. This ensures an available clearance of at least 155 mm (6.10 in.). The rack depth (distance between front and rear doors) is at least 1000 mm (39.37 in.).
- The guide rails or tray can bear the weight of the equipment and its accessories.
- The rack has a reliable grounding lug for the chassis to connect to earth ground.
- The rack has a reliable ventilation system. The open area of front and rear doors is greater than 50%.

#### 2.4 Tools

Table 2-3 Tools

Common Tools	Phillips screwdriver, flat-blade screwdriver, cables, Ethernet cables, four M6 screws and their cage nuts (for cabinet installation), diagonal pliers, cable ties, SC-SC optical fibers
<b>Dedicated Tools</b>	Anti-ESD glove, wire stripper, crimper, RJ45 connector crimping plier, and wire cutter
Meters	Multimeter
Relevant Equipment	PC, display, and keyboard



Note

The equipment is delivered without a toolkit. Prepare the preceding tools by yourself.


# 3 Installing the Switch



Caution

Before installing the equipment, ensure that guidelines and requirements in Chapter 2 have been met.

#### 3.1 Installation Procedure



## 3.2 Before You Begin

- The installation site provides sufficient space for heat dissipation.
- The installation site meets the temperature and humidity requirements.
- The power supply is available at the installation site, and its current meets the requirements.
- The Ethernet cables have been deployed at the installation site.
- The power supply meets the requirements.
- Locate the emergency power-off switch in the room before installation. In the case of an accident, cut off the power supply immediately.

#### 3.3 Precautions

During installation, pay attention to the following:

- Connect the power cords of different colors to the corresponding cable terminals.
- Ensure that the connector of the power cord is properly seated in the power port of the equipment. After plugging the power cord into the equipment, secure the power cord with a power cord retention clip.
- Do not place anything on the RG-NBS5200-24GT4XS-P-V2 switch.
- Maintain sufficient clearance (as indicated in the installation section) around the equipment to ensure proper airflow. Do not stack switches.
- Keep the RG-NBS5200-24GT4XS-P-V2 switch away from high-power radio transmitting stations, radar stations, and high-frequency large-current devices. Take electromagnetic shielding measures to minimize interference when necessary, for example, use shielded interface cables.
- Route Ethernet cables with a distance of 100 meters (328.08 ft.) indoors. Take surge protection measures if they need to be routed outdoors.
- Route optical fibers indoors. Take protection measures to ensure that optical fibers are not damaged when they are routed outdoors.

### 3.4 Mounting a Switch


The RG-NBS5200-24GT4XS-P-V2 switch can be mounted in a rack.

#### 3.4.1 Mounted in a Rack

The RG-NBS5200-24GT4XS-P-V2 switch can be installed in a 19-inch rack. Take the following installation steps:

(1) Take out six M4 x 8 mm cross recessed countersunk head screws (provided with the rack-mount brackets). Secure one end of each rack-mount bracket to the switch using the screws, as shown in Figure 3-1.

Figure 3-1 Securing Rack-Mount Brackets



(2) Horizontally mount the switch to an appropriate position inside the rack, and use M6 screws and cage nuts to secure the other end of the rack-mount brackets to square holes of the rack.

Figure 3-2 Securing Rack-Mount Brackets to the Rack (1)






Figure 3-3 Securing Rack-Mount Brackets to the Rack (2)



## 3.5 Connecting the Switch to Earth Ground

The switch has a grounding point on the rear panel. Connect the grounding point to the grounding lug of the rack and then connect the grounding lug of the rack to the grounding bar of the equipment room.

Figure 3-4 Grounding Installation



• The sectional area of a grounding wire should be determined according to the possible maximum current.

- Grounding wires with good conductors should be used.
- Do not use bare wire.
- The resistance between the chassis and ground should be less than 1 ohm.

## 3.6 Connecting Cables

#### 3.6.1 Precautions

- Make sure that the models of optical transceivers and optical cables match with SFP ports. The transmitting
  port on the local device should be connected to the receiving port on the peer device and vice versa.
- Avoid a small bend radius at the connector.

#### 3.6.2 Steps


Connect the power cord.

Insert the power cord retention clip into the power cord retention clip holes, place the power cord retention clip upward, insert the power cord, and then place the power cord retention clip downward to secure the power cord.



Use the delivered power cords. Otherwise, security accidents may occur.

Figure 3-5 Connecting the Power Cord



#### Connect cables.

- a Connect the RJ45 connector of a twisted pair cable to the Ethernet port on the switch, and the other end to a managed device or PC.
- a Plug the SMF and MMF optical fibers into the corresponding ports according to the panel identification, and distinguish the transmitting and receiving ends of the optical fibers.

## 3.7 Bundling Cables

#### 3.7.1 Precautions

- Bundle the power cord and other cables in an esthetically pleasing way.
- Make sure that the fibers at the connectors have natural bends or bends of large radius.
- Do not bind fibers and twisted pair cables too tightly, as this may press the fibers and affect their service life and transmission performance.

#### 3.7.2 Bundling Steps

(1) Bind the drooping part of the optical cables and twisted pairs, and lead them to both sides of the chassis for convenience.

- (2) On both sides of the chassis, fasten the optical fibers and twisted pair cables to the cable management ring or cabling chute.
- (3) For the power cords, you should bind them closely along the bottom of the chassis, in a straight line wherever possible.

### 3.8 Verifying the Installation

- Verify that the grounding wire is connected.
- Verify that the cables including power cords are properly connected.
- Check whether the cables with a distance of 100 meters (328.08 ft.) are routed indoors. If not, check whether
  the power strip with surge protection, Ethernet surge protector, and others are installed for the AC power
  supply.
- Verify that there is sufficient clearance around the equipment (as indicated in the installation section) to ensure proper airflow.

# 4 Networking Configuration

#### 4.1 Power-on

#### 4.1.1 Checklist Before Power-on

- The equipment is properly grounded.
- The power cord is reliably connected.
- The input voltage meets the requirement.
- The network port of the PC is properly connected to the console port of the switch.

#### 4.1.2 Checklist After Power-on


- The LED status is normal.
- Service ports can forward data properly.

### 4.2 Configuring the Switch through Web Login or QR Code Scanning

#### 4.2.1 Configuring the Switch through Web Login

- (1) Connect a PC to an Ethernet port on the switch through an Ethernet cable.
- (2) Set the IP address of the PC to 10.44.77.XXX (1-255, excluding 200).

Figure 4-1 Modifying the PC's IP Address



- (3) Open a browser, and enter 10.44.77.200 in the address bar to log in to the configuration system. The default password is admin.
- (4) Perform device commissioning and configuration based on service requirements.


#### Caution

For security purposes, change the password after login.

# **5** Common Troubleshooting

### 5.1 Troubleshooting Flowchart

Figure 5-1 Troubleshooting Flowchart



### 5.2 Common Faults

Table 5-1 Common Faults and Troubleshooting

Fault Symptom	Possible Cause	Solution	
The login password cannot be retrieved.	The login password is forgotten after being configured.	Press and hold the Reset button for over five seconds to reset your username and password.	
The SYS LED is off after the switch is powered on.	No power is supplied to the switch or the power cord is loose.	Check whether the power socket in the equipment room is normal and whether the power cord connected to the switch is loose.	
An RJ45 port is disconnected or a frame	<ul> <li>The twisted pair cable is not connected properly.</li> <li>The cable length exceeds 100 m (328.08 ft.).</li> <li>The port is specially configured</li> </ul>	<ul> <li>Replace the twisted pair cable.</li> <li>Use optical cables or connect to an intermediate switch for relay.</li> <li>Make sure that the port works in the same mode as the interconnected</li> </ul>	

Fault Symptom	Possible Cause	Solution
sending/receiving error occurs.	and does not use the same work mode as the interconnected switch.	switch.
An optical port cannot be connected.	<ul> <li>The transmit and received ends are connected incorrectly.</li> <li>The types of the interconnected optical transceivers do not match.</li> <li>The optical fiber type does not meet requirements.</li> <li>The optical fiber length is beyond the allowed length marked on the optical transceiver.</li> <li>The optical cable or connector is contaminated.</li> </ul>	<ul> <li>Exchange the transmit and received ends of the optical cable.</li> <li>Replace the optical transceiver with another one of the same type.</li> <li>Replace the optical fiber with a qualified one.</li> <li>Use an optical fiber with the required length.</li> <li>Clean the connector with a lint-free cloth or a cleaning pen. For details, see Appendix.</li> </ul>

# 6 Appendix

### 6.1 Interfaces, Interface Connectors, and Media

#### 6.1.1 10/100/1000BASE-T Ports

The 10/100/1000BASE-T port supports auto-negotiable 10/100/1000 Mbps and automatic MDI/MDIX crossover. It can be connected to an RJ45 connector.

Compliant with IEEE 802.3ab, 1000BASE-T requires 100-ohm Category 5 or Category 5e UTP or STP (STP is recommended) with a maximum distance of 100 meters (328.08 ft.).

The 1000BASE-T port requires that all four pairs of wires be connected for data transmission. <u>Figure 6-1</u> shows twisted pair connections for the 1000BASE-T port.

Figure 6-1 1000BASE-T Twisted Pair Connections

Straight-T	hrough	Cross	over
Switch	Switch	Switch	Switch
1TP0+ ←	→ 1TP0+	1TP0+ <b>←</b>	→1TP0+
2TP0- <b>←</b>	→ 2TP0-	2TP0- <b>←</b>	→2TP0-
3TP1+ <b>←</b>	→ 3TP1+	3TP1+ ←	→3TP1+
6TP1- <b>←</b>	→ 6TP1-	6TP1- <b>←</b>	→6TP1-
4TP2+ <b>←</b>	→ 4TP2+	4TP2+ <b>←</b>	→4TP2+
5TP2- ←	→ 5TP2-	5TP2- <b>←</b>	→5TP2-
7TP3+ <b>←</b>	→ 7TP3+	7TP3+	<b>→</b> 7TP3+
8TP3- <b>←</b>	→ 8TP3-	8TP3- <b>←</b>	→8TP3-

The 10/100BASE-T port can also be connected by cables of the preceding specifications. Besides, the 10BASE-T port can be connected by 100-ohm Category 3, Category 4, and Category 5 cables with a maximum distance of 100 meters (328.08 ft.). The 100BASE-TX port can be connected by 100-ohm Category 5 cables with a maximum distance of 100 meters (328.08 ft.). Table 6-1 lists pin assignments for the 10/100BASE-T port.

Table 6-1 10/100BASE-T Pin Assignments

Pin	Socket	Plug
1	Input Receive Data+	Output Transmit Data+
2	Input Receive Data-	Output Transmit Data-
3	Output Transmit Data+	Input Receive Data+
6	Output Transmit Data-	Input Receive Data-
4, 5, 7, 8	Not used	Not Used

Figure 6-2 shows feasible connections of the straight-through and crossover twisted pairs for a 10/100BASE-T port.

Figure 6-2 10/100BASE-T Twisted Pair Connections

Straight-Through		Crossover		
Switch	Adapter	Switch	Switch	
1 IRD+ ←	→ 1 OTD+	1 IRD+ ←	→ 1 IRD+	
2 IRD- ←	→ 2 OTD-	2 IRD- ←	→ 2 IRD-	
3 OTD+ <b>←</b>	→ 3 IRD+	3 OTD+←	→ 3 OTD+	
6 OTD- ←	→ 6 IRD-	6 OTD- ←	→ 6 OTD-	

#### 6.1.2 SFP and SFP+ Ports

Optical transceivers or copper transceivers need to be inserted into the SFP and SFP+ ports.

- Optical transceivers inserted into SFP and SFP+ use LC connectors and are connected to the peer end through optical cables.
- Copper transceivers inserted into the SFP ports use RJ45 connectors and are connected to the peer end through an Ethernet cable.

Select single-mode fibers (SMFs) or multimode fibers (MMFs) for connections according to the types of the optical transceivers connected. <u>Figure 6-3</u> shows the connections. The local TX end must be connected to the remote RX end, and the local RX end must be connected to the remote TX end.

Figure 6-3 Connecting the Optical Cables



#### 6.2 SFP and SFP+ Transceivers

We provide SFP and SFP+ transceivers based on port types, allowing you to choose the one that best suits your needs.

SFP transceivers are 1GE modules (support for optical transceivers and copper transceivers – mini-GBIC-GT modules). SFP+ transceivers are 10GE modules. The following models and technical specifications of some SFP and SFP+ transceivers are listed for your reference. For details about technical specifications, see the *Ruijie Transceiver Installation and Reference Guide*.

### 6.2.1 SFP Transceivers

Table 6-2 1GE Mini-GBIC (SFP) Models and Technical Specifications

Model		Optical Fiber	Support	Transmit Power (dBm)		Receive Power (dBm)	
	(nm)	Туре	(Yes/No)	Min	Ma x	Min	Ma x
MINI-GBIC-SX-MM850	850	MMF	No	-9.5	-3	-17	0
MINI-GBIC-LX-SM1310	1310	SMF	No	-9.5	-3	-20	-3
MINI-GBIC-LH40-SM1310	1310	SMF	Yes	-2	3	-22	-3
GE-SFP-LX20-SM1310- BIDI	1310TX /1550R X	SMF	Yes	-9	-3	-20	-3
GE-SFP-LX20-SM1550- BIDI	1550TX /1310R X	SMF	Yes	-9	-3	-20	-3
GE-SFP-LH40-SM1310- BIDI	1310TX /1550R X	SMF	Yes	-5	0	-24	-1
GE-SFP-LH40-SM1550- BIDI	1550TX /1310R X	SMF	Yes	-5	0	-24	-1
MINI-GBIC-ZX80-SM1550	1550	SMF	Yes	0	4.7	-22	-3
NIS-GE-SFP-10KM- SM1310	1310	SMF	Yes	-9.5	-3	-20	-3
NIS-GE-SFP-20KM- SM1310-BIDI	1310TX /1550R X	SMF	Yes	-9	-3	-22	-3
NIS-GE-SFP-20KM- SM1550-BIDI	1550TX /1310R X	SMF	Yes	-9	-3	-22	-3
NIS-GE-SFP-550M-MM850	850	MMF	Yes	-9.5	-3	-17	0

Table 6-3 1GE SFP Copper Transceivers

Standard	1000BASE-T SFP Model	DDM Supported (Yes/No)	
1000BASE-T	Mini-GBIC-GT	No	

Table 6-4 Cabling Specifications of SFP Transceivers

Model	Interface Type	Optical Fiber Type	Core Size (μm)	Max Cabling Distance
MINI-GBIC-SX-MM850	LC	MMF	62.5/125	275 m (902.23 ft.)
WILL SELECTION OF THE S			50/125	550 m (1804.46 in.)
MINI-GBIC-LX-SM1310	LC	SMF	9/125	10 km (6.21 miles)
MINI-GBIC-LH40-SM1310	LC	SMF	9/125	40 km (24.85 miles)
GE-SFP-LX20-SM1310-BIDI	LC	SMF	9/125	20 km (12.43 miles)
GE-SFP-LX20-SM1550-BIDI	LC	SMF	9/125	20 km (12.43 miles)
GE-SFP-LH40-SM1310-BIDI	LC	SMF	9/125	40 km (24.85 miles)
GE-SFP-LH40-SM1550-BIDI	LC	SMF	9/125	40 km (24.85 miles)
MINI-GBIC-ZX80-SM1550	LC	SMF	9/125	80 km (49.71 miles)
Mini-GBIC-GT	RJ45 cable	Category 5 (or higher) UTP or STP cable		100 m (328.08 ft.)

#### Note

- For optical transceivers with a cabling distance of no less than 40 km (24.85 miles), install an optical attenuator to avoid overload when using short-distance SMFs.
- An optical transceiver is a laser transmitter. Do not look into the light source to prevent it from burning your eyes.
- To keep the optical transceiver clean, make sure that the unused ports remain capped.

Pairing Description of the BIDI Optical Transceiver Table 6-5

Rate/Distance	Pairing Model
GE/20 km (12.43 miles)	GE-SFP-LX20-SM1310-BIDI and GE-SFP-LX20-SM1550-BIDI
	NIS-GE-SFP-20KM-SM1310-BIDI and NIS-GE-SFP-20KM-SM1550-BIDI
GE/40 km (24.85 miles)	GE-SFP-LH40-SM1310-BIDI and GE-SFP-LH40-SM1550-BIDI

#### **A** Caution

BIDI optical transceivers must be used in pairs. If GE-SFP-LX20-SM1310-BIDI is used at one end, GE-SFP-LX20-SM1550-BIDI then must be used at the other end.

#### 6.2.2 SFP+ Transceivers

Current models of 10GE SFP+ optical transceivers:

Models and Technical Specifications of 10GE SFP+ Transceivers Table 6-6

	Wavelength	DDM Support	Optic al Fiber	Transmit Power (dBm)		Receive Power (dBm)	
Model	(nm)	(nm) ed (Yes/No)		Min	Max	Min	Max
XG-SFP-SR- MM850	850	Yes	MMF	-7.3	-1	-9.9	-1
SFP+MM850	850	Yes	MMF	-7.3	-1	-9.9	-1
XG-SFP-LR- SM1310	1310	Yes	SMF	-8.2	0.5	-14.4	0.5
XG-SFP-ER- SM1550	1550	Yes	SMF	-4.7	4	-11.3	-1
XG-SFP-ZR- SM1550	1550	Yes	SMF	0	4	-24	-7

Table 6-7 10GE SFP+ Active Optical Cables

Model	Туре	Connect or Type	Copper Cable Length (m)	Condu ctor Diame ter (AWG)	Data Speed (Gbps)	DDM Support ed (Yes/No)
XG-SFP-AOC1M	Active	SFP+	1	\	10.3125	Yes
XG-SFP-AOC3M	Active	SFP+	3	١	10.3125	Yes
XG-SFP-AOC5M	Active	SFP+	5	١	10.3125	Yes
XG-SFP- AOC10M	Active	SFP+	10	\	10.3125	Yes

#### Note

- SFP+ transceiver types are subject to change without prior notice. For more accurate information about the optical transceivers, contact the Ruijie marketing or technical support personnel.
- In the DDM function of the AOC cable, the transmit power may be displayed as N/A.

Table 6-8 Cabling Specifications of SFP+ Transceivers

Model	Interface Type	Optical Fiber Type	Core Size (μm)	Modal Bandwidth (MHz-km)	Max Cabling Distance
XG-SFP-SR- MM850	LC	MMF	50/125	2000 (OM3)	300 m (984.25 ft.)
SFP+MM850	LC	MMF	50/125	2000 (OM3)	300 m (984.25 ft.)
XG-SFP-LR- SM1310	LC	SMF	9/125	N/A	10 km (6.21 miles)
XG-SFP-ER- SM1550	LC	SMF	9/125	N/A	40 km (24.85 miles)
XG-SFP-ZR- SM1550	LC	SMF	9/125	N/A	80 km (49.71 miles)

#### 6.3 Surge Protection

#### 6.3.1 Installing AC Power Arrester (Power Strip with Surge Protection)

When an AC power cord is introduced from outdoors and directly connected to the power port of the equipment, the AC power port must be connected to an external power strip with surge protection to protect the equipment against lightning strokes. The power strip with surge protection can be fixed on the rack, workbench, or wall in the equipment room by using cable ties and screws. AC power enters the power strip with surge protection and then enters the equipment.

Figure 6-4 Power Arrester




Table 6-9 Power Arrester

No.	Feature
1	Electronic circuit board (internal)
2	Normal operation LED. When the LED is green, the circuit is working properly. Otherwise, the protective circuit is damaged.
3	Grounding and polarity detection LED. If the LED is red, the cable connection is incorrect (the ground cable is not connected, or the N and L lines are reversely connected). Check your power supply lines.
4	Power switch.
5	IEC standard socket, which is connected to the power supply in the equipment room through a power cord.
6	Overload protector, which can be reset manually.

7	Multi-purpose socket (connected to the power supply of the equipment)
---	---



#### Caution

The power arrester is not delivered with the equipment. Please purchase it based on actual requirements.

Precautions during the installation:

- Make sure that the PE terminal of the power arrester is well grounded.
- After the AC power plug of the switch is connected to the socket of the power arrester (power strip with surge
  protection), surge protection is implemented only if the running status LED is green and the alarm LED is off.
- If the alarm LED on the power arrester is red, check whether it is caused by a poor grounding connection or by the reversed connection of the neutral and live wires. The detection method is as follows: Use a multimeter to measure the polarity of the power socket for the arrester when the LED is red. If the neutral wire is on the left and the live wire is on the right (facing the socket), the arrester's PE terminal is not grounded. If not, the polarity of the arrester should be reversed. In this case, open the lightning arrester and rectify the polarity of the connection. If the LED is still red, the arrester's PE terminal is not grounded.

#### **6.3.2 Installing the Ethernet Port Arrester**

Please connect an Ethernet port arrester to the equipment to prevent the damage by lightning before connecting an outdoor Ethernet cable to the equipment.

Tools: Phillips screwdriver or flat-blade screwdriver, multimeter, and diagonal pliers

Installation steps:

- (1) Tear one side of the protective paper for the double-sided adhesive tape and paste the tape to the enclosure of the Ethernet port arrester.
- (2) Tear the other side of the protective paper for the double-sided adhesive tape and paste the Ethernet port arrester to the equipment enclosure as close to the grounding lug of the equipment as possible.
- (3) According to the distance between the equipment grounding lug and the Ethernet port arrester, cut the grounding cable for the Ethernet port arrester and firmly crimp the grounding cable to the grounding lug of the equipment.
- (4) Use a multimeter to check whether the grounding cable for the arrester is in good contact with the grounding lug and the enclosure of the equipment.
- (5) Connect the arrester using an adapter cable (note that the external Ethernet cable is connected to the IN end, while the OUT end is connected to the adapter cable) and check whether the module LED is normal.
- (6) Use a nylon cable tie to bind the cables.

Figure 6-5 Installing an Ethernet Port Arrester




Table 6-10 Installing an Ethernet Port Arrester

No.	Description
1	Ethernet cable for indoor connection
2	Ethernet cable for outdoor connection
3	RJ45 Ethernet port arrester (pasted on the switch enclosure)
4	Grounding cable of the arrester
5	Grounding stud of the equipment
6	Adapter cable for the RJ45 Ethernet port
7	Power input

#### $\mathbf{A}$

#### Caution

- The Ethernet port arrester applies only to Ethernet ports with an RJ45 connector.
- The Ethernet port arrester is not delivered with the equipment. Please purchase it based on actual requirements. The user manual for Ethernet port arresters contains technical parameters and maintenance and installation instructions. Carefully read this manual during installation.

Pay attention to the following situations during the actual installation to avoid influencing the performance of an Ethernet port arrester:

- The arrester is incorrectly connected to the cables. Connect the external Ethernet cable to the IN end and connect the Ethernet port of the equipment to the OUT end.
- The arrester is incorrectly grounded. The grounding cable of the arrester should be as short as possible to
  ensure that it is in good contact with the grounding lug of the equipment. Use a multimeter to confirm the
  contact condition after grounding.

Not all Ethernet ports are installed with arresters. If more than one Ethernet port on the switch is connected
to the peer equipment, arresters need to be installed on all the ports for surge protection.

#### 6.4 Cabling Recommendations

When the switch is installed in a standard 19-inch rack, cables are routed upward or downward along the sides of the cable management bracket according to the actual situation in the equipment room. All adapted connectors should be placed at the bottom of the rack in an orderly manner instead of outside the rack that is easy to touch. Power cords are routed beside the rack. Top cabling or bottom cabling is adopted according to the actual situation in the equipment room, such as the positions of the DC power distribution box, AC socket, or lightning protection box.

#### 6.4.1 Requirement for the Minimum Bend Radius of Cables

- The bend radius of a fixed power cord, Ethernet cable, or flat cable should be over five times greater than their respective external diameters. The bend radius of these cables that are often bent or plugged should be over seven times greater than their respective external diameters.
- The bend radius of a fixed common coaxial cable should be over seven times greater than its external diameter. The bend radius of these cables that are often bent or plugged should be over 10 times greater than their respective external diameters.
- The minimum bend radius of a high-speed cable, such as an SFP+ cable, should be over five times greater
  than its external diameter. The bend radius of these cables that are often bent or plugged should be over 10
  times greater than their respective external diameters.

#### 6.4.2 Requirement for the Minimum Bend Radius of Optical Cables

- The diameter of the optical cable tray should be over 25 times greater than that of the optical cable.
- When an optical cable is moved, the bend radius of the optical cable should be over 20 times greater than
  the diameter of the optical cable.
- During cabling of an optical cable, its bend radius should be over 10 times greater than its diameter.

#### 6.4.3 Precautions for Cable Binding

- Before cables are bundled, mark labels and stick the labels to cables wherever appropriate.
- Cables should be neatly and properly bundled in the rack without twisting or bending, as shown in <u>Figure 6-6</u>.

Figure 6-6 Bundling Cables (1)





Table 6-11 Cable Bundling

No.	Description
1	Cables should not be twisted after being bundled in the rack.
2	Cables should not be bent after being bundled in the rack.
3	Cables should be neatly and properly bundled in the rack.


- Cables of different types (such as power cords, signal cables, and grounding cables) should be separated in cabling and bundling. Mixed bundling is disallowed. When they are close to each other, you are advised to adopt crossover cabling. In the case of parallel cabling, maintain a minimum distance of 30 mm (1.18 in.) between power cords and signal cables.
- The cable management brackets and cabling troughs inside and outside the rack should be smooth without sharp corners.
- The metal holes traversed by cables should have a smooth and fully rounded surface or an insulated lining.
- Use cable ties to bundle up cables properly. Please do not connect two or more cable ties to bundle up cables.
- After bundling up cables with cable ties, cut off the remaining part. The cut should be smooth and trim without sharp corners, as shown in <u>Figure 6-7</u>.

Figure 6-7 Bundling Cables (2)




When cables need to be bent, bundle them first but do not tie cables within the bend. Otherwise, stress may
be generated on the cables and cause the wires inside to break, as shown in <u>Figure 6-8</u>.

Figure 6-8 Binding Cables (3)



- Cables not to be assembled or the remaining parts of cables should be folded and placed in a proper position
  of the rack or cable trough. The proper position refers to a position that does not affect the equipment running
  or damage the equipment or cables.
- Do not bind power cords to the guide rails of moving parts.
- The power cords connecting moving parts such as door grounding cables should be reserved with some
  excess after being assembled. This can avoid tension or stress on power cords. After the moving part is
  installed, the remaining cable part should not touch heat sources, sharp corners, or sharp edges. If heat
  sources must be touched, high-temperature cables should be used.
- When using screw threads to secure a cable lug, ensure that the bolt or screw is properly tightened and take
  measures to prevent it from loosening, as shown in <u>Figure 6-9</u>.

Figure 6-9 Fastening Cable Lugs



①Flat washer

③Spring washer

②Nut

4) Flat washer

- Hard power cords should be fastened in the terminal connection area to prevent stress on terminal connection and cable.
- Do not use tapping screws to secure cable lugs.
- Power cords of the same type and in the same cabling direction should be bundled up into cable bunches, with cables in cable bunches clean and straight.
- Bundle up cables by using cable ties according to the following table.

Cable Bunch Diameter	Bundling Spacing
10 mm (0.39 in.)	80–150 mm (3.15–5.91 in.)
10–30 mm (0.39–1.18 in.)	150–200 (5.91–7.87 in.)
30 mm (1.18 in.)	200–300 (7.87–11.81 in.)

- Do not tie cables or bundles in a knot.
- For wiring terminal blocks (such as circuit breakers) with cord end terminals, the metal part of the cord end terminal should not be exposed outside the terminal block during assembly.

#### 6.5 Site Selection

• The equipment room should be at least 5 km (3.11 miles) away from heavy pollution sources, such as smelters, coal mines, and thermal power plants. The equipment room should be at least 3.7 km (2.30 miles) away from medium pollution sources, such as the chemical factory, rubber factory, and electroplating factory. The equipment room should be at least 2 km (1.24 miles) away from light pollution sources, such as the food factory and leather plant. If the pollution source is unavoidable, the equipment room should be located on the windward side of the pollution source perennially with advanced protection.

- The equipment room should be at least 3.7 km (2.30 miles) away from the sea or salt lake. Otherwise, the equipment room must be sealed, with an air conditioner installed for temperature control. Saline soil cannot be used for construction. Otherwise, you should select equipment with advanced protection against severe environments.
- Do not build the equipment room in the proximity of livestock farms. Otherwise, the equipment room should be located on the windward side of the pollution source perennially. The previous livestock house or fertilizer warehouse cannot be used as the equipment room.
- The equipment room should be firm enough to withstand severe weather conditions such as windstorms and heavy rain as well as away from dust. If the dust is unavoidable, keep the door and window away from the pollution source.
- The equipment falls into Class A. Therefore, the equipment room should be located away from the residential area. Otherwise, the equipment room should meet construction specifications to avoid noise and radio interference.
- Make sure the air vent of the equipment room is away from the sewage pipe, septic tank, and sewage treatment tank. Keep the equipment room under positive pressure to prevent corrosive gas from entering the equipment room to corrode components and circuit boards.
- Keep the equipment room away from industrial boilers and heating boilers.
- The equipment room should be on the second floor or higher. Otherwise, the equipment room floor should be 600 mm (23.62 in.) higher than the highest flood level ever recorded.
- Make sure no cracks or holes exist in the wall and floor. If there are cable entries in the wall or window, take
  proper sealing measures. Ensure that the wall is flat, wear-resistant, and dust-free, meeting standards for
  flame resistance, soundproofing, heat absorption, dust reduction, and electromagnetic shielding.
- Keep the door and the window closed to make the equipment room sealed.
- You are advised to use the steel door for soundproofing.
- Do not use sulfur-containing materials.
- Keep the air conditioner from blowing wind straight toward the equipment or blowing water drops from the window or air vent toward the equipment.

### 6.6 Cleaning the Optical Cable Connector and End Face

To ensure that a fiber jumper is properly connected to a fiber-optic coupler, clean the end faces, which directly affects the communication quality of the optical network. In routine optical network construction, the end faces of fibers are prone to be contaminated by non-standard operation or other causes. If a large amount of dust, oil, and other contaminants are attached to the end faces and are not detected or cleaned, the connection of the fibers will lead to an increase in optical signal attenuation, causing an optical network failure, and even the breakdown of the entire optical signal system. The following describes common methods for cleaning optical cable connectors and end faces.

• Use a fiber cleaning pen.

The fiber cleaning pen, also known as the one-click fiber cleaner, is made of ESD-resin, dust-free cleaning fiber, and cleaning agent, which can effectively prevent secondary dust pollution on the product. It comes with two endface cleaning pens of 1.25 mm (0.05 in.) and 2.5 mm (0.1 in.), which can meet routine cleaning requirements for SC, FC, and LC fiber connectors. Select a fiber cleaning pen based on the port to be

cleaned. Gently insert the fiber cleaning pen into the port. Do not exert excessive force to avoid damage to the fiber connector. Slightly press the pen inward. When you hear a click, the end face is cleaned. You can repeat the operation two or three times to ensure a satisfactory cleaning result. Then, remove the fiber cleaning pen. The cleaning process is complete.

- Use a fiber cleaning box or lint-free cloth.
  - The fiber cleaning box is made of high-density textile fibers. It does not require alcohol during use, generates no static electricity, does not shed lint, and is convenient and efficient to use. It applies to SC, FC, and LC fiber connectors.
  - o Hold the fiber cleaning box with one hand, press its switch to expose the cleaning tape, and gently wipe the end face of a fiber connector with the cleaning tape. Be careful not to apply too much force to avoid damaging the connector. This will effectively remove the contaminants attached to the end face.

## **Contents**

1 Change Description	1
1.1 ReyeeOS 2.341	1
1.1.1 Hardware Change	1
1.1.2 Software Feature Change	1
2 Login	2
2.1 Configuration Environment Requirements	2
2.2 Logging in to the Web Interface	2
2.2.1 Connecting to the Device	2
2.2.2 Logging in to the Web Interface	2
2.2.3 Layout Configuration	4
2.3 Quick Setup	4
2.3.1 Configuration Preparations	4
2.3.2 Procedure	5
2.3.3 Procedure for Configuring VCS	8
2.4 Work Mode	11
2.5 Switching the Work Mode	11
3 Network-Wide Management	13
3.1 Viewing the Network Information	13
3.2 Adding Network Devices	15
3.2.1 Wired Connection	15
3.2.2 AP Mesh	16
3.3 Configuring Network Planning	25
3.3 Configuring Network Planning      3.3.1 Configuring Wired VLAN	

3.3.2 Configuring Wi-Fi VLAN	27
3.4 Network-wide Wireless Management	29
3.5 Devices Management	30
3.6 Online Client Management	32
3.6.1 Configuring Client IP Binding	33
3.6.2 Configuring Client Access Control	34
3.6.3 Blocking Clients	35
3.6.4 Configuring Client Rate Limiting	36
3.7 Firewall Management	37
3.7.1 Viewing Firewall Information	37
3.7.2 Configuring Firewall Port	38
3.8 Alerts	39
4 One-Device Information	41
4.1 Basic information about the One-Device	41
4.1.1 Setting the device name	41
4.1.2 Switching the Work Mode	41
4.1.3 Setting MGMT IP	42
4.2 Port Info	42
5 VLAN	44
5.1 VLAN Overview	44
5.2 Configuring a VLAN	44
5.2.1 Adding a VLAN	44
5.2.2 VLAN Description Modifying	45
5.2.3 Deleting a VLAN	46

	5.3 Configuring Port VLAN47	,
	5.3.1 Overview47	,
	5.3.2 Procedure48	}
	5.4 Batch Switch Configuration49	)
	5.4.1 Overview49	)
	5.4.2 Procedure49	)
	5.4.3 Verifying Configuration50	)
6	Monitor52	2
	6.1 Port Flow	2
	6.2 Clients Management	2
	6.2.1 Overview	2
	6.2.2 Displaying the MAC Address Table53	3
	6.2.3 Configuring Static MAC Binding53	3
	6.2.4 Displaying Dynamic MAC Address55	5
	6.2.5 Configuring MAC Address Filtering55	5
	6.2.6 Configuring MAC Address Aging Time56	;
	6.2.7 Displaying ARP Information57	7
7	Ports58	3
	7.1 Overview	}
	7.2 Port Configuration59	)
	7.2.1 Basic Settings59	)
	7.2.2 Physical Settings61	
	7.3 Aggregate Interfaces63	3
	7.3.1 Aggregate Interface Overview63	3

7.3.2 Overview	63
7.3.3 Aggregate Interface Configuration	65
7.3.4 Configuring a Load Balancing Mode	66
7.3.5 Configuring LACP Settings	67
7.4 Port Mirroring	69
7.4.1 Overview	69
7.4.2 Procedure	69
7.5 Rate Limiting	71
7.5.1 Rate Limiting Configuration	71
7.5.2 Changing Rate Limits of a Single Port	72
7.5.3 Deleting Rate Limiting	72
7.6 PoE Configuration	73
7.6.1 PoE Global Settings	74
7.6.2 Power Supply Configuration of Ports	75
7.6.3 Displaying Global PoE Information	77
7.6.4 Displaying the Port PoE Information	77
7.7 MGMT IP Configuration	79
7.7.1 Configuring the Management IPv4 Address	79
7.7.2 Configuring the Management IPv6 Address	79
8 Layer 2 Multicast	81
8.1 Multicast Overview	81
8.2 Multicast Global Settings	81
8.3 IGMP Snooping	82
8.3.1 Overview	82

	8.3.2 Enabling Global IGMP Snooping	82
	8.3.3 Configuring Protocol Packet Processing Parameters	83
	8.4 Configuring MVR	85
	8.4.1 Overview	85
	8.4.2 Configuring Global MVR Parameters	85
	8.4.3 Configuring the MVR Ports	86
	8.5 Configuring Multicast Group	87
	8.6 Configuring a Port Filter	90
	8.6.1 Configuring Profile	90
	8.6.2 Configuring a Range of Multicast Groups for a Profile	91
	8.7 Setting an IGMP Querier	93
	8.7.1 Overview	93
	8.7.2 Procedure	93
9	Layer 3 Multicast	95
	9.1 Overview	95
	9.2 Multicast Routing Table	95
	9.3 Configuring PIM	96
	9.3.1 Overview	96
	9.3.2 Enabling PIM	96
	9.3.3 Viewing PIM Neighbor Table	97
	9.4 Configuring RP	98
	9.4.1 Overview	98
	9.4.2 Configuring a Static RP	98
	9.4.3 Configuring a Candidate RP	99

	9.5 Configuring BSR	100
	9.5.1 Overview	100
	9.5.2 Configuring BSR	100
	9.5.3 Viewing BSR Routing Info	101
	9.6 Configuring IGMP	101
	9.6.1 Overview	101
	9.6.2 Enabling IGMP	101
	9.6.3 Viewing IGMP Multicast Group	102
1 C	) Layer 3 Management	104
	10.1 Setting a Layer 3 Interface	104
	10.2 Configuring the IPv6 Address for the Layer 3 Interface	106
	10.3 Configuring the DHCP Service	109
	10.3.1 Enable DHCP Services	109
	10.3.2 Viewing the DHCP Client	111
	10.3.3 Configuring Static IP Addresses Allocation	111
	10.3.4 Configuring the DHCP Server Options	112
	10.4 Configuring the DHCPv6 Service	113
	10.4.1 Configuring the DHCPv6 Server	113
	10.4.2 Viewing DHCPv6 Clients	114
	10.4.3 Configuring the Static DHCPv6 Address	115
	10.5 Configuring the IPv6 Neighbor List	116
	10.6 Configuring a Static ARP Entry	117
11	Configuring Routes	119
	11.1 Configuring Static Routes	119

11.2	Configuring the IPv6 Static Route	.121
11.3	Configuring RIP	.122
	11.3.1 Configuring RIP Basic Functions	.122
	11.3.2 Configuring the RIP Port	.123
	11.3.3 Configuring the RIP Global Configuration	.124
	11.3.4 Configuring the RIP Route Redistribution List	.125
	11.3.5 Configuring the Passive Interface	.126
	11.3.6 Configuring the Neighbor Route	.127
11.4	Configuring RIPng	.127
	11.4.1 Configuring RIPng Basic Functions	.127
	11.4.2 Configuring the RIPng Port	.129
	11.4.3 Configuring the RIPng Global Configuration	.129
	11.4.4 Configuring the RIPng Route Redistribution List	.130
	11.4.5 Configuring the RIPng Passive Interface	.131
	11.4.6 Configuring the RIPng Aggregate Route	.132
11.5	OSPFv2	.132
	11.5.1 Configuring OSPFv2 Basic Parameters	.133
	11.5.2 Adding an OSPFv2 Interface	.138
	11.5.3 Redistributing OSPFv2 Instance Routes	.139
	11.5.4 Managing OSPFv2 Neighbors	.140
	11.5.5 Viewing OSPFv2 Neighbor Information	.140
11.6	OSPFv3	.141
	11.6.1 Configuring OSPFv3 Basic Parameters	.141
	11.6.2 Adding an OSPFv3 Interface	147

	11.6.3 Viewing OSPFv3 Neighbor Information	148
	11.7 Routing Table Info	148
	11.7.1 IPv4 Route Info	149
	11.7.2 IPv6 Route Info	149
12	Viewing Optical Transceiver Info	150
13	Security	151
	13.1 DHCP Snooping	151
	13.1.1 Overview	151
	13.1.2 Standalone Device Configuration	151
	13.1.3 Batch Configuring Network Switches	151
	13.2 Storm Control	153
	13.2.1 Overview	153
	13.2.2 Procedure	153
	13.3 ACL	154
	13.3.1 Overview	154
	13.3.2 Creating ACL Rules	154
	13.3.3 Applying ACL Rules	156
	13.4 Port Protection	157
	13.5 IP-MAC Binding	158
	13.5.1 Overview	158
	13.5.2 Procedure	158
	13.6 IP Source Guard	160
	13.6.1 Overview	160
	13.6.2 Enabling Port IP Source Guard	160

1	13.6.3 Configuring Exceptional VLAN Addresses	161
1	13.6.4 Viewing Binding List	162
13.7 C	Configure 802.1X authentication	163
1	13.7.1 Function Introduction	163
1	13.7.2 Configuration 802.1X	164
1	13.7.3 View the list of wired authentication users	170
13.8 A	Inti-ARP Spoofing	171
1	13.8.1 Overview	171
1	13.8.2 Procedure	171
14 Advan	ced Configuration	173
14.1 S	STP	173
1	14.1.1 STP Global Settings	173
1	14.1.2 MSTP Settings	177
14.2 L	LDP	179
1	14.2.1 Overview	179
1	14.2.2 LLDP Global Settings	179
1	14.2.3 Applying LLDP to a Port	181
1	14.2.4 Displaying LLDP information	182
14.3 F	RLDP	183
1	14.3.1 Overview	183
1	14.3.2 Standalone Device Configuration	183
1	14.3.3 Batch Configuring Network Switches	185
14.4 E	RPS	187
1	14.4.1 Overview	187

14.4.2 Control VLAN and Data VLAN	187
14.4.3 Basic Model of an Ethernet Ring	188
14.4.4 RPL and Nodes	190
14.4.5 ERPS Packet	191
14.4.6 ERPS Timer	191
14.4.7 Ring Protection	192
14.4.8 Protocols and Standards	192
14.4.9 Configuring ERPS	192
14.4.10 ERPS Typical Configuration Examples	196
14.5 QoS	201
14.5.1 Overview	201
14.5.2 Principles	201
14.5.3 Configuring QoS	205
14.6 Configuring Smart Hot Standby	210
14.6.1 Configuring Hot Standby	211
14.6.2 Configuring DAD Interfaces	211
14.6.3 Active/Standby Switchover	212
14.7 Voice VLAN	212
14.7.1 Overview	212
14.7.2 Voice VLAN Global Configuration	212
14.7.3 Configuring a Voice VLAN OUI	213
14.7.4 Configuring the Voice VLAN Function on a Port	214
14.8 Configuring the Local DNS	217
15 Diagnostics	218

	15.1 Info Center	218
	15.1.1 Port Info	218
	15.1.2 VLAN Info	219
	15.1.3 Routing Info	219
	15.1.4 DHCP Clients	220
	15.1.5 ARP List	220
	15.1.6 MAC Address	221
	15.1.7 DHCP Snooping	221
	15.1.8 IP-MAC Binding	222
	15.1.9 IP Source Guard	222
	15.1.10 PoE	223
	15.1.11 CPP Info	223
	15.2 Network Tools	224
	15.2.1 Ping	224
	15.2.2 Traceroute	224
	15.2.3 DNS Lookup	225
	15.3 Fault Collection	225
	15.4 Cable Diagnostics	226
	15.5 Alerts	226
16	System Configuration	229
	16.1 System Logs	229
	16.1.1 Viewing logs	229
	16.1.2 Setting Logs	231
	16.2 Setting the System Time	235

	Setting the Web Login Password	230
16.4	Setting the Session Timeout Duration	237
16.5	Configuration Backup and Import	237
16.6	Reset	238
	16.6.1 Resetting the Device	238
	16.6.2 Resetting the Devices in the Network	238
16.7	Configuring SNMP	239
	16.7.1 Overview	239
	16.7.2 Global Configuration	239
	16.7.3 View/Group/Community/Client Access Control	241
	16.7.4 SNMP Service Typical Configuration Examples	248
	16.7.5 Trap service configuration	253
	16.7.6 Typical configuration examples of the trap service	257
16.8	Upgrade	259
	16.8.1 Online Upgrade	260
	16.8.1 Online Upgrade	
16.9		260
16.9	16.8.2 Local Upgrade	260 261
16.9	16.8.2 Local Upgrade	260 261
16.9	16.8.2 Local Upgrade  Rebooting the Device	260 261 261
	16.8.2 Local Upgrade  Rebooting the Device	260 261 261 261
16.1	16.8.2 Local Upgrade  Rebooting the Device	260 261 261 261 261
16.1	16.8.2 Local Upgrade	260 261 261 261 262

16.11.3 Unb	inding Cloud Service	e264
-------------	----------------------	------

Configuration Guide Change Description

## 1 Change Description

This chapter describes the major changes in software and hardware of different versions and related documentation. For details about hardware changes, see the release notes published with software versions.

#### 1.1 ReyeeOS 2.341

#### 1.1.1 Hardware Change

This baseline version has no hardware change. The following table lists the applicable hardware models of this version.

Model	Hardware Version
RG-NBS3100-48GT4SFP-P-V2	1.0x
RG-NBS3200-24GT4XS-P-V2	1.0x
RG-NBS3200-48GT4XS-P-V2	1.0x
RG-NBS5200-24GT4XS-P-V2	1.0x

#### 1.1.2 Software Feature Change

This baseline version has no software feature change.

# **2** Login

#### 2.1 Configuration Environment Requirements

 Google Chrome, Internet Explorer 9.0, 10.0, and 11.0, and some Chromium/Internet Explorer kernel-based browsers (such as 360 Extreme Explorer) are supported. Exceptions such as garble characters or format error may occur if an unsupported browser is used.

• 1024 x 768 or a higher resolution is recommended. If other resolutions are used, the page fonts and formats may not be aligned, the GUI is less artistic, or other exceptions may occur.

#### 2.2 Logging in to the Web Interface

#### 2.2.1 Connecting to the Device

Use a network cable to connect the switch port to the network port of the PC, and configure an IP address for the PC that is on the same network segment as the default IP of the device to ensure that the PC can ping through the switch. For example, set the IP address of the PC to 10.44.77.100.

Table 2-1 Default settings

Feature	Default Value
Device IP Address	10.44.77.200
Password	A username is not required when you log in for the first time. The default password is admin.


#### 2.2.2 Logging in to the Web Interface

(1) Enter the IP address (10.44.77.200 by default) of the device in the address bar of the browser to open the login page.



#### Note

- If the static IP address of the device is changed, or the device dynamically obtains a new IP address, the new IP address can be used to access the web management system of the device as long as the PC and the device are on the same LAN, and their IP addresses are in the same network segment.
- The login page varies with products. The actual login page prevails.
- (2) Enter the password and click Log In to open the homepage of the web management system.



You can use the default password admin to log in to the device for the first time. For security purposes, you are advised to change the default password as soon as possible after logging in, and to regularly update your password thereafter.

If you forget the Device IP address or password, hold down the Reset button on the device panel for more than 5s when the device is connected to the power supply to restore factory settings. After restoration, you can use the default IP address and password to log in.

#### Caution

- Restoring factory settings will delete all configurations of the device. Therefore, exercise caution when performing this operation.
- The method for restoring factory settings varies with the device model. For details, see the installation guide of the device.

#### 2.2.3 Layout Configuration




Table 2-2 Layout Configuration

No.	Description
1	Navigation of frequently used device functions, including Network, Gateway, and Device & System related functionalities.
2	Quick view of device alarms, change eWeb page language, and exit eWeb.
3	Device information and device restart button.
4	Device function configuration and display area. Click <b>Monitor</b> to display the interface traffic and PoE power usage of the device (only PoE switches with model names containing –P, -LP, -HP, and -UP support this function). Click <b>Config</b> to view the device's configuration and operational status.
5	The navigation bar.
6	Bulk settings can be applied to commonly used functions of all wired and wireless Reyee products within the self-organizing network.
7	It allows for the configuration of all functions of the local device, as well as rapid setup of the Gateway.

## 2.3 Quick Setup

#### 2.3.1 Configuration Preparations


Connect the device to the power supply, and connect the device port to an uplink device with a network cable.

#### 2.3.2 Procedure

#### 1. Change Web Interface Language

Click **English** in the top right corner of the Web interface.

Select the desired language from the dropdown menu to change the language of the Web interface.




#### 2. Adding Device to Network

By default, users can perform batch settings and centralized management of all devices in the network. Therefore, before starting configuration, you need to check and confirm the number of online devices and network status in the network.



Under normal circumstances, when multiple new devices are powered on and connected, they will be automatically interconnected into a network, and the user only needs to confirm that the number of devices is correct.

If there are other devices in the network that are not added to the current network, you can manually add them by clicking [Workspace/Quick Setup/Add to My Network] within the Network-wide section and entering the management password of each device. This will incorporate the respective devices into the appropriate network, allowing you to proceed with the network-wide configuration.



#### 3. Creating a Web Project


(1) Click **Start Setup** to configure the Internet connection type.




#### Note

Parameters displayed on the **Network Settings** page vary according to device types on the network. The following parameters are displayed when the network contains gateways, switches, and APs.


- Internet: Configure the Internet connection type according to requirements of the local Internet Service Provider (ISP).
  - o DHCP: The access point detects whether it can obtain an IP address via DHCP by default. If the access point connects to the Internet successfully, you can click Next without entering an account.
  - o PPPoE: Click PPPoE, and enter the username, password, and service name. Click Next.
  - o Static IP: Enter the IP address, subnet mask, gateway, and DNS server, and click Next.
- Wi-Fi Settings: Select the Wi-Fi configuration mode. This configuration option is unavailable for a new project.
  - Use Old Settings: Use the Wi-Fi settings of an existing project.
  - Use New Settings: Configure the Wi-Fi network using new settings.
- **SSID** and **Wi-Fi Password**: The device has no Wi-Fi password by default, indicating that the Wi-Fi network is an open network. You are advised to configure a complex password to enhance the network security.
- Country/Region: The Wi-Fi channel may vary from country to country. To ensure that a client searches for a Wi-Fi network successfully, you are advised to select the actual country or region.
- **Time Zone**: Set the system time. The network time server is enabled by default to provide the time service. You are advised to select the actual time zone.



- (2) Click Next. On the page that is displayed, set the project name and management password.
- **Project Name**: Identify the network project where the device is located.
- Management Password: The password is used for logging in to the management page.



(3) Click Finish. The device will deliver the initialization and check the network connectivity.



Redirecting...

After completing the quick setup, the new device can access the Internet. You can click Homepage in the upper right corner of the page to access the web interface, or bind the device with a Ruijie Cloud account for remote management. Follow the instruction to log in to Ruijie Cloud for further configuration.



If your device is not connected to the Internet, click Service is unavailable. in the displayed Internet **connection failed.** dialog box to exit the configuration wizard.

Please log in again with the new password if you change the management password.

#### 2.3.3 Procedure for Configuring VCS

VCS improves data forwarding reliability when an RG-NBS series device serves as the core switch. Two switches can be stacked, and services are automatically switched to the standby switch when the active switch is faulty, ensuring uninterrupted data forwarding in the case of a single failure.




Supported Products

Only RG-NBS5200 series switches support the feature.

#### Caution

- Only two switches can form a VCS group.
- VCS is only supported on switches of the same series.
- Switches of the same series but different models (for example, RG-NBS5200-24GT4XS and RG-NBS5200-48GT4XS) can be configured to work in hot standby mode. If the two switches have different capacities, the smaller capacity prevails after the hot standby configuration.
- In hot backup mode, only the MGMT port on the active device or primary supervisor module is available.

Stacking: Physically connect multiple switches with stack cables, allowing them to operate as a single logical unit for data forwarding.




(1) Connect two switches with cables to form a VCS group.




#### Caution

Only one link is required between devices before VCS is configured, for example, connect Port 25 of Device 1 to Port 25 of Device 2, as shown in Figure 2-1. Otherwise, a loop may occur.


Figure 2-1 Connecting Switches Before Configuring VCS




(2) Enter the default IP address 10.44.77.200 in the address bar of your browser to access the web interface of an RG-NBS switch. Click **Configure**.




(3) Click Start Setup.




(4) Connect the 10GE interfaces of the two switches using a cable (for example, connect Interface 25 of Device 1 to Interface 25 of Device 2, as shown in <u>Figure 2-1</u>). Then, choose **Dual-Device Config**, and click **Next**.



- (5) Select the standby switch.
- (6) Select another VCS interface (Interface 26 in the following figure), or multiple VCS interfaces. You are advised to select two adjacent interfaces on a switch. Up to four VCS interfaces on a switch can be selected. These VCS interfaces must be 10GE interfaces. By default, the active switch has a priority of 200, while the standby switch has a priority of 100. If the priority is changed, a switch with a higher priority will become the active switch.



(7) Click **Next**. Use a 10GE cable to connect the VCS interfaces that you have selected. (The following figure shows an example of connecting Interface 26 of Device 1 to Interface 26 of Device 2.)



(8) After the cables are connected, proceed as prompted, and wait for the device to reboot successfully.



#### Caution

To delete the VCS configuration, ensure that the cable connecting the VCS interfaces is disconnected. Failure to do so may result in a loop that can cause network disconnection.

#### 2.4 Work Mode

The device supports two work modes: **Standalone** and **Self-Organizing Network**. It works in **Self-Organizing Network** mode by default. The system presents different menu items based on the work mode. To modify the work mode, see <u>2.5</u> Switching the Work Mode.

**Self-Organizing Network**: After the self-organizing network discovery function is enabled, the device can be discovered in the network and discover other devices in the network. Devices network with each other based on the device status and synchronize global configuration. You can log in to the Web management page of the device to check management information about all devices in the network. After self-organizing network discovery is enabled, users can maintain and manage the current network more efficiently. You are advised to keep this function enabled.


When the device is in self-organizing network mode, the Web page has two configuration modes: the network mode and the local device mode. For more information, see <u>2.5</u> Switching the Work Mode.

**Standalone mode:** If the self-organizing network discovery function is disabled, the device will not be discovered in the network. After logging in to the Web page, you can configure and manage only the currently logged in device. If only one device is configured or global configuration does not need to be synchronized to the device, you can disable the self-organizing network discovery function.

### 2.5 Switching the Work Mode


In standalone mode, you can configure and manage only the current logged in device without self-organizing network function. As shown in

Figure 2-2 The Web Interface in Standalone Mode



In Self-organizing mode, you can batch set the commonly used functions of all wired and wireless Reyee products within the self-organizing network, including the currently logged-in device. As shown in

Figure 2-3 The Web Interface in Self-Organizing Mode



# 3 Network-Wide Management


Choose Network-Wide > Workspace > Physical Topology.

The **Overview** webpage displays the current network topology, real-time uplink and downlink flow, networking status, and the number of users. The quick access to network and device settings is also provided on the **Overview** webpage. Users can monitor, configure and manage the network status on the current page.




# 3.1 Viewing the Network Information


You can view the online device, port ID, device SN as well as the real-time uplink and downlink flow in the network topology.




Click the egress gateway in the topology to view real-time traffic information of the device.



Click the device in the topology to view the operating status and configuration of the device and configure
the device functions. The hostname is set to the product model by default. You can click to modify the
hostname.




 The update time of the topology is displayed at the bottom left corner. Click Refresh to update the topology to the latest status. Please wait for a few minutes for the update.




# 3.2 Adding Network Devices

## 3.2.1 Wired Connection


(1) If a new device is connected to the device in the network through wired connection, a prompt message will pop up, indicating that a device not in SON (Self-Organizing Network) is discovered. The number (in orange) of devices that are not in SON is displayed under the **Devices** at the top left corner of the page. Click **Handle** to add the device to the current network.



(2) Go to the Network List page, click Other Network to select the target device and click Add to My Network.



(3) If the target device is not configured yet, you can add the device directly without a password. If the device is configured with a password, please enter the management password of the device. If the password is incorrect, the device cannot be added to the network.



## 3.2.2 AP Mesh



## Note

Only Reyee AP devices that support AP Mesh function can complete networking through AP Mesh.

#### 1. Overview

After being powered on and enabled with the AP Mesh feature, a Mesh-capable new AP can be paired with other Mesh-capable wireless devices on the target network through multiple ways. Then the AP will be synchronized its Wi-Fi configuration with other devices automatically. Mesh networking addresses pain points such as complex wireless networking and cabling. A new AP can be connected to any uplink wireless device among AP, EG router, and EGW router in the following ways:


Button-based pairing: Short press the Mesh button on the EGW router on the target network to implement

fast pairing of the AP with the EGW router.

- Search-based pairing: Log in to the web interface of a device on the target network. Search and add APs to be paired.
- Wired pairing: Connect the new AP to a wireless device on the target network using an Ethernet cable. The new AP will go online on the target network.

After pairing finishes, the new AP obtains the wireless backhaul information from network-wide neighboring APs. Install the new AP as planned, and it will connect to the optimal neighboring AP.

#### 2. Configuration Steps



#### 3. Configuration Steps for Button-based Pairing


#### $\mathbf{A}$

#### Caution

- Uplink device is an EGW router.
- The new AP must be in factory status.
- It can be scanned only when the live network is enabled with Mesh.
- Place the new AP no more than 2 meters away from the uplink device to ensure that the new AP can
  receive the Wi-Fi signal from the uplink device. The new AP may fail to be scanned due to the long
  distance or obstacles between it and the uplink device.
- (1) Power on the new AP and place it near the EGW router on the target network.
- (2) Press and hold the Mesh button on the EGW router for no more than two seconds to start pairing.


  The pairing process takes about one minute.

(3) Check the topology on the **Physical Topology** page to make sure that the new AP has connected to the uplink device in wireless mode.



- (4) Power off the new AP and install it as planned.
- (5) Log in to the web interface of a device on the target network. In **Network-Wide** mode, choose **Devices > AP**.


Make sure that the new AP is online and the corresponding entry contains icon in the **Relay Information** column. The icon indicates that wireless backhaul is performed through the 5 GHz radio.



(6) Click View Details following the



icon to obtain information about the uplink device and RSSI.




## 4. Configuration Steps for Search-based Pairing

#### Caution


- Uplink device is an AP or EGW router.
- The new AP must be in factory status.
- It can be scanned only when the live network is enabled with Mesh.
- Place the new AP no more than 2 meters away from the uplink device to ensure that the new AP can
  receive the Wi-Fi signal from the uplink device. The new AP may fail to be scanned due to the long
  distance or obstacles between it and the uplink device.
- (1) Power on the new AP and place it near the AP or EGW router on the target network.
- (2) Log in to the web interface of a device on the target network. In Network-Wide mode, click +Discover Devices in the upper right corner of the Physical Topology page to scan the APs in other networks not plugged in with Ethernet cables.



(3) On the **AP Mesh** page, click **Scan** to scan devices that are not connected to the network via an Ethernet cable.



(4) Select the APs to be added and click **Add to My Network**. No more than eight APs are allowed at a time. Wait until network merging finishes.




(5) Check the topology on the **Physical Topology** page to make sure that the new AP has connected to the uplink device in wireless mode.



- (6) Power off the new AP and install it as planned.
- (7) Log in to the web interface of a device on the target network. In **Network-Wide** mode, choose **Devices** > **AP**.

  Make sure that the new AP is online and the corresponding entry contains icon in the **Relay**Information column. The icon indicates that wireless backhaul is performed through the 5 GHz radio.



(8) Click **View Details** following the icon to obtain information about the uplink device and RSSI.




#### 5. Configuration Steps for Wired Pairing

#### $\mathbf{A}$


#### Caution

- Uplink device is an AP, EG router, or EGW router.
- The new AP must be in factory status.
- It can be scanned only when the live network is enabled with Mesh.
- (1) Plug one end of the Ethernet cable to the uplink port of the new AP, and the other end to the downlink port of an AP, EG router, or EGW router on the target network. Mesh networking takes one to three minutes. When the system status LED is steady on, it indicates that Mesh networking finishes.
- (2) Log in to the web interface of a device on the target network. In **Network-Wide** mode, choose **Devices** and make sure that the new AP is online.



- (3) Unplug the Ethernet cable, power off the new AP, and install it as planned.
- (4) Log in to the web interface of a device on the target network. In Network-Wide mode, choose Devices > AP.

Make sure that the new AP is online and the corresponding entry contains icon in the **Relay** Information column. The icon indicates that wireless backhaul is performed through the 5 GHz radio.




(5) Click **View Details** following the icon to obtain information about the uplink device and RSSI.




#### 6. Enabling WAN Port

The WAN port works as the wired uplink port of the AP by default. For the AP added to the target network through Mesh pairing, the WAN port is disabled by default. If you want to connect the Mesh AP to other downlink device in wired mode to expand the network, enable this port.

(1) Log in to the web interface of the network project. Choose **Network-Wide > Devices > AP**, and click **Manage** next to a device in the AP list.




(2) Choose Config > Advanced > Enable WAN, toggle on Enable, and click Save.




## 7. Querying Mesh APs and Mesh Details

- (1) Log in to the web interface of a device on the target network.
- (2) Query Mesh APs.
- Method 1: In Network-Wide mode, check the topology on the Physical Topology page. The AP that
  connects to the uplink device in wireless mode is a Mesh AP.



Method 2: In Network-Wide mode, choose Devices > AP. If an entry contains icon in the Relay Information column, the corresponding AP is a Mesh AP.



(3) Query Mesh networking details.

In **Network-Wide** mode, choose **Devices** > **AP**. Select the target AP, and click **View Details** in the **Relay Information** column to obtain the Mesh networking details.



# 3.3 Configuring Network Planning


Choose Network-Wide > Workspace > Network Planning.




# 3.3.1 Configuring Wired VLAN

 $\label{lem:choose Network-Wide > Workspace > Network\ Planning}.$ 


On the Network Planning page, click Add Wired VLAN.




Alternatively, you can select an existing wired VLAN and click **Setup** to edit the VLAN.




(1) Configure the VLAN ID, address pool server, and DHCP pool. The gateway is configured as the address pool server by default to assign IP addresses to clients. If an access switch exists in the network, you can select the access switch as the address pool server. Click **Next** after VLAN parameters are configured.



(2) Select the target switch in the topology and all member ports in the VLAN, and click Next.




(3) Please confirm the delivered configurations and click **Save**. The configurations will take effect after a few minutes.



# 3.3.2 Configuring Wi-Fi VLAN


Choose Network-Wide > Workspace > Network Planning.

On the Network Planning page, click Add Wi-Fi VLAN.




Alternatively, you can select an existing wireless VLAN and click Setup to edit the VLAN.


(1) Configure the SSID, Wi-Fi password and band. Click **Advanced Settings** to expand the advanced settings and set the parameters. Then, click **Next**.



(2) Configure the VLAN ID, address pool server and DHCP pool. The gateway is configured as the address pool server by default to assign IP addresses to clients. If an access switch exists in the network, you can select the access switch as the address pool server. Click **Next** after VLAN parameters are configured.




(3) Please confirm the delivered configurations and click **Save**. The configurations will take effect after a few minutes.



# 3.4 Network-wide Wireless Management

Choose Network-Wide > Workspace > Wireless.




The functions supported by Network-wide Wireless Management depend on the AP devices in the network. Detailed information on the supported functions can be found in the Configuration Guide accompanying RG-RAP devices. For example, if the software version of the AP device is ReyeeOS 2.280, the functions supported by Network-wide Wireless Management can be referenced in the RG-RAP Configuration Guide for ReyeeOS 2.280 version.

# 3.5 Devices Management

View all device information in the current network. Users can configure and manage the entire network of devices simply by logging into one device in the network. The methods to access device management are as follows:

 Method 1: Click the device icon in the top right corner of the Physical Topology to switch to the device list view.




#### Method 2: Choose Network-Wide > Devices

Click <Handle> to add an ungrouped device to the current network.

Click <Manage> to configure a specific device.

Click <Reboot> to restart a specific device.


Click <Select>, check the offline devices, click <Delete Offline>, and the devices can be removed from the list and network topology.



# 3.6 Online Client Management

#### Choose Network-Wide > Clients.

The client list displays wired, wireless, and users not connected on the current network, including the username, connection mode, associated device, IP/MAC address, IP address binding status, rate, and related operations.



- Click Not Bound in the IP/MAC column to bind the client to a static IP address.
- Click a button in the Action column to perform the corresponding operation on the online client.
  - o Wired: Only access control can be configured.
  - o Wireless: Access control, associate, and block can be configured.
- Note

IP binding and access control are supported only in router mode.

Table 3-1 Online Client Management Configuration Parameters

Parameter	Description
Username	Name of the connected client.
SSID and Band	Indicates the access mode of the client, which can be wireless or wired. The SSID and frequency band is displayed when a client is connected wirelessly.
Connected To	Indicates wired or wireless connection, the associated device and SN.
IP/MAC	Indicates the IP address and MAC address of the client.
Rate	Indicates the uplink and downlink rates of the client.
Action	You can click the corresponding button to perform access control, association, and block operations on online clients.
Signal Quality	The Wi-Fi signal strength of the client and the associated channel.  Note: This information is displayed only in the wireless online client list.

Parameter	Description
Negotiated Rate	Negotiation rate between the client and the AP.  Note: This information is displayed only in the wireless online client list.
Online Duration	Online duration of the client.  Note: This information is displayed only in the wireless online client list.
Limit Speed	Indicates the wireless rate limiting of the current client. For details, see 3.6.4  Configuring Client Rate Limiting.  Note: This information is displayed only in the wireless online client list.

# 3.6.1 Configuring Client IP Binding




#### Note

This function is supported only in router mode.

#### Choose Network-Wide > Clients.

IP address binding is a security and access control policy that associates a specific IP address with a specific device or user to achieve identity authentication, access control, monitoring, and accounting.


Single client IP address binding
 Select the client to be bound with an IP address in the list, click Not bound, and click OK in the pop-up box to bind the client to a static IP address.



- Batch IP binding
  - a Click Select.



b Select the clients to be bound, click **Bind IP**, and click **OK** in the pop-up box to bind the selected clients to a static IP address.



Unbind an IP address
 Select the client to be unbound from the list, click **Bound**, and click **OK** in the pop-up box.




# 3.6.2 Configuring Client Access Control



This function is supported only in router mode.

#### Choose Network-Wide > Clients.

Select a client in the list and click **Access Control** in the **Action** column. You will be redirected to the **Add Rule** page, where a MAC-based access control rule is automatically generated. The name and MAC address are automatically generated based on the selected client. After selecting the control type and effective time, click **OK** to create an access control rule for the client.



# 3.6.3 Blocking Clients

Choose Network-Wide > Clients.


An unauthorized client may occupy network bandwidth and pose security risks. You can block specified clients to solve the unauthorized access problem.



Client block is available only for wireless clients.

Block a single client


Select a client to block in the list, click **Block** in the **Action** column, and click **OK** in the pop-up box to block the selected client.



- Batch block clients
  - a Click Select.




b Select the target clients, click **Block**, and click **OK** in the pop-up box to block the selected clients.



Cancel block

Choose Network-Wide > Workspace > Wireless > Blocklist/Allowlist > Global Blocklist/Allowlist.

Select the client to be removed from the blocklist in the wireless blocklist and click **Delete**.



## 3.6.4 Configuring Client Rate Limiting

Choose Network-Wide > Clients > Wireless.

To ensure fair resource allocation, the network administrator can implement wireless rate limiting to prevent some users or devices from occupying a large amount of bandwidth and affecting the network experience of other users.




Rate limiting applies only to wireless clients.

Configure rate limits for clients


Click the **Wireless** tab, click the **LimitSpeed** column in the table, set the uplink rate limit and downlink rate limit, and click **OK**.





#### Cancel rate limits

Click the Wireless tab, click the LimitSpeed column in the table, and click Disable.



# 3.7 Firewall Management


After a firewall is added to the network, you can manage and configure the firewall on the Web management system.

# 3.7.1 Viewing Firewall Information


You can view the basic information and license of the firewall on the Web management system.

Choose Network-Wide > Firewall.

(1) If the password of the firewall is inconsistent with that of the gateway, please enter the management password of the firewall and click **OK**.



(2) The basic information, capacity, and security service license of the firewall are displayed on the Web management system.



Click **Manage Firewall** to go to the Web management interface of the firewall. Configure the security policy and license activation for the firewall. For details, see the Web-based configuration guide of the firewall.

# 3.7.2 Configuring Firewall Port

If the firewall is set to transparent mode, the **Firewall Port Config** page appears. You can select the WAN port connected to the gateway or the LAN port connected to the switch and enable **Security Guard**.



#### 3.8 **Alerts**

When a network exception occurs, the network overview page will display an alert and provide a suggestion. Click an alert in the Alert Center to view the faulty device, problem details, and description. You can troubleshoot the fault based on the suggestion.




The Alert List page displays possible problems on the network environment and device. All types of alarms are followed by default. You can click **Unfollow** in the **Action** column to unfollow this type of alarm.



#### Caution

After unfollowing a specified alert type, you will not discover and process all alerts of this type promptly. Therefore, exercise caution when performing this operation.



#### Are you sure you want to unfollow the alarm and delete it from the alarm list?

- 1. After being unfollowed, an alarm will not appear again. 2. You can click View Unfollowed Alert to re-follow an
- unfollowed alarm.

Cancel

Click View Unfollowed Alert to view the unfollowed alert. You can follow the alert again in the pop-up window.



# View Unfollowed Alert

Power supply is insufficient.

Cancel

 $\times$ 


Configuration Guide One-Device Information

# 4 One-Device Information

# 4.1 Basic information about the One-Device


Choose Local Device > Home > Basic Info.

Basic information includes device model, device name, SN number, software version, management IP, MAC address, networking status, system time, working mode, etc.



## 4.1.1 Setting the device name


Click the device name to modify the device name in order to distinguish between different devices.



# 4.1.2 Switching the Work Mode

Click the current work mode to change the work mode.

Configuration Guide One-Device Information



# 4.1.3 Setting MGMT IP


Click current management IP address to jump to the management IP configuration page. For more information, see <u>7.7 MGMT IP Configuration</u>.



## 4.2 Port Info


Choose Local Device > Home > Port Info.

 The port info page displays the details of all ports currently on the switch. Click Panel View to view the port roles and statuses corresponding to port icons of different colors or shapes.




Move the cursor to the icon of a port (for example, Gi14) on the port panel, and more information about the
port will be displayed, including the port ID, port status, port rate, uplink and downlink traffic, transmission
rate, and optical/electrical attribute of the port.

Configuration Guide One-Device Information



Traffic data is automatically updated every five minutes. You can click Refresh above the port panel to obtain
the latest port traffic and status information simultaneously.



# 5 VLAN

## 5.1 VLAN Overview

A virtual local area network (VLAN) is a logical network created on a physical network. A VLAN has the same properties as a normal physical network except that it is not limited by its physical location. Each VLAN has an independent broadcast domain. Different VLANs are Layer 2-isolated. Layer 2 unicast, broadcast, and multicast frames are forwarded and spread within one VLAN and will not be transmitted to other VLANs.


When a port is defined as a member of a VLAN, all clients connected to the port are a part of the VLAN. A network supports multiple VLANs. VLANs can make Layer 3 communication with each other through Layer 3 devices or Layer 3 interfaces.

VLAN division includes two functions: creating VLANs and setting port VLANs.

# 5.2 Configuring a VLAN


Choose Local Device > VLAN > VLAN List.

The VLAN list contains all the existing VLAN information. You can modify or delete the existing VLAN, or create a new VLAN.




# 5.2.1 Adding a VLAN

Create multiple VLANs: Click Batch Add. In the displayed dialog box, enter VLAN ID range (separate multiple VLAN ID ranges with commas (,)), and click OK. The VLANs added will be displayed in VLAN List.




 Create a VLAN: Click Add. Enter the VLAN ID and description for the VLAN, and click OK. The VLAN added will be displayed in VLAN List.



- Note
- The range of a VLAN ID is from 1 to 4094.
- You can separate multiple VLANs to be added in batches with commas (,), and separate the start and end VLAN IDs of a VLAN range with a hyphen (-).
- If no VLAN description is configured when the VLAN is added, the system automatically creates a VLAN
  description in the specified format, for example, VLAN000XX. The VLAN descriptions of different VLANs
  must be unique.
- If the device supports Layer 3 functions, VLANs, routed ports, and Layer 3 aggregate interfaces share limited hardware resources. If resources are insufficient, a message indicating resource insufficiency for VLAN will be displayed.


# 5.2.2 VLAN Description Modifying

In VLAN List, Click Edit in the last Action column to modify the description information of the specified VLAN.




# 5.2.3 Deleting a VLAN

 Batch delete VLANs: In VLAN List, select the VLAN entries to be deleted and click Delete Selected to delete VLANs in a batch.



Delete a VLAN: In VLAN List, click Delete in the last Action column to delete the specified VLAN.



Note


The default VLAN (VLAN 1), management VLAN, native VLAN, and access VLAN cannot be deleted. For these VLANs, the **Delete** button is unavailable in gray.

# 5.3 Configuring Port VLAN

## 5.3.1 Overview

Choose Local Device > VLAN > Port List.

**Port List** displays the VLAN division of the current port. Create VLANs in **VLAN List** page (see <u>5.2</u> Configuring a VLAN) and then configure the port based on the VLANs.



You can configure the port mode and VLAN members for a port to determine VLANs that are allowed to pass through the port and whether packets to be forwarded by the port carry the tag field.

Table 5-1 Port Modes Description

Port mode	Function
Access port	One access port can belong to only one VLAN and allow only frames from this VLAN to pass through. This VLAN is called an access VLAN.  Access VLAN has attributes of both Native VLAN and Permitted VLAN  The frames sent from the Access port do not carry tags. When the access port receives an
	untagged frame from a peer device, the local device determines that the frame comes from the Access VLAN and adds the access VLAN ID to the frame.
	One trunk port supports one native VLAN and several allowed VLANs. Native VLAN frames forwarded by a trunk port do not carry tags while allowed VLAN frames forwarded by the trunk port carry tags.
Trunk port	A trunk port belongs to all VLANs of the device by default, and can forward frames of all VLANs. You can set the allowed VLAN range to limit VLAN frames that can be forwarded.  Note that the trunk ports on both ends of the link must be configured with the same Native VLAN.
Hybrid port	A hybrid port supports one native VLAN and several allowed VLANs. The allowed VLANs are divided into Tag VLAN and Untagged VLAN. The frames forwarded by the hybrid port from a Tag VLAN carry tags, and the frames forwarded by the hybrid port from an Untagged VLAN do

Port mode	Function
	not carry tags. The frames forwarded by the hybrid port from Native VLAN must not carry tags,
	therefore Native VLAN can only belong to Untagged VLAN List.



#### **Specification**

Whether the hybrid mode function is supported depends on the product version.

#### 5.3.2 Procedure


#### Choose Local Device > VLAN > Port List.

Configure port VLANs in a batch: Click **Batch Edit**, select the port to be configured on the port panel, and select the port mode. If the port mode is Access port, you need to select Access VLAN; if the port mode is Trunk port, you need to select Native VLAN and enter the allowed VLAN ID range; if the port mode is Hybrid port, you need to select Native VLAN and enter the allowed VLAN range and Untagged VLAN range. Click **OK** to complete the batch configuration.

# $\bigcirc$


#### **Specification**

In Hybrid mode, the allowed VLANs include Tag VLAN and Untagged VLAN, and the Untagged VLAN range must include Native VLAN.



Configure one port: In **Port List**, click **Edit** in the last **Action** column of a specified port, configure the port mode and corresponding VLAN, and click **OK**.

Configuration Guide VLAN



# Note

- VLAN ID range is from 1 to 4094, among which VLAN 1 is the default VLAN that cannot be deleted.
- When hardware resources are insufficient, the system displays a VLAN creation failure message.
- Improper configuration of VLANs on a port (especially uplink port) may cause the failure to log in to the web interface. Therefore, exercise caution when configuring VLANs.

# 5.4 Batch Switch Configuration


# 5.4.1 Overview

You can batch create VLANs, configure port attributes, and divide port VLANs for switches on the network.

# 5.4.2 Procedure


Choose Network-Wide > Workspace > Wired > SW Config.

(1) The page displays all switches in the current network. Select the switches to configure, and then select the desired ports in the device port view that appears below. If there are a large number of devices in the current network, select a product model from the drop-down list box to filter the devices. After the desired devices and ports are selected, click **Next**.



Configuration Guide VLAN

(2) Click **Add VLAN** to create a VLAN for the selected devices in a batch. If you want to create multiple VLANs, click **Batch Add** and enter the VLAN ID range, such as 3-5,100. After setting the VLANs, click **Next**.




(3) Configure port attributes for the ports selected in Step 1 in a batch. Select a port type. If you set Type to Access Port, you need to configure VLAN ID. If you set Type to Trunk Port, you need to configure Native VLAN and Permitted VLAN. After setting the port attributes, click Override to deliver the batch configurations to the target devices.



# 5.4.3 Verifying Configuration

View the VLAN and port information of switches to check whether the batch configurations are successfully delivered.

Configuration Guide VLAN



# **Monitor**

# **Port Flow**


Choose Local Device > Monitor > Port Flow.

Display traffic statistics such as the rate of the device port, the number of sent and received packets, and the number of error packets. The rate of the port is updated every five seconds. Other traffic statistics are updated every five minutes.

Select a port and click Clear Selected, or click Clear All to clear statistics such as current port traffic and start statistics collection again.



Aggregate ports can be configured. Traffic of an aggregate interface is the sum of traffic of all member ports.



# **Clients Management**

# 6.2.1 Overview

A MAC address table records mappings of MAC addresses and interfaces to virtual local area networks (VLANs).

A device queries the MAC address table based on the destination MAC address in a received packet. If the device finds an entry that is consistent with the destination MAC Address in the packet, the device forwards the packet through the interface corresponding to the entry in unicast mode. If the device does not find such an entry, it forwards the packet through all interfaces other than the receiving interface in broadcast mode.

MAC address entries are classified into the following types:

Static MAC address entries: Manually configured by the user. Packets whose destination MAC address matches the one in such an entry are forwarded through the correct interface. This type of entries does not age.

 Dynamic MAC address entries: Automatically generated by devices. Packets whose destination MAC address matches the one in such an entry are forwarded through the correct interface. This type of entries ages.

 Filtering MAC address entries: Manually configured by the user. Packets whose source or destination MAC address matches the one in such an entry are discarded. This type of entries does not age.



#### Note


This section describes the management of static, dynamic, and filtering MAC address entries, without involving multicast MAC address entries.

# 6.2.2 Displaying the MAC Address Table

Choose Local Device > Monitor > Clients Management > MAC List.

Displays the MAC address information of the device, including the static MAC address manually set by the user, the filtering MAC address, and the dynamic MAC address automatically learned by the device.

Querying MAC address entries: Support querying MAC address entries based on MAC address, VLAN ID or port. Select the search type, enter the search string, and click **Search**. MAC entries that meet the search criteria are displayed in the list. Support fuzzy search.






### Note

The MAC address entry capacity depends on the product. For example, the MAC address entry capacity of the device shown in the figure above is 16K.

# 6.2.3 Configuring Static MAC Binding

The switch forwards data based on the MAC address table. You can set a static MAC address entry to manually bind the MAC address of a downlink network device with the port of the device. After a static address entry is configured, when the device receives a packet destined to this address from the VLAN, it will forward the packet


to the specified port. For example, when 802.1X authentication is enabled on the port, you can configure static MAC address binding to implement authentication exemption.



## 1. Adding Static MAC Address Entries

Choose Local Device > Monitor > Clients Management > Static MAC.


Click **Add**, enter the MAC address and VLAN ID, select the port for packet forwarding, and click **OK**. After the addition is successful, the MAC address table will update the entry data.



# 2. Deleting Static MAC Address Entries

Choose Local Device > Monitor > Clients Management > Static MAC.


- Batch delete: In MAC List, select the MAC address entries to be deleted and click Delete Selected. In the displayed dialog box, click OK.
- Delete an entry: In MAC List, find the entry to be deleted, click Delete in the last Action column. In the displayed dialog box, click OK.




# 6.2.4 Displaying Dynamic MAC Address

Choose Local Device > Monitor > Clients Management > Dynamic MAC.

After receiving the packet, the device will automatically generate dynamic MAC address entries based on the source MAC address of the packet. The current page displays the dynamic MAC address entries learned by the device. Click **Refresh** to obtain the latest dynamic MAC address entries.




Delete dynamic MAC address: Select the clear type (by MAC address, by VLAN, or by port), enter a string for matching the dynamic MAC address entry, and click **Clear**. The device will clear MAC address entries that meet the conditions.



# 6.2.5 Configuring MAC Address Filtering

To prohibit a user from sending and receiving packets in certain scenarios, you can add the MAC address of the user to a filtering MAC address entry. After the entry is configured, packets whose source or destination MAC address matches the MAC address in the filtering MAC address entry are directly discarded. For example, if a user initiates ARP attacks, the MAC address of the user can be configured as a to-be-filtered address to prevent attacks.



# 1. Adding Filtering MAC Address

Choose Local Device > Monitor > Clients Management > MAC Filter.


Click Add. In the dialog box that appears, enter the MAC address and VLAN ID, and then click OK.



#### 2. MAC Filter

Choose Local Device > Monitor > Clients Management > MAC Filter.

- Batch delete: In MAC List, select the MAC address entries to be deleted and click Delete Selected. In the displayed dialog box, click OK.
- Delete an entry: In MAC List, find the entry to be deleted, click Delete in the last Action column. In the displayed dialog box, click OK.



# 6.2.6 Configuring MAC Address Aging Time


Set the aging time of dynamic MAC address entries learned by the device. Static MAC address entries and filtering MAC address entries do not age.

The device deletes useless dynamic MAC address entries based on the aging time to save entry resources on the device. An overly long aging time may lead to untimely deletion of useless entries, whereas an overly short aging time may lead to deletion of some valid entries and repeated learning of MAC addresses by the device,

which increases the packet broadcast frequency. Therefore, you are advised to configure a proper aging time of dynamic MAC address entries as required to save device resources without affecting network stability.

Choose Local Device > Monitor > Clients Management > Aging Time.

Enter valid aging time and click **Save**. The value range of the aging time is from 10 to 630, in seconds. The value 0 specifies no aging.



# 6.2.7 Displaying ARP Information

Choose Local Device > Monitor > Clients Management > ARP List.

When two IP-based devices need to communicate with each other, the sender must know the IP address and MAC address of the peer. With MAC addresses, an IP-based device can encapsulate link-layer frames and then send data frames to the physical network. The process of obtaining MAC addresses based on IP addresses is called address resolution.


The Address Resolution Protocol (ARP) is used to resolve IP addresses into MAC addresses. ARP can obtain the MAC Address associated with an IP address. ARP stores the mappings between IP addresses and MAC addresses in the ARP cache of the device.

The device learns the IP address and MAC address of the network devices connected to its interfaces and generates the corresponding ARP entries. The **ARP List** page displays ARP entries learned by the device. The ARP list allows you search for specified ARP entries by IP or MAC address. Click **Refresh** to obtain the latest ARP entries.



# Note

For more ARP entry function introduction, see <a href="10.6">10.6</a> Configuring a Static ARP Entry.



# **7** Ports

# 7.1 Overview

Ports are important components for data exchange on network devices. The port management module allows you to configure basic settings for ports, and configure port aggregation, switched port analyzer (SPAN), port rate limiting, management IP address, etc.

Table 7-1 Description of Port Type

Port Type	Note	Remarks
Switch Port	A switch port consists of a single physical port on the device and provides only the Layer 2 switching function. Switch ports are used to manage physical port and their associated Layer 2 protocols.	Described in this section
Layer 2 aggregate interface	An Interface binds multiple physical members to form a logical link. For Layer 2 switching, an aggregate interface is like a high-bandwidth switch port. It can combine the bandwidths of multiple ports to expand link bandwidth. In addition, for frames sent through a Layer 2 aggregate interface, load balancing is performed on member ports of the Layer 2 aggregate interface. If one member link of the aggregate interface fails, the Layer 2 aggregate interface automatically transfers traffic on this link to other available member links, improving connection reliability.	Described in this section
SVI Port	A switch virtual interface (SVI) serves as the management interface of the device, through which the device can be managed. You can also create an SVI as a gateway interface, which is equivalent to the virtual interface of corresponding VLAN and can be used for inter-VLAN routing on Layer 3 devices.	For related configuration, see 10.1 Setting a Layer 3 Interface.
Routed Port	On Layer 3 devices, you can configure a single physical port as a routed port and use it as the gateway interface of Layer 3 switching. Route interfaces do not have Layer 2 switching functions and have no corresponding relationship with VLANs, but only serve as access interfaces.	For related configuration, see 10.1 Setting a Layer 3 Interface.

Port Type	Note	Remarks
Layer 3 Aggregate Interface	A Layer 3 aggregate interface is a logical aggregate interface group composed of multiple physical member ports, just like a Layer 2 aggregate Interface. The ports to be aggregated must be Layer 3 ports of the same type. An aggregate interface serves as the gateway interface of Layer 3 switching. It treats multiple physical links in the same aggregate group as one logical link. It is an important way to expand link bandwidth. Multiple physical links are combined into one logical link, expanding the bandwidth of a link. Frames sent over the Layer 3 aggregate interface are balanced among the Layer 3 aggregate interface member ports. If one member link fails, the Layer 3 aggregate interface automatically transfers the traffic on the faulty link to other member links, improving reliability of connections. Layer 3 aggregate interfaces do not support the Layer 2 switching function.	For related configuration, see 10.1 Setting a Layer 3 Interface.


# 7.2 Port Configuration

Port configuration includes common attributes such as basic settings and physical settings of the port. Users can adjust the port rate, set port switch, duplex mode, flow control mode, energy efficient Ethernet switch, port media type and MTU, etc.


# 7.2.1 Basic Settings

Choose Local Device > Ports > Port Settings > Basic Settings.

Support setting whether to enable the port, the speed and duplex mode of the port, and the flow control mode, and display the current actual status of each port.



Batch configure: Click **Batch Edit**, select the port to be configured In the displayed dialog box, select the port switch, rate, work mode, and flow control mode, and click **OK** to deliver the configuration. In batch configuration, optional configuration items are a common collection of selected ports (that is, attributes supported the selected ports).



Configure one port: In **Port List**, select a port entry and click **Edit** in the **Action** column. In the displayed dialog box, select port status, rate, work mode, and flow control mode, and click **OK**.




Table 7-2 Description of Basic Port Configuration Parameters

Parameter	Description	Default Value
Status	If a port is closed, no frame will be received and sent on this port, and the corresponding data processing function will be lost.	Enable
Rate	Set the rate at which the Ethernet physical interface works.  Set to Auto means that the port rate is determined by the auto-negotiation between the local and peer devices. The negotiated rate can be any rate within the port capability.	Auto
Work Mode	<ul> <li>Full duplex: realize that the port can receive packets while sending.</li> <li>Half duplex: control that the port can receive or send packets at a time.</li> <li>Auto: the duplex mode of the port is determined through auto negotiation between the local port and peer port</li> </ul>	Auto

Parameter	Description	Default Value
Flow Control	After flow control is enabled, the port will process the received flow control frames, and send the flow control frames when congestion occurs on the port.	Disable




## Note

The rate of a GE optical port can be set to 1000M, 100M, or Auto. The rate of a GE electrical port can be set to 1000M, 100M, 100M, or Auto. The rate of a 10GE port can be set to 1000M or Auto.

# 7.2.2 Physical Settings

Choose Local Device > Ports > Port Settings > Physical Settings.

Support to enable the energy-efficient Ethernet (EEE) function of the port, and set the media type and MTU of the port.




 Batch configure: Click Batch Edit. In the displayed dialog box, select the port to be configured, configure the EEE switch and port mode, enter the port description and MTU, and click OK.



# Note

Copper ports and SFP ports cannot be both configured during batch configuration.



Configure one port: Click Edit in the Action column of the list. In the displayed configuration box, configure
the EEE switch and port mode, enter the port description and MTU, and click OK.




Table 7-3 Description of Physical Configuration Parameters

Parameter	Description	Default Value
EEE	It is short for energy-efficient Ethernet, which is based on the standard IEEE 802.3az protocol. When enabled, EEE saves energy by making the interface enter LPI (Low Power Idle) mode when the Ethernet connection is idle.  Value: Disable/Enable	Disable
Attribute	The port attribute indicates whether the port is a copper port or an SFP port.  Copper port: copper mode (cannot be changed);  SFP port: fiber mode (cannot be changed);  Only combo ports support mode change.	Depending on the port attribute
Description	You can add a description to label the functions of a port.	NA

Parameter	Description	Default Value
MTU	MTU (Maximum Transmission Unit) is used to notify the peer of the acceptable maximum size of a data service unit. It indicates the size of the payload acceptable to the sender. You can configure the MTU of a port to limit the length of a frame that can be received or forwarded through this port.	1500

# A

#### Note

- Different ports support different attributes and configuration items.
- Only the SFP combo ports support port mode switching.
- SFP ports do not support enabling EEE.

# 7.3 Aggregate Interfaces

# 7.3.1 Aggregate Interface Overview

An aggregate interface is a logical link formed by binding multiple physical links. It is used to expand link bandwidth, thereby improving connection reliability.

This function supports load balancing and therefore, evenly distributes traffic to member links. It implements link backup. When a member link of an aggregate interface is disconnected, the system automatically distributes traffic of this link to other available member links. Broadcast or multicast packets received by one member link of an aggregate interface are not forwarded to other member links.

- If a single interface that connects two devices supports the maximum rate of 1000 Mbps (assume that interfaces of both devices support the rate of 1000 Mbps), when the service traffic on the link exceeds 1000 Mbps, the excess traffic will be discarded. Link aggregation can solve this problem. For example, use n network cables to connect the two devices and bind the interfaces together. In this way, the interfaces are logically bound to support the maximum traffic of 1000 Mbps × n.
- If two devices are connected through a single cable, when the link between the two interfaces is disconnected, services carried on this link are interrupted. After multiple interconnected interfaces are bound, as long as there is one link available, services carried on these interfaces will not be interrupted.

# 7.3.2 Overview

# 1. Static Aggregation Address

In static aggregation mode, you can manually add a physical port to an aggregate interface. An aggregate interface in static aggregation mode is called a static aggregate interface and the member ports are called member ports of the static aggregate interface. Static aggregation can be easily implemented. You can aggregate multiple physical links by running commands to add specified physical ports to an aggregate interface. Once a member interface is added to an aggregate interface, it can send and receive data and balance traffic in the aggregate interface.

# 2. Automatic Aggregation

Automatic aggregation mode is a special port aggregation function developed for the WAN port of RG-EG series gateway devices. The maximum bandwidth of the WAN port of the RG-EG device is 2000M, but after the intranet port is connected to the switch, a single port can only support a maximum bandwidth of 1000M. In order to prevent the downlink bandwidth from being wasted, it is necessary to find a way to increase the maximum bandwidth of the port between the MR device and the switch, and the automatic aggregation function emerged to meet the need.

After connecting the two fixed aggregation member ports on the RG-EG gateway device to any two ports on the switch, through packet exchange, the two ports on the switch can be automatically aggregated, thereby doubling the bandwidth. The aggregate interface automatically generated in this way on the switch is called an automatic aggregate interface, and the corresponding two ports are the member ports of the aggregate interface.



#### Note

Automatic aggregate interfaces do not support manual creation and can be deleted after they are automatically generated by the device, but member ports cannot be modified.

#### **Specification**

The RG-NBS3100, RG-NBS3200, and RG-NBS5200 series switches support automatic aggregation, and the peer device for automatic aggregation must be RG-EG310G-E.

#### 3. Load Balancing

An aggregate interface, based on packet characteristics such as the source MAC address, destination MAC address, source IP address, destination IP address, L4 source port ID, and L4 destination port ID of packets received by an inbound interface, differentiates packet flows according to one or several combined algorithms. It sends the same packet flow through the same member link, and evenly distributes different packet flows among member links. For example, in load balancing mode based on source MAC addresses, packets are distributed to different member links of an aggregate interface based on their source MAC addresses. Packets with different source MAC addresses are distributed to different member links; packets with a same source MAC address are forwarded along a same member link.

Currently, the aggregate interface supports the traffic balancing modes based on the following:

- Source MAC address or destination MAC address
- Source MAC address + destination MAC address
- Source IP address or destination IP address
- Source IP address + destination IP address
- Source port
- L4 source port or L4 destination port
- L4 source port + L4 destination port

## 4. LACP

Link Aggregation Control Protocol (LACP) is a standardized protocol for dynamically aggregating multiple physical links into a single logical link to enhance network bandwidth and reliability. LACP defines the negotiation

process and parameters of link aggregation, which enables the exchange of link aggregation information and the negotiation of link aggregation parameters among network devices and ensures the reliability and stability of the link aggregation. LACP supports dynamic addition and deletion of links, achieving dynamic link adjustment and optimization.

In LACP, two roles are defined: the actor and the partner. The actor sends a link aggregation request, while the partner responds to the request and joins the link aggregation group.

# 7.3.3 Aggregate Interface Configuration


Choose Local Device > Ports > Aggregate Ports > Aggregate Port Settings.

### 1. Adding an Aggregate Interface

Enter an aggregate interface ID, select member ports (ports that are already a member of an aggregate interface cannot be selected), toggle on **LACP**, and click **Save**. You can enable **LACP** to dynamically aggregate links to enhance network reliability and flexibility. The port panel displays a successfully added aggregate interface.

# Note

- An aggregate interface contains a maximum of eight member ports.
- The attributes of aggregate interfaces must be the same, and copper ports and SFP ports cannot be aggregated.
- Automatic aggregate interfaces do not support manual creation.
- The LACP state cannot be modified once a static aggregate interface is created.




## 2. Modifying Member Ports of an Aggregate Interface

Click an added static aggregate interface. Member ports of the aggregate interface will become selected. Click a port to deselect it; or select other ports to join the current aggregate interface. Click **Save** to modify the member ports of the aggregate interface.



# 3. Deleting an Aggregate Interface


Move the cursor over an aggregate interface icon and click upper-right, or select the aggregate interface to be deleted, and click **Delete Selected** to delete the selected aggregate interface. After deleted, the corresponding ports become **available** on the port panel to set a new aggregate interface.



# 7.3.4 Configuring a Load Balancing Mode

Choose Local Device > Ports > Aggregate Port > Global Settings.

Select **Load Balance Algorithm** and click **Save**. The Device distributes incoming packets among member links by using the specified load balancing algorithm. The packet flow with the consistent feature is transmitted by one member link, whereas different packet flows are evenly distributed to various links.




# 7.3.5 Configuring LACP Settings

# 1. LACP System Priority

Choose Local Device > Ports > Aggregate Ports > LACP Settings > Global Settings.


In LACP, the device with a higher system priority becomes the actor in the link aggregation group and controls the working state and parameters of the link aggregation group. The value of system priority ranges from 1 to 65535, and the default value is 32768. The lower the value of system priority, the higher the device priority. When two devices have the same system priority, their MAC addresses are compared, and the device with the smaller MAC address becomes the actor in the link aggregation group.



# 2. LACP Port List

Choose Local Device > Ports > Aggregate Ports > LACP Settings > LACP Port List.

The **LACP Port List** page shows the port ID, priority, mode, and timeout mode of each LACP-enabled port. You can view the member port details of the corresponding link aggregation group by selecting an aggregate interface.



You can select a specific port and click **Edit**, or select multiple ports and click **Batch Edit** to modify the port priority, mode, and timeout mode in the pop-up window. Then, click **OK** to confirm and apply the changes.





Table 7-4 Description of LACP Port List Configuration Parameters

Parameter	Description	Default Value
Priority	Priority is used to determine which port is the master, with the highest-priority port being selected as the active port. The priority value ranges from 1 to 65535, and a lower priority value indicates a higher priority. If multiple ports have the same priority, their priority ranking is determined by evaluating their port IDs, and the port with the lower port ID will be given a higher priority.	32768
Mode	Mode refers to the method by which two devices within a link aggregation group negotiate their operating mode.  Active: In active mode, the device assumes the role of the actor and sends requests to establish link aggregation.  Passive: In passive mode, the device assumes the role of the partner and waits for the peer device to send a request.	Active
Timeout	The purpose of the timeout mode is to determine the timeout period and mechanism for LACP link aggregation. When no LACP frames are received from the peer device within the specified timeout duration, it is assumed that the peer device has experienced a failure. As a result, the failure detection and recovery mechanism of the link aggregation is triggered.  Long: In long timeout mode, LACP frames are sent every 30 seconds, and the timeout duration is set to 90 seconds. This mode enhances the reliability and stability of link aggregation, but it can potentially lead to delayed detection of faults.  Short: In short timeout mode, LACP frames are sent every second, and the timeout duration is set to 3 seconds. This mode enhances the response speed of link aggregation and ensures timely fault detection, but it may impose additional network load and resource consumption.	Long

# 3. Viewing LACP State

Choose Local Device > Ports > Aggregate Ports > LACP Details.

You can select an LACP-enabled aggregate interface and click **Search** to view the LACP-enabled member ports and the aggregate interface information on this page.




# 7.4 Port Mirroring

# 7.4.1 Overview

The switched port analyzer (SPAN) function is a function that copies packets of a specified port to another port that is connected to a network monitoring device, After port mirroring is set, the packets on the source port will be copied and forwarded to the destination port, and a packet analyzer is usually connected to the destination port to analyze the packet status of the source port, so as to monitor all incoming and outgoing packets on source ports.

As shown, by configuring port mirroring on Device A, the device copies the packets on Port 1 to Port 10. Although the network analysis device connected to Port 10 is not directly connected to Port 1, it can receive packets through Port 1. Therefore, the aim to monitor the data flow transmitted by Port 1 is realized.

Figure 7-1 Port Mirroring Principles Figure



The SPAN function not only realizes the data traffic analysis of suspicious network nodes or device ports, but also does not affect the data forwarding of the monitored device. It is mainly used in network monitoring and troubleshooting scenarios.

# 7.4.2 Procedure

Choose Local Device > Ports > Port Mirroring.

Click **Edit**, select the source port, destination port, monitor direction, and whether to receive packets from non-source ports, and click **OK**. A maximum of four SPAN entries can be configured.


To delete the port mirroring configuration, click **Delete** in the corresponding **Action** column.

## $\Lambda$

# Caution

• You can select multiple source traffic monitoring ports but only one destination port. Moreover, the source traffic monitoring ports cannot contain the destination port.

- An aggregate interface cannot be used as the destination port.
- A maximum of four SPAN entries can be configured. SPAN cannot be configured for ports that have been used for SPAN.






Table 7-5 Description of Port Mirroring Parameters


Parameter	Description	Default Value	
Src Port	A source port is also called a monitored port. Data flows on the source port are monitored for network analysis or troubleshooting.	N/A	
	Support selecting multiple source ports and mirroring multiple ports to one destination port		

Parameter	Description	Default Value
Dest Port	The destination port is also called the monitoring port, that is, the port connected to the monitoring device, and forwards the received packets from the source port to the monitoring device.	N/A
Monitor Direction	<ul> <li>The type of packets (data flow direction) to be monitored by a source port.</li> <li>Both: All packets passing through the port, including incoming and outgoing packets</li> <li>Incoming: All packets received by a source port are copied to the destination port</li> <li>Outgoing: All packets transmitted by a source port are copied to the destination port</li> </ul>	Both
Receive Pkt from Non-Src Ports	It is applied to the destination port and indicates whether a destination port forwards other packets while monitoring packets.  • Enabled: While monitoring the packets of the source port, the packets of other non-source ports are normally forwarded  • Disabled: Only monitor source port packets	Enable

# 7.5 Rate Limiting

Choose Local Device > Ports > Rate Limiting.

The **Rate Limiting** module allows you to configure traffic limits for ports, including rate limits for inbound and outbound direction of ports.



# 7.5.1 Rate Limiting Configuration

Click **Batch Edit**. In the displayed dialog box, select ports and enter the rate limits, and click **OK**. You must configure at least the ingress rate or egress rate. After the configuration is completed, it will be displayed in the list of port rate limiting rules.




Table 7-6 Description of Rate Limiting Parameters

Parameter	Description	Default Value
Rx Rate	Max Rate at which packets are sent from a port to a switch, in kbps.	Not limited
Tx Rate	Max Rate at which packets are sent out of a switch through a port, in kbps.	Not limited

# 7.5.2 Changing Rate Limits of a Single Port

In the port list for which the rate limit has been set, click **Edit** on the corresponding port entry, enter the ingress rate and egress rate in the displayed dialog box, and click **OK**.



# 7.5.3 Deleting Rate Limiting

Batch configure: Select multiple records in **Port List**, click **Delete Selected** and click **OK** in the confirmation dialog box.

Configure one port: In **Port List**, click **Delete** on the corresponding port entry, and click **OK** in the confirmation dialog box.



- Note
- When configuring rate limits for a port, you must configure at least the ingress rate or egress rate.
- When the ingress rate or egress rate is not set, the port rate is not limited.

# 7.6 PoE Configuration




# Specification

Only PoE switches (model name containing -P, -LP, -HP, and -UP) support this function.

#### Choose Local Device > Ports > PoE.

The device supplies power to PoE powered devices through ports. Users can view the current power supply status, and set the system power supply and port power supply policies respectively to achieve flexible power distribution.


#### **PoE Overview**



# PoE Settings

Power Mode: ②

**Energy Saving** 



# 7.6.1 PoE Global Settings

Choose Local Device > Ports > PoE > PoE Settings.

PoE Transmit Power Mode refers to the way that a device allocates power to a connected PD (Powered Device). It supports Auto mode and Energy-saving mode.

In Auto mode, the system allocates power based on the classes of PDs detected on ports. The device allocates power to PD devices of Class 0~4 based on a fixed value: Class 0 is 15.4W, Class 1 is 4W, Class 2 is 7W, Class 3 is 15.4W, Class 4 Type 1 is 15.4W, and Class 4 Type 2 is 30W. In this mode, if the port is connected to a device of Class 3, even if the actual power consumption is only 11W, the PoE power supply device will allocate power to the port based on the power of 15.4W.

In energy-saving mode, the PoE device dynamically adjusts allocated power based on actual consumption of PDs. In this mode, in order to prevent the power supply of the port from fluctuating due to the fluctuation of the actual power consumption of the PD when the power is fully loaded, you can set the Reserved Transmit Power, and the reserved power will not be used for power supply, so as to ensure that the total power consumed by the current system does not exceed the limit of the PoE device. The size of the reserved power is expressed as a percentage of the total PoE power. The value ranges from 0 to 50.

PoE watchdog: This feature is mainly applicable to security surveillance scenarios. After this feature is enabled, when a PoE port of the device suddenly stops receiving packets during the ping interval, the powered device (PD) will be restarted after the ping interval expires to restore normal operation.

Table 7-7 PoE Watchdog Configuration Description


Packet Receiving Status of the PoE Port	PoE Watchdog is Enabled	Action Taken on the PD
During the ping interval, a PoE port of the device	Yes	The PD is restarted to restore normal operation, and the ping interval is reset.
suddenly stops receiving packets.	No	No action is initiated on the PD.
During the ping interval, a	Yes	No action is initiated on the PD.
PoE port of the device still stops receiving packets.	No	No action is initiated on the PD.
During the ping interval, a PoE port of the device starts to receive packets.	Yes	The ping interval is reset.
	No	No action is initiated on the PD.

# 0

# Note

If a non-PD, such as a computer, is connected to a PoE-enabled port of this device, the PoE watchdog will not initiate any action on the non-PD even if the trigger condition is met.

# **PoE Settings**



# 7.6.2 Power Supply Configuration of Ports

Choose Local Device > Ports > PoE > Port List.

Click Edit in the port entry or click Batch Edit to set the PoE power supply function of the port.




Table 7-8 Description of Parameters for Power Supply Configuration of Ports

Parameter	Description	Default Value
PoE	Whether to enable the power supply function on the ports	Enable
Non-Standard	By default, the device only supplies power to PDs that comply with the standard IEEE 802.3af and 802.3at protocols. In practical applications, there may be PDs that do not conform to the standard. After the non-standard mode is enabled, the device port can supply power to some non-standard PD devices.	Disable
Priority	The power supply priority of the port is divided into three levels: High, Medium, and Low In auto and energy-saving modes, ports with high priorities are powered first. When the system power of the PoE device is insufficient, ports with low priorities are powered off first.  Ports with the same priority are sorted by the port number. A smaller port number indicates a higher priority.	Low

Parameter	Description	Default Value
Max Power	The maximum power that the port can transmit, ranging from 0 to 30, in watts (W). A blank value indicates no limit	Not limit

# 7.6.3 Displaying Global PoE Information

Choose Local Device > Ports > PoE > PoE Overview.

Displays the global power supply information of the PoE function, including the total system power, used power, reserved power, remaining available power, peak maximum power, and the number of ports currently powered.



# 7.6.4 Displaying the Port PoE Information

Choose Local Device > PoE > Port List.

The **Port List** displays the PoE configuration and status information of each port. Click to expand the detailed information.

When the PD device connected to the port needs to be restarted, for example, when the AP connected to the port is abnormal, you can click **Repower** to make the port power off briefly and then power on again to restart the device connected to the power supply port.




Table 7-9 Description of Port Power Supply Info

Field	Description
Port	Device Port ID
PoE Status	Whether to enable the PoE function on the ports.
Power Status	Whether the port supplies power for PDs currently.
Priority	The power supply priority of the port is divided into three levels: High, Medium, and Low.


Field	Description	
Current Power	Indicates the power output by the current port, in watts (W).	
Non-Standard	Indicates whether the non-standard compatibility mode is enabled.	
Work Status	Current work status of PoE ports.	
Current	Indicates the present current of the port in milliamps (mA).	
Voltage	Indicates the present current of the port in volts (V).	
Avg Power	Indicates the current average power of the port, namely, the sampling average of current power after the port is powered on, in watts (W).	
Max Power	The maximum output power of the port in watts (W).	
PD Class	The classification level of the PD connected to the port is divided into Class 0~4, based on the IEEE 802.3af/802.3at standard.	

# 7.7 MGMT IP Configuration

# 7.7.1 Configuring the Management IPv4 Address

Choose Local Device > Ports > MGMT IP > MGMT IP.

The **MGMT IP** page allows you to configure the management IP address for the device. Users can configure and manage the device by accessing the management IP.



The device can be networked in two modes:

- DHCP: Uses a temporary IP address dynamically assigned by the upstream DHCP server for Internet access.
- Static IP: Uses a static IP address manually configured by users for Internet access.

If you select DHCP, the device obtains parameters from the DHCP Server. If Static IP is selected, you need to enter the management VLAN, IP address, subnet mask, default gateway IP address, and address of a DNS server. Click **Save** to make the configuration take effect.



- If the management VLAN is null or not specified, VLAN 1 takes effect by default.
- The management VLAN must be selected from existing VLANs. If no VLAN is created, go to the VLAN list to add a VLAN (for details, see <u>5.2 Configuring a VLAN</u>).
- You are advised to bind a configured management VLAN to an uplink port. Otherwise, you may fail to
  access the web interface.

# 7.7.2 Configuring the Management IPv6 Address

Configure the IPv6 address used to log in to the device management page.


Choose Local Device > Ports > MGMT IP > MGMT IPv6.

Configure the management IPv6 address so that you can log in to the device management page using the IPv6 address of the device.

The device supports the following Internet connection types:

- **Null**: The IPv6 function is disabled on the current port.
- DHCP: The device dynamically obtains an IPv6 address from the upstream device.
- Static IP: You need to manually configure the IPv6 address, length, gateway address, and DNS server.

Click Save.



# 8 Layer 2 Multicast

# 8.1 Multicast Overview

IP transmission methods are categorized into unicast, multicast, and broadcast. In IP multicast, an IP packet is sent from a source and forwarded to a specific group of receivers. Compared with unicast and broadcast, IP multicast saves bandwidth and reduces network loads. Therefore, IP multicast is applied to different network services that have high requirements for real timeliness, for example, Internet TV, distance education, live broadcast and multimedia conference.

# 8.2 Multicast Global Settings

Choose Local Device > L2 Multicast > IGMP Snooping > Global Settings.

**Global Settings** allow you to specify the version of the IGMP protocol, whether to enable report packet suppression, and the behavior for processing unknown multicast packets.




Table 8-1 Description of Configuration Parameters of Global Multicast

Parameter	Description	Default Value
Version	The Internet Group Management Protocol (IGMP) is a TCP/IP protocol that manages members in an IPv4 multicast group and runs on the multicast devices and hosts residing on the stub of the multicast network, creating and maintaining membership of the multicast group between the hosts and connected multicast devices. There are three versions of IGMP: IGMPv1, IGMPv2, and IGMPv3.  This parameter is used to set the highest version of IGMP packets that can be processed by Layer 2 multicast, and can be set to IGMPv2 or IGMPv3.	IGMPv2


Parameter	Description	Default Value
IGMP Report Suppression	After this function is enabled, to reduce the number of packets in the network, save network bandwidth and ensure the performance of the IGMP multicast device, the switch forwards only one report packet to the multicast router if multiple downlink clients connected to the switch simultaneously send the report packet to demand the same multicast group.	Disable
Unknown Multicast Pkt	When both the global and VLAN multicast functions are enabled, the processing method for receiving unknown multicast packets can be set to <b>Discard</b> or <b>Flood</b> .	Discard

# 8.3 IGMP Snooping

### 8.3.1 Overview

The Internet Group Management Protocol (IGMP) snooping is an IP multicast snooping mechanism running on a VLAN to manage and control the forwarding of IP multicast traffic within the VLAN. It implements the Layer 2 multicast function.


Generally, multicast packets need to pass through Layer 2 switches, especially in some local area networks (LANs). When the Layer 2 switching device does not run IGMP Snooping, the IP multicast packets are broadcast in the VLAN; when the Layer 2 switching device runs IGMP Snooping, the Layer 2 device can snoop the IGMP protocol packets of the user host and the upstream PIM multicast device. In this way, a Layer 2 multicast entry is established, and IP multicast packets are controlled to be sent only to group member receivers, preventing multicast data from being broadcast on the Layer 2 network.



# 8.3.2 Enabling Global IGMP Snooping

Choose Local Device > L2 Multicast > IGMP Snooping > IGMP Snooping.

Turn on IGMP Snooping and click Save.




# 8.3.3 Configuring Protocol Packet Processing Parameters

By controlling protocol packet processing, a Layer 2 multicast device can establish static or dynamic multicast forwarding entries. In addition, the device can adjust parameters to refresh dynamic multicast forwarding entries and IGMP snooping membership quickly.

Choose Local Device > L2 Multicast > IGMP Snooping > IGMP Snooping.

The IGMP Snooping function is implemented based on VLANs. Therefore, each VLAN corresponds to an IGMP Snooping setting entry. There are as many IGMP Snooping entries as VLANs on the device.

Click **Edit** in the VLAN entry. In the displayed dialog box enable/disable the VLAN multicast function, dynamic learning function, fast leave function and static route connection port, and set the router aging time and the host aging time, and click **OK**.






Table 8-2 Description of VLAN Configuration Parameters of IGMP Snooping


Parameter	Description	Default Value
Multicast Status	Whether to enable or disable the VLAN multicast function. The multicast function of a VLAN takes effect only when both the global IGMP snooping and VLAN multicast functions are enabled.	Disable
Dynamic Learning	The device running IGMP Snooping identifies the ports in the VLAN as router ports or member ports. The router port is the port on the Layer 2 multicast device that is connected to the Layer 3 multicast device, and the member port is the host port connected to the group on the Layer 2 multicast device.  By snooping IGMP packets, the Layer 2 multicast device can automatically discover and maintain dynamic multicast router ports.	Enable
Router Port	List of current multicast router ports includes dynamically learned routed ports (if Dynamic Learning function is enabled) and statically configured routed ports.	NA
Fast Leave	After it is enabled, when the port receives the Leave packets, it will immediately delete the port from the multicast group without waiting for the aging timeout. After that, when the device receives the corresponding specific group query packets and multicast data packets, the device will no longer forward it to the port.  This function is applicable when only one host is connected to	Disable

Parameter	Description	Default Value
	one port of the device, and is generally enabled on the access switch directly connected to the endpoint.	
Router Aging Time (Sec)	Aging time of dynamically learned multicast router ports ranges from 30 to 3600, in seconds.	300 seconds
Host Aging Time (Sec)	Aging time of dynamically learned member ports of a multicast group, in seconds.	260 seconds
Select Port	In the displayed dialog box, select a port and set it as the static router port. When a port is configured as a static router port, the port will not age out	NA

# 8.4 Configuring MVR

#### 8.4.1 Overview

IGMP snooping can forward multicast traffic only in the same VLAN. If multicast traffic needs to be forwarded to different VLANs, the multicast source must send multicast traffic to different VLANs. In order to save upstream bandwidth and reduce the burden of multicast sources, multicast VLAN register (MVR) comes into being. MVR can copy multicast traffic received from an MVR VLAN to the VLAN to which the user belongs and forward the traffic.



#### 8.4.2 Configuring Global MVR Parameters

Choose Local Device > L2 Multicast > IGMP Snooping > MVR.

Click to enable the MVR, select the MVR VLAN, set the multicast group supported by the VLAN, and click **Save**. Multiple multicast groups can be specified by entering the start and end multicast IP addresses.





Table 8-3 Description of Configuring Global MVR Parameters

Parameter	Description	Default Value
MVR	Enables/Disables MVR globally	Disable
Multicast VLAN	VLAN of a multicast source	1
Start IP Address	Learned or configured start multicast IP address of an MVR multicast group.	NA
End IP Address	Learned or configured end multicast IP address of an MVR multicast group.	NA

#### 8.4.3 Configuring the MVR Ports

Choose Local Device > L2 Multicast > IGMP Snooping > MVR.

 Batch configure: Click Batch Edit, select the port role, the port to be set, and whether to enable the Fast Leave function on the port, and click OK.



• Configure one port: Click the drop-down list box to select the MVR role type of the port. Click the switch in the **Fast Leave** column to set whether the port enables the fast leave function.




Table 8-4 Description of MVR Configuration Parameters of Ports

Parameter	Description	Default Value
Role	NONE: Indicates that the MVR function is disabled.  SOURCE: Indicates the source port that receives multicast data streams.  RECEIVER: Indicates the receiver port connected to a client.	NONE
Fast Leave	Configures the fast leave function for a port. After the function is enabled, if the port receives the leave packet, it is directly deleted from the multicast group.	Disable

- Note
- If a source port or a receiver port is configured, the source port must belong to the MVR VLAN and the
  receiver port must not belong to the MVR VLAN.
- The fast leave function takes effect only on the receiver port.


# 8.5 Configuring Multicast Group

Choose Local Device > L2 Multicast > IGMP Snooping > Multicast Group.

A multicast group consists of the destination ports, to which multicast packets are to be sent. Multicast packets are sent to all ports in the multicast group.

You can view the **Multicast List** on the current page. The search box in the upper-right corner supports searching for multicast group entries based on VLAN IDs or multicast addresses.

Click Add to create a multicast group.






Table 8-5 Description of Multicast Group Configuration Parameters

Parameter	Description	Default Value
VLAN ID	VLAN, to which received multicast traffic belongs	NA
Multicast IP Address	Multicast IP address. The value range is from 224.0.1.0 to 239.255.255.255.	NA
Multicast Source IP	IP address of a multicast source.  i Note  When the software version is ReyeeOS 2.320 or later and the IGMP version configured globally is IGMPv3, this parameter can be set and displayed in the multicast list.	NA
Protocol	If the VLAN ID is a multicast VLAN and the multicast address is within the multicast IP address range of the MVR, the protocol is MVR. In other cases, the protocol is IGMP snooping.	NA
Туре	Multicast group generation mode can be statically configured or dynamically learned.  In normal cases, a port can join a multicast group only after the port receives an IGMP Report packet from the multicast, that is, dynamically learned mode.  If you manually add a port to a group, the port can be statically added to the group and exchanges multicast group information with the PIM router without IGMP packet exchange.	NA
Forwarding Port	List of ports that forward multicast traffic	NA
INCLUDE Port	The INCLUDE port only receives traffic from specified multicast source addresses. As shown in the previous figure, the INCLUDE port is Te1/0/4, and receives only traffic with the source address 2.2.2.6 from the multicast traffic with the address 224.2.2.2.  i Note  When the software version is ReyeeOS 2.320 or later and the IGMP version configured globally is IGMPv3, this parameter can be set and displayed in the multicast list.	NA

Parameter	Description	Default Value
EXCLUDE Port	The EXCLUDE port does not receive traffic from specified multicast source addresses. As shown in the previous figure, the EXLUDE port is Te1/0/5, and does not receive multicast traffic with the source address 2.2.2.6 from the multicast traffic with the address 224.2.2.2.	NA
	When the software version is ReyeeOS 2.320 or later and the IGMP version configured globally is IGMPv3, this parameter can be set and displayed in the multicast list.	



Note


Static multicast groups cannot learn other dynamic forwarding ports.

## 8.6 Configuring a Port Filter

Choose Local Device > L2 Multicast > IGMP Snooping > IGMP Filter.

Generally, the device running ports can join any multicast group. A port filter can configure a range of multicast groups that permit or deny user access, you can customize the multicast service scope for users to guarantee the interest of operators and prevent invalid multicast traffic.

There are 2 steps to configure the port filter: configure the profile and set a limit to the range of the port group address.



#### 8.6.1 Configuring Profile

Choose Local Device > L2 Multicast > IGMP Snooping > IGMP Filter > Profile List.

Click **Add** to create a **Profile**. A profile is used to define a range of multicast groups that permit or deny user access for reference by other functions.




Table 8-6 Description of Profile Configuration Parameters

Parameter	Description	Default Value
Profile ID	Profile ID	NA
Behavior	DENY: Forbids demanding multicast IP addresses in a specified range.  PERMIT: Only allows demanding multicast IP addresses in a specified range.	NA
Start IP Address	Start Multicast IP address of the range of multicast group addresses	NA
End IP Address	End Multicast IP address of the range of multicast group addresses	NA

#### 8.6.2 Configuring a Range of Multicast Groups for a Profile

Choose Local Device > L2 Multicast > IGMP Snooping > IGMP Filter > Filter List.

The port filter can cite a profile to define the range of multicast group addresses that can be or cannot be demanded by users on a port.

Click **Batch Edit**, or click **Edit** of a single port entry. In the displayed dialog box, select profile ID and enter the maximum number of multicast groups allowed by a port and click **OK**.




Table 8-7 Description of Port Filter Configuration Parameters

Parameter	Description	Default Value
Profile ID	Profile that takes effect on a port. If it is not set, no profile rule is bound to the port.	NA
Max Multicast Groups	Maximum number of multicast groups that a port can join.  If too much multicast traffic is requested concurrently, the multicast device will be severely burdened. Therefore, configuring the maximum number of multicast groups allowed for the port can guarantee the bandwidth.	256

## 8.7 Setting an IGMP Querier

#### 8.7.1 Overview

In a three-layer multicast network, the Layer 3 multicast device serves as the querier and runs IGMP to maintain group membership. Layer 2 multicast devices only need to listen to IGMP packets to establish and maintain forwarding entries and implement Layer 2 multicasting. When a multicast source and user host are in the same Layer 2 network, the query function is unavailable because the Layer 2 device does not support IGMP. To resolve this problem, you can configure the IGMP snooping querier function on the Layer 2 device so that the Layer 2 device sends IGMP Query packets to user hosts on behalf of the Layer 3 multicast device, and listens to and maintains IGMP Report packets responded by user hosts to establish Layer 2 multicast forwarding entries.

#### 8.7.2 Procedure

Choose Local Device > L2 Multicast > IGMP Snooping > Querier.

One querier is set for each VLAN. The number of queriers is the same as that of device VLANs.

In **Querier List**, click **Edit** in the last **Action** column. In the displayed dialog box, select whether to enable the querier, set the querier version, querier source IP address, and packet query interval, and click **OK**.




Table 8-8 Description of Querier Configuration Parameters

Parameter	Description	Default Value
Querier Status	Whether to enable or disable the VLAN querier function.	Disable
Version	IGMP Protocol version of query packets sent by the querier. It can be set to IGMPv2 or IGMPv3.	IGMPv2
Src IP Address	Source IP address carried in query packets sent by the querier.	NA
Query Interval (Sec)	Packet transmission interval, of which the value range is from 30 to 18000, in seconds.	60 seconds

#### O

#### Note

- The querier version cannot be higher than the global IGMP version. When the global IGMP version is lowered, the querier version is lowered accordingly.
- If no querier source IP is configured, the device management IP is used as the source IP address of the querier.

# **9** Layer 3 Multicast



**Specification** 

This feature is supported only on the RG-NBS5200 series switches

#### 9.1 Overview

Layer 3 multicast is a communication method that uses multicast addressing at the network layer for sending data. Multicast enables a sender to send packets to a group of receivers simultaneously, which reduces the network bandwidth consumption and lowers the network load. Layer 3 multicast is extensively used in applications such as video conferencing, streaming media, VoIP, and others.

In Layer 3 multicast, each multicast group address corresponds to a specific multicast group, and the members of a multicast group share the same multicast group address. The sender sends data packets to the multicast group address, and routers on the network forward the packets to all members of the multicast group based on the multicast group address and the routing protocols used.

### 9.2 Multicast Routing Table

Choose Local Device > L3 Multicast > Multicast Routing Table.

The **Multicast Routing Table** page displays the information of the Layer 3 multicast routing table, including the source IP address, multicast group address, incoming interface, outgoing interface, and time to live (TTL). You can search the routing information based on either the source IP address or the multicast group address. You can click **Refresh** to view the up-to-date multicast routing table information.




Table 9-1 Description of Multicast Routing Table Parameters

Parameter	Description	Default Value
Source IP Address	IP address of the source device sending the multicast packet.	N/A
Multicast Group Address	A special IP address that identifies a multicast group. In the routing table, the multicast group address is the IP address of the destination multicast group.	N/A

Parameter	Description	Default Value
Incoming Interface	Interface receiving the multicast packets	N/A
Outgoing Interface	When the router receives a multicast packet, it forwards the multicast packet to the appropriate outgoing interface according to the value in the <b>Outgoing Interface</b> field in the routing table.	N/A
TTL	The TTL value is the duration for which a routing table entry remains valid. Once this time expires, the routing table entry is considered expired and is no longer utilized.	N/A

# 9.3 Configuring PIM

#### 9.3.1 Overview

Protocol Independent Multicast (PIM) is a protocol-independent intra-domain multicast routing protocol. PIM allows multicast communication to be implemented using various unicast routing protocols, including static routing, RIP, OSPF, and others. Through the implementation of the PIM protocol, routers can exchange multicast routing information, which enables the establishment and maintenance of multicast trees, thus efficiently delivering multicast data packets from the source to the receivers within the multicast group.


The PIM protocol features two widely used modes:

- PIM Dense Mode (PIM-DM)
  - This mode is applicable to small-scale networks or scenarios with dense multicast traffic. In PIM-DM, multicast packets are transmitted along all available paths, which results in higher network bandwidth and resource consumption.
- PIM Sparse Mode (PIM-SM)
  - This mode is applicable to large-scale networks or scenarios with sparse multicast traffic. In PIM-SM, routers only forward multicast packets along the required paths, effectively reducing the utilization of network bandwidth.

#### 9.3.2 Enabling PIM

Choose Local Device > L3 Multicast > PIM > PIM-enabled Interface List.

Click **Add**. A pop-up window is displayed. On the pop-up window, select the interface on which PIM is to be enabled, and click **OK**. Multicast packet forwarding can be implemented on the selected interface. The PMI mode is PIM-SM by default.



#### 9.3.3 Viewing PIM Neighbor Table

In the PIM protocol, routers discover neighboring routers and establish neighbor relationships through the exchange of Hello messages. Once a neighbor relationship is established between two PIM-enabled routers, they can exchange multicast information, including multicast group memberships and multicast forwarding states. By continuously updating and maintaining the PIM neighbor table, PIM-enabled routers are able to efficiently forward and process multicast packets based on the neighbor information, thereby achieving effective multicast communication.

Choose Local Device > L3 Multicast > PIM > PIM Neighbor Table.

The **PIM Neighbor Table** page displays information about PIM neighbors, such as interface, PIM neighbor, TTL, and aging time. You can search for PIM neighbor table information by entering either the interface or the PIM neighbor in the search box. You can click **Refresh** to view the up-to-date PIM neighbor table information.




Table 9-2 Description of PIM Neighbor Table Parameters

Parameter	Description	Default Value
Interface	Interface connecting the neighbor router to the local router.	N/A
PIM Neighbor	IP address of the neighbor router.	N/A
TTL	The TTL value indicates the duration in which Hello messages sent by neighboring routers remain valid. If the local router does not receive any new Hello messages from a neighbor within the TTL time, it will consider the neighboring router as inactive or expired.	N/A
Aging Time	If a neighboring router becomes inactive or ceases to send Hello messages, the respective entry in the PIM Neighbor Table will be deleted after the specified aging time is exceeded.	105 seconds

# 9.4 Configuring RP

#### 9.4.1 Overview

The Rendezvous Point (RP) is a crucial concept in the PIM protocol. In multicast communication, when a sender sends a multicast data packet, it needs to identify a specific point as the rendezvous point, from which multiple receivers can receive the multicast packet. The RP is the rendezvous point router in the multicast tree. An RP can be manually configured or dynamically elected through the BSR (Bootstrap Router) mechanism.





An RP can provide services for multiple or all multicast groups. However, only one RP can forward multicast traffic for a multicast group at a time.

#### 9.4.2 Configuring a Static RP

Choose Local Device > L3 Multicast > RP > Static RP.

Click **Add**. On the pop-up window that is displayed, enter the multicast group range covered by the RP and the RP address, then click **OK**.





#### 9.4.3 Configuring a Candidate RP

On a PIM network, a Candidate RP refers to a router that is eligible to become an RP. You can configure several PIM-enabled routers in the PIM domain as Candidate RPs, so that a suitable RP is eventually elected. This process aims to enhance the efficiency and reliability of multicast communication.

Choose Local Device > L3 Multicast > RP > Candidate RP.

Toggle on **Local routing device as candidate RP:** to designate the local device as the candidate RP. Enter the priority, advertisement interval, source IP address, and the designated multicast group. Then, click **Save**.

#### **Candidate RP**




Table 9-3 Description of Candidate RP Configuration Parameters

Parameter	Description	Default Value
Priority	The priority determines which candidate RP will become the RP during the election process. The priority value ranges from 0 to 255, where a smaller value indicates a higher priority. A candidate RP with a higher priority has a greater chance of being elected as the RP.	192

Parameter	Description	Default Value
Advertisement interval	A candidate RP announces its presence and availability by sending PIM messages. The advertisement interval determines the frequency at which a candidate RP sends these messages. A shorter advertisement interval can notify other routers about the presence of candidate RP more quickly, but it will also increase the network load.	60 seconds
Source IP Address	The source IP address of the PIM messages sent by the candidate RP, which can be either an interface or an IP address.	N/A
Designated multicast group	The PIM messages sent by the candidate RP must contain a multicast group address, which falls within the range of 224.0.0.0/4 to 239.255.255.255/32. Candidate RPs typically send multiple messages, each specifying a different multicast group address, in order to notify other routers that they can become the RP for these multicast groups. You can click <b>Add</b> to configure multiple multicast group addresses.	N/A

## 9.5 Configuring BSR

#### 9.5.1 Overview

In PIM-SM mode, RP needs to be manually configured, which is a tedious task for large-scale networks. The BSR (Bootstrap Router) mechanism can automatically select the RP, simplifying the RP configuration process. BSR serves as the management core of the PIM-SM domain, responsible for collecting and advertising RP information within the domain. BSR is elected by candidate BSRs.



Note

A PIM-SM domain can have only one BSR, but can have multiple candidate BSRs.

#### 9.5.2 Configuring BSR

Choose Local Device > L3 Multicast > BSR > Local Routing Device as Candidate BSR.

Toggle on **Local routing device as candidate BSR:** to designate the local device as the candidate BSR. Enter the priority and the source IP address. Then, click **Save**.




Table 9-4 Description of Candidate BSR Configuration Parameters

Parameter	Description	Default Value
Priority	Higher-priority candidate BSRs have a greater chance of being elected as the BSR. The priority value ranges from 0 to 255, where a smaller value indicates a higher priority.	192
Source IP Address	The source IP address of the PIM messages sent by the candidate BSR, which can be either an interface or an IP address.	N/A

#### 9.5.3 Viewing BSR Routing Info

Choose Local Device > L3 Multicast > BSR > BSR Routing Info.

The **BSR Routing Info** page displays BSR routing information, including BSR address, priority, status, online duration and aging time. You can click **Refresh** to view the up-to-date BSR routing information.



# 9.6 Configuring IGMP


#### 9.6.1 Overview

Internet Group Management Protocol (IGMP) is used to enable multicast communication on IPv4 networks. IGMP is responsible for managing the membership of multicast groups and facilitating communication between hosts and multicast routers. With IGMP, hosts can join or leave a specific multicast group and advertise its membership to multicast routers. Multicast routers use IGMP to determine which hosts are members of a multicast group, enabling efficient forwarding of multicast traffic.


#### 9.6.2 Enabling IGMP

Choose Local Device > L3 Multicast > IGMP > IGMP-enabled Interface List.

The **IGMP-enabled Interface List** page displays basic information of IGMP-enabled interfaces, including the interface and the IGMP version.



Add: Click **Add**. The **Select Interfaces** pop-up window is displayed. On the pop-up window, select an interface on which IGMP will be enabled. Then, Click **OK**. IGMP is enabled on the corresponding VLAN.



Batch edit: Select the interfaces, and click **Batch Edit**. On the pop-up window that is displayed, select the IGMP version, then click **OK**.

IGMPv3 has improved functionality and flexibility compared to IGMPv2. It supports more multicast group management features, provides finer control over membership and query methods, and introduces security mechanisms. With these enhancements, IGMPv3 can be applied in scenarios that require a higher level of multicast management and security.



Batch delete: Select the interfaces, and click **Delete Selected**. IGMP is disabled on the selected interfaces.

#### 9.6.3 Viewing IGMP Multicast Group

Choose Local Device > L3 Multicast > IGMP > IGMP Multicast Group.

The **IGMP Multicast Group** page displays information about IGMP multicast groups, including the number of multicast groups, source IP addresses, TTL, and aging time. You can click to expand a multicast group to view the detailed IP addresses associated with the multicast group on that interface.

You can search IGMP multicast group information by entering the interface in the search box. You can click **Refresh** to view the up-to-date IGMP multicast group information.



# **10** Layer 3 Management




The RG-NBS3100 series switches do not support this feature.

## 10.1 Setting a Layer 3 Interface

Choose Local Device > L3 Interfaces > L3 Interfaces.

The port list displays various types of Layer 3 interfaces on the device, including SVIs, Routed Ports, and Layer 3 aggregate interfaces.

Click Add L3 Interface to set a new Layer 3 Interface.






Table 10-1 Description of Configuration Parameters of Layer 3 Interfaces

Parameter	Description
Port Type	The type of a created Layer 3 interface. It can be an SVI, routed port, or Layer 3 aggregate interface. For details, see <u>Table 7-1</u> .
Networking	Specifies DHCP or static mode for a port to obtain the IP address.

Parameter	Description
VLAN	When <b>Port Type</b> is set to <b>SVI</b> , you need to specify the VLAN, to which an SVI belongs.
Primary IP/Mask	When <b>Networking</b> is set to <b>Static IP</b> , you need to manually enter the IP address and subnet mask.
Select Port	When <b>Port Type</b> is set to <b>Routed Port</b> or <b>L3 Aggregate Port</b> , you need to select the device port to be configured.
Aggregate	When <b>Port Type</b> is set to <b>L3 Aggregate Port</b> , you need to specify the aggregate interface ID, for example, Ag1, when a Layer 3 aggregate interface is created.
LACP	After LACP is enabled on a Layer 3 aggregate interface, the links can be dynamically ag.
	Disabled: Indicates that the DHCP service is disabled. No IP address can be assigned to clients connected to the interface.      DHCP Server: Indicates that the device functions as the DHCP server to assign IP addresses to downlink devices connected to the interface. You need to set the start IP address of an address pool, number of IP addresses that can be assigned, and
DHCP Mode	<ul> <li>address lease; for more information, see 10.3.1 Enable DHCP Services.</li> <li>DHCP Relay: Indicates that the device serves as a DHCP relay, obtains IP addresses from an external server, and assigns the IP addresses to downlink devices. The interface IP address and DHCP server IP address need to be configured. The interface IP address must be in the same network segment as the address pool of the DHCP server.</li> </ul>
	Note  DHCP Mode can be set to DHCP Server only on RG-NBS5200 series switches.

#### Note

- VLAN 1 is the default SVI of the device. It can be neither modified nor deleted.
- The management VLAN is only displayed on the **L3 Interfaces** page but cannot be modified. To modify it, choose **Ports** > **MGMT IP**. For details, see <u>7.7 MGMT IP Configuration</u>.
- The DHCP relay and DHCP server functions of a Layer 3 interface are mutually exclusive and cannot be configured at the same time.
- Member ports of a Layer 3 interface must be routed ports.
- If the IPv4 address is set to DHCP and the interface fails to obtain an IPv4 address, the IPv6 address will not take effect either.

# 10.2 Configuring the IPv6 Address for the Layer 3 Interface

IPv6 is a suite of standard protocols for the network layer of the Internet. IPv6 solves the following problems of IPv4:

Address depletion:

NAT must be enabled on the gateway to convert multiple private network addresses into a public network address. This results in an extra delay caused by address translation, and may interrupt the connection

between devices inside and outside the gateway. In addition, you need to add a mapping to enable access to the intranet devices from the Internet.


Design defect:

IP addresses cannot be formed using network topology mapping, and a large-scale routing table is needed.

Lack of built-in authentication and confidentiality:

IPv4 itself does not require encryption. It is difficult to trace the source after address translation. As the number of addresses in a network segment is limited, it is easy for attackers to scan all hosts in the LAN. IPv6 integrates IPsec by default. End-to-end connections can be established without address translation, and it is easy to trace the source. IPv6 has a huge address space. A 64-bit prefix address supports 64 host bits, which increases the difficulty and cost of scanning and therefore prevents attacks.

#### Choose Local Device > L3 Interfaces > IPv6 Config.



#### Caution

- Add an IPv4 Layer 3 interface first. Then, select the interface on the IPv6 Layer 3 interface configuration page, and click **Edit**.
- If the IPv4 address of an interface is set to DHCP and no IPv4 address is obtained, the IPv6 address of this interface will not take effect.
- If an upstream DHCPv6 server is available, select Auto Obtained IP and specify the MTU. The default MTU is 1500. You are advised to retain the default value. Then, click OK.



• If no upstream DHCPv6 server is available to assign the IP address, configure the IPv6 information as follows:




Table 10-2 IPv6 Address Configuration Parameters of the Layer 3 Interface

Parameter	Description
Auto Obtained IP	If no upstream DHCPv6 server is available, do not select <b>Obtain an IPv6 address via DHCPv6.</b> . Instead, manually add the IPv6 address.
	Configure the IPv6 address and prefix length. You can click <b>Add</b> to add multiple IPv6 addresses.
IPv6 Address/Prefix	If the primary IP address is empty, the configured secondary IP address is invalid.
Length	For manual configuration, the prefix length ranges from 1 to 128.
	For auto configuration, the prefix length ranges from 1 to 64.
	If the IPv6 prefix length of the Layer 3 interface is between 48 and 64, this address can be assigned.
MTU	Configure the MTU. The default MTU is 1500.
Advanced Settings	Click <b>Advanced Settings</b> to configure the link local address, subnet prefix name, subnet prefix length, and subnet ID.
Link-local Address	The link local address is used to number hosts on a single network link. The first 10 bits of link address in binary notation must be '1111111010'.
Subnet Prefix Name	It identifies a specified link (subnet).
Subnet Prefix Length	It indicates the length (in bits) of the subnet prefix in the address. The value ranges from 48 to 64 (The subnet prefix length must be greater than the length of the prefix assigned by the server).
Subnet ID	Configure the subnet ID of the interface in hexadecimal notation. The number of available subnet IDs is $(2^N - 1)$ , where <b>N</b> is equal to (Subnet prefix length of the

Parameter	Description
	interface - Length of the prefix assigned by the server).

# 10.3 Configuring the DHCP Service



#### **Specification**


This feature is supported only on the RG-NBS5200 series switches

After the DHCP server function is enabled on the Layer 3 interface, the device can assign IP addresses to downlink devices connected to the port.

#### 10.3.1 Enable DHCP Services

Choose Local Device > L3 Interfaces > L3 Interfaces.

Click **Edit** on the designated port, or click **Add L3 Interface** to add a Layer 3 interface, select DHCP mode for local allocation, and enter the starting IP of the address pool, the number of allocated IPs, the excluded IP address range, and the address lease time.



> Port Type Routed Port Networking Static IP \* Primary IP/Mask Add + ? 1.1.1.1 255.255.255.0 DHCP Mode Disabled DHCP Server DHCP Relay \* Start IP Address 1.1.1.1 \* IP Count 254 Available IP Addresses: 244. End IP Address: 1.1.1.254. External IP/External User Add + ?1.1.1.1-1.1.1.10 \* Lease Time (Min) 100 Cancel

Edit ×

Table 10-3 Description of DHCP Server Configuration Parameters


Parameter	Description
DHCP Mode	To choose DHCP server
Start IP Address	The DHCP server assigns the Start IP address automatically, which is the Start IP address of the DHCP address pool. A client obtains an IP address from the address pool. If all the addresses in the address pool are used up, no IP address can be obtained from the address pool.
IP Count	The number of IP addresses in the address pool
External IP/External User	IP addresses in the address pool that are not used for allocation, support inputting a single IP address or IP network segment, and add up to 20 address segments.
Lease Time (Min)	The lease of the address, in minutes. Lease Time (Min): When a downlink client is connected, the leased IP address is automatically renewed. If a leased IP address is not renewed due to client disconnection or network instability, the IP address will be reclaimed after the lease term expires. After the downlink client connection is restored, the client can request an IP address again

#### 10.3.2 Viewing the DHCP Client

Choose Local Device > L3 Interfaces > IPv4 Config > DHCP Clients.

View the addresses automatically allocated to downlink clients after the Layer 3 Interfaces enable DHCP services. You can find the client information based on the MAC address, IP address, or username.


Find the target client and click **Convert to Static IP** in the **Status** column, or select desired clients and click **Batch Convert**. The dynamic address allocation relationship is added to the static address allocation list, so that the host can obtain the bound IP address for each connection. For details on how to view the static address allocation list, see 10.3.3 Configuring Static IP Addresses Allocation.




#### 10.3.3 Configuring Static IP Addresses Allocation

Choose Local Device > L3 Interfaces > IPv4 Config > Static IP Addresses.

Displays the client entries which are converted into static addresses in the client list as well as manually added static address entries. The upper-right search box supports searching for corresponding entries based on the assigned IP address or the Device MAC Address



Click **Add**. In the displayed static IP address binding dialog box, enter the MAC address and IP address of the client to be bound, and click **OK**. After a static IP address is bound, the bound IP address will be obtained each time the corresponding downlink client connects to the network.



To delete a static address, select the static entry to be deleted in **Static IP Address List**, and click **Delete Selected**; or click **Delete** in the last **Action** column of the corresponding entry.

#### 10.3.4 Configuring the DHCP Server Options

Choose Local Device > L3 Interfaces > IPv4 Config > DHCP Option.

The configuration delivered to the downlink devices is optional and takes effect globally when the Layer 3 interface serves as the DHCP server.




Table 10-4 Description of the DHCP Server Options Configuration Parameters

Parameter	Description
DNS Server	DNS server address provided by an ISP. Multiple IP addresses can be entered and separated by spaces.
Option 43	When the AC (wireless controller) and the AP are not in the same LAN, the AP cannot discover the AC through broadcast after obtaining an IP address from the DHCP server. To enable the AP to discover the AC, you need to configure Option 43 carried in the DHCP response packet on the DHCP server.

Parameter	Description
Option 138	Enter the IP address of the AC. Similar to Option 43, when the AC and AP are not in the same LAN, you can configure Option 138 to enable the AP to obtain the IPv4 address of the AC.
Option 150	Enter the IP address of the TFTP server. Enter the IP address of the TFTP server to specify the TFTP server address assigned to the client. Multiple IP addresses can be entered and separated by spaces.
Gateway	Enter the gateway IP address of the DHCP server.



#### Note

DHCP options are optional configuration when the device functions as a Layer 3 DHCP server. The configuration takes effect globally and does not need to be configured by default. If no DNS server address is specified, the DNS address assigned to a downlink port is the gateway IP address by default.

## 10.4 Configuring the DHCPv6 Service



#### **Specification**

This feature is supported only on the RG-NBS5200 series switches

Dynamic Host Configuration Protocol for IPv6 (DHCPv6) is a protocol that allows the DHCP server to pass configuration information (such as the IPv6 network address) to IPv6 nodes.

Compared with other IPv6 address assignment methods (such as manual configuration and stateless address autoconfiguration), DHCPv6 provides the functions of address assignment, Prefix Delegation (PD), and configuration parameter assignment.

- DHCPv6 is both a stateful address autoconfiguration protocol and a stateless address configuration protocol. It supports flexible addition and reuse of network addresses, and can record the assigned addresses, thus enhancing network management.
- The configuration parameter assignment function of DHCPv6 can solve the problem that parameters cannot be obtained under the stateless address autoconfiguration protocol, and provide the host with configuration information, such as the DNS server address and domain name.

#### 10.4.1 Configuring the DHCPv6 Server

Choose Local Device > L3 Interfaces > IPv6 Config > DHCPv6 Server.

(1) Click Add, select a Layer 3 interface and IP address assignment method, and enter the address lease term and DNS server address. The address lease term is 30 minutes by default. You are advised to retain the default value. Then, click OK.




Table 10-5 IPv6 Address Configuration Parameters of the Layer 3 Interface

Parameter	Description
L3 Interfaces	Select the Layer 3 interface for which the DHCPv6 server needs to be added.
IPv6 Assignment	If this parameter is set to <b>Auto</b> , both DHCPv6 and SLAAC are used to assign IPv6 addresses.
Lease Time (Min)	The default value is <b>30</b> minutes. The value ranges from 30 to 2880 minutes.  When the device stays online and the network is normal, this parameter is periodically updated (reset to 0).
DNS Server	Enter the DNS server address.


#### 10.4.2 Viewing DHCPv6 Clients

Choose Local Device > L3 Interfaces > IPv6 Config > DHCPv6 Clients.

View the information of the client that obtains the IPv6 address from the device, including the host name, IPv6 address, remaining lease term, DHCPv6 Unique Identifier (DUID), and status. Click **+ Bind Selected** to bind the IP addresses and hosts in batches, so that the IP addresses obtained by the hosts from the switch remain unchanged.



Each server or client has only one DUID for identification.




#### 10.4.3 Configuring the Static DHCPv6 Address


Configure the IPv6 address statically bound to the DUID of a client so that the client can obtain the specified address each time.

Choose Local Device > L3 Interfaces > IPv6 Config > Static DHCPv6.

Click **Add**, and enter the IPv6 address and DUID. You are advised to bind the IPv6 address and DUID in the client list. You can run the **ipconfig/all** command on the Command Prompt in Windows to view the DUID.

```
Command Prompt
Microsoft Windows [Version 10.0.17763.1577]
(c) 2018 Microsoft Corporation. All rights reserved.
 :\Users\admin<mark>></mark>ipconfig /all
Windows IP Configuration
    Host Name . . . . .
Primary Dns Suffix
                                                                  PC-
    Node Type . . . . . . . IP Routing Enabled. . WINS Proxy Enabled. .
                                                                  Hybrid
                                                                  No
Ethernet adapter
    Connection-specific DNS Suffix
    Description . . . . . . . . . . . . . . . .
                                                                  RuiJie VirtIO Ethernet Adapter
    Physical Address. . . . . DHCP Enabled. . . . . . . . . Autoconfiguration Enabled
                                                                  Yes
                                                                 fe80::6dd5:266f:b695:55df%12(Preferred)
172.26.1.123(Preferred)
255.255.255.0
     Link-local IPv6 Address . .
     IPv4 Address. . . . .
    Subnet Mask . .
Lease Obtained.
                                                                 255.255.255.0
Thursday, December 22, 2022 5:29:03 PM
Friday, December 30, 2022 5:28:57 PM
172.26.1.1
172.26.1.1
340939776
00-01-00-01-27-C7-77-50-52-54-00-3C-D6-BE
     Lease Expires . .
     Default Gateway
    DHCP Server .
    DHCPv6 IAID
     DHCPv6 Client DUID.
```





## 10.5 Configuring the IPv6 Neighbor List


In IPv6, Neighbor Discovery Protocol (NDP) is an important basic protocol. NDP replaces the ARP and ICMP route discovery protocols of IPv4, and supports the following functions: address resolution, neighbor status tracking, duplicate address detection, router discovery, and redirection.


Choose Local Device > L3 Interfaces > IPv6 Config > IPv6 Neighbor List.

Click Add and manually add the interface, IPv6 address and MAC address of the neighbor.

Click Bind Selected to bind the IPv6 address and MAC address in the list to prevent ND attacks.

You can also modify, delete, batch delete, or search neighbors (by IP address or MAC address).






# 10.6 Configuring a Static ARP Entry


Choose Local Device > L3 Interfaces > IPv4 Config > ARP List.

The device learns the IP address and MAC address of the network devices connected to its interfaces and generates the corresponding ARP entries. Supports binding ARP mappings or manually specifying the IP address and MAC address mapping to prevent devices from learning wrong ARP entries and improve network security.


The ARP List displays the reachability, type, IP address, MAC address, and the physical interface corresponding to each MAC address.

- To bind a dynamic ARP entry to a static entry: Select the ARP mapping entry dynamically obtained in the ARP List, and click Bind to complete the binding.
- To manually configure a static ARP entry: Click Add, enter the IP address and MAC address to be bound, and click OK.





To remove the binding between a static IP address and a MAC address, click **Delete** in the **Action** column.



Configuration Guide **Configuring Routes** 

# 11 Configuring Routes



#### **Specification**

The RG-NBS3100 series switches do not support this feature.

## **Configuring Static Routes**

#### Choose Local Device > Routing > Static Routing

Static routes are manually configured by the user. When a data packet matches a static route, the packet will be forwarded according to the specified forwarding mode.



#### Caution


Static routes cannot automatically adapt to changes of the network topology. When the network topology changes, you need to reconfigure the static routes.



#### Note

The maximum number of Layer 3 interfaces and IPv4 addresses varies with device models. For details, see the device's eWeb.

Click Add. In the dialog box that appears, enter the destination address, subnet mask, outbound interface, and next-hop IP address to create a static route.



Configuration Guide Configuring Routes





Table 11-1 Description of Static Routes Configuration Parameters

Parameter	Description
Dest IP Address	Specify the destination network to which the data packet is to be sent. The device matches the data packet based on the destination address and subnet mask.
Subnet Mask	Specify the subnet mask of the destination network. The device matches the data packet based on the destination address and subnet mask.
Outbound Interface	Specify the interface that forwards the data packet.
Next Hop	Specify the IP address of the next hop in the route for the data packet

After creating a static route, you can view the static route information and status in the static route list. The **Reachable** parameter indicates whether the next hop address is on the local directly connected network segment. If the next hop address is on the directly connected network segment, **Yes** is displayed and the route takes effect. Otherwise, **No** is displayed and the route does not take effect. In this case, check the configuration.



To delete or modify a static route, in **Static Route List**, you can click **Delete** or **Edit** in the last **Action** column; or select the static route entry to be deleted, click **Delete Selected** to delete multiple static route entries.

# 11.2 Configuring the IPv6 Static Route

Choose Local Device > Routing > IPv6 Static Routing.

You need to manually configure an IPv6 static route. When the packet matches the static route, the packet will be forwarded according to the specified forwarding method.



#### Caution

The static route cannot automatically adapt to changes in the network topology. When the network topology changes, you need to manually reconfigure the static route.

#### 0

#### Note

The maximum number of Layer 3 interfaces and IPv4 addresses varies with device models. For details, see the device's eWeb.

Click **Add**, and enter the destination IPv6 address, length, outbound interface, and next-hop IP address to create a static route.






Table 11-2 IPv6 Static Route Configuration Parameters

Parameter	Description
IPv6 Address/Prefix Length	Destination network of the packet. The destination address of the packet is matched according to the IPv6 address and prefix length.
Interface	Interface that forwards the packet.

Parameter	Description
Next Hop	IP address of the next routing node to which the packet is sent.

# 11.3 Configuring RIP



**Specification** 

This feature is supported only on the RG-NBS5200 series switches

Routing Information Protocol (RIP) is applicable to small and medium-sized networks and is a dynamic routing protocol that is easy to configure. RIP measures the network distance based on the number of hops and selects a route based on the distance. RIP uses UDP port 520 to exchange the routing information.

#### 11.3.1 Configuring RIP Basic Functions

Choose Local Device > Routing > RIP Settings.

Click **Add** and configure the network segment and interface.






Table 11-3 RIP Configuration Parameters

Parameter	Description
Туре	Network Segment: Enable RIP in the specified network segment. The IP addresses of
	this network segment are added to the RIP routing table. The device and its RIP-enabled

Parameter	Description
	neighbor devices learn the routing table from each other.
	Port: Enable RIP on the specified port. All the IP addresses of this port are added to the
	RIP routing table. The device and its RIP-enabled neighbor devices learn the routing
	table from each other.
	Enter the network segment, for example, 10.1.0.0/24, when Type is set to Network
Network Segment	Segment.
	RIP will be enabled on all interfaces of the device covered by this network segment.
Port	Select a VLAN interface or physical port when <b>Type</b> is set to <b>Port</b> .
	No Authentication: The protocol packets are not authenticated.
Auth Mode	Encrypted Text: The protocol packets are authenticated, and the authentication key is
	transmitted with the protocol packets in the form of encrypted text.
	Plain Text: The protocol packets are authenticated, and the authentication key is
	transmitted with the protocol packets in the form of plain text.
Auth Key	Enter the authentication key to authenticate protocol packets when <b>Auth Mode</b> is set to
	Encrypted Text or Plain Text.

# 11.3.2 Configuring the RIP Port

Choose Local Device > Routing > RIP Settings > Port Settings.




Table 11-4 Configuration Parameters in the Port List

Parameter	Description
Port Name	Name of the port where RIP is enabled.
Rx Status	RIP version of packets currently received.

Parameter	Description
Tx Status	RIP version of packets currently transmitted.
Poison Reverse	After the port learns the route, the route overhead is set to <b>16</b> (indicating that the route is unreachable), and the route is sent back to the neighbor from the original port to avoid a loop.
v2 Broadcast Packet	When a neighbor does not support multicast, broadcast packets can be sent.  You are advised to disable RIPv2 broadcast packets to improve network performance.
	No Authentication: The protocol packets are not authenticated.
Auth Mode	<b>Encrypted Text</b> : The protocol packets are authenticated, and the authentication key is transmitted with the protocol packets in the form of encrypted text.
	Plain Text: The protocol packets are authenticated, and the authentication key is transmitted with the protocol packets in the form of plain text.
Auth Key	Enter the authentication key to authenticate protocol packets when <b>Auth Mode</b> is set to <b>Encrypted Text</b> or <b>Plain Text</b> .
Action	Click <b>Edit</b> to modify RIP settings of the port.

## 11.3.3 Configuring the RIP Global Configuration

Choose Local Device > Routing > RIP Settings > Advanced, click Edit Config, and configure RIP global configuration parameters.




Table 11-5 RIP Global Configuration Parameters


Parameter	Description
RIP Version	Default: Select RIPv2 for sending packets and RIPv1/v2 for receiving packets.
	V1: Select RIPv1 for sending and receiving packets.

Parameter	Description
	V2: Select RIPv2 for sending and receiving packets.
Route Advertisement	After route advertisement is enabled, the current device generates a default route and sends it to the neighbor.
Administrative Distance	Redistribute routes of other protocols to the RIP domain so that RIP can interwork with other routing domains.
Update Timer	RIP update cycle. The routing information is updated every 30 seconds by default.
Invalid Timer	If no update is received before a route becomes invalid, the route is considered unreachable. The default value is 180 seconds.
Flush Timer	If no update is received before the flush timer of an invalid route expires, the route is completely deleted from the RIP routing table. The default value is 120 seconds.

# 11.3.4 Configuring the RIP Route Redistribution List

Redistribute routes of other protocols to the RIP domain so that RIP can interwork with other routing domains.

Choose Local Device > Routing > RIP Settings > Advanced > Route Redistribution List, click Add, and select the type and administrative distance.







Table 11-6 RIP Route Redistribution Parameters


Parameter	Description
Туре	OSPF Routing Static Routing
Administrative Distance	A smaller administrative distance indicates a higher priority. The default value is <b>0</b> . The value ranges from 0 to 16.
Instance ID	Select the instance ID of OSPF that needs to be redistributed, when <b>Type</b> is set to <b>OSPF Routing</b> . OSPFv2 needs to be enabled on the local device.

## 11.3.5 Configuring the Passive Interface

If an interface is configured as a passive interface, it will suppress RIP update packets. If the connected peer device does not run RIP, you are advised to enable the passive interface.

Choose Local Device > Routing > RIP Settings > Advanced > Passive Interface, click Add, and select a passive interface.






## 11.3.6 Configuring the Neighbor Route

When the router cannot process broadcast packets, another router can be designated as the neighbor to establish a RIP direct link.

Choose Local Device > Routing > RIP Settings > Advanced > Neighbor Route, click Add, and enter the IP address of the neighbor router.



# 11.4 Configuring RIPng



This feature is supported only on the RG-NBS5200 series switches


## 11.4.1 Configuring RIPng Basic Functions

RIP Next Generation (RIPng) provides the routing function for IPv6 networks.

RIPng uses UDP port 512 to exchange the routing information.

Choose Local Device > Routing > RIPng Settings > RIPng Settings.

Click Add, set Type to Network Segment or Port, and specify the network segment or port accordingly.



If the address length is between 48 and 64, the address will be used as a prefix.

Alternatively, enable RIPng on a specified port:




**Table 11-7 RIPng Configuration Parameters** 

Parameter	Description
Туре	Network Segment: Enable RIP in the specified network segment. The IP addresses of this network segment are added to the RIP routing table, and the device and its RIP-enabled neighbor devices learn the routing table from each other.  Port: Enable RIP on the specified port. All the IP addresses of this port are added to the RIP routing table, and the device and its RIP-enabled neighbor devices learn the routing table from each other.
Network Segment	Enter the IPv6 address and prefix length when <b>Type</b> is set to <b>Network Segment</b> .  RIPng will be enabled on all interfaces of the device covered by this network segment.
Port	Select a VLAN interface or physical port when <b>Type</b> is set to <b>Port</b> .

#### 11.4.2 Configuring the RIPng Port


RIPng poison reverse: After the port learns the route, the route overhead is set to **16** (indicating that the route is unreachable), and the route is sent back to the neighbor from the original port to avoid a loop.

Choose Local Device > Routing > RIPng Settings > Port Settings, click Edit, and enable IPv6 poison reverse.



## 11.4.3 Configuring the RIPng Global Configuration

Choose Local Device > Routing > RIPng Settings > Advanced > RIPng Global Config, and click Edit Config.






Table 11-8 RIPng Global Configuration Parameters

Parameter	Description
Route Advertisement	After route advertisement is enabled, the current device generates a default route and sends it to the neighbor.
Administrative Distance	Redistribute routes of other protocols to the RIP domain so that RIP can interwork with other routing domains.
Update Timer	RIP update cycle. The routing information is updated every 30 seconds by default.
Invalid Timer	If no update is received before a route becomes invalid, the route is considered unreachable. The default value is 180 seconds.
Flush Timer	If no update is received before the flush timer of an invalid route expires, the route is completely deleted from the RIP routing table. The default value is 120 seconds.

# 11.4.4 Configuring the RIPng Route Redistribution List

Redistribute routes of other protocols to the RIPng domain to interwork with other routing domains.

Choose Local Device > Routing > RIPng Settings > Advanced > Route Redistribution List, and click + Add.





Table 11-9 RIP Route Redistribution Parameters

Parameter	Description
	Direct Routing
Туре	OSPF Routing
	Static Routing
Administrative Distance	Value range: 0-16. The default value is <b>0</b> .

#### 11.4.5 Configuring the RIPng Passive Interface

If an interface is configured as a passive interface, it will suppress RIPng update packets. If the connected peer device does not run RIP, you are advised to enable the passive interface.


Choose Local Device > Routing > RIPng Settings > Advanced > Passive Interface, click Add, and enter the IP address of the neighbor router.





#### 11.4.6 Configuring the RIPng Aggregate Route

Choose Local Device > Routing > RIP Settings > Advanced > RIPng Aggregate Routing, click Add, and enter the IPv6 address and prefix length (value range: 0–128).



#### 11.5 OSPFv2




This feature is supported only on the RG-NBS5200 series switches

Open Shortest Path First (OSPF) can be applied to large-scale networks. IPv4 uses OSPFv2, and IPv6 uses OSPFv3.


OSPF is a typical link-state routing protocol, which can solve the problems of slow route update, inaccurate measurement, and poor scalability in large networks. It is suitable for networks of various sizes, and even a network with up to thousands of devices.

# 11.5.1 Configuring OSPFv2 Basic Parameters

Choose **Local Device** > **Routing** > **OSPFv2**, click **Start Setup**, and then configure an instance and an interface respectively.



(1) Configure an instance.



**Table 11-10 Instance Configuration Parameters** 

Parameter	Description
Instance ID	Create an OSPF instance based on the service type.
	The instance only takes effect locally, and does not affect packet exchange with other devices.
	It identifies a router in an OSPF domain.
Router ID	⚠ Caution
	Router IDs within the same domain must be unique. The same
	configuration may cause neighbor discovery failures.
	Generate a default route and send it to the neighbor.
	After this function is enabled, you need to enter the metric and select a type.
Advertise Default Route	The default metric is 1.
	Type 1: The metrics displayed on different routers vary.
	Type 2: The metrics displayed on all routers are the same.
	Redistribute routes of other protocols to the OSPF domain to interwork with
	other routing domains.
	If Static Route Redistribution is selected, enter the metric, which is 20 by
Import External Route	default.
	If Direct Route Redistribution is selected, enter the metric, which is 20 by
	default.
	If RIP Redistribution is selected, enter the metric, which is 20 by default.
Details	Expand the detailed configuration.





Table 11-11 Parameters in the Instance Detailed Configuration

Parameter	Description
Distance	It is used for protocol selection. By default, the intra-area, inter-area, and external distances are all <b>110</b> .
LSA	Frequent network changes and route flapping may occupy too much network bandwidth and device resources. The LSA generation and reception delays are specified in OSPF by default.  The default value is 1000 ms.
SPF Calculation	When the link state database (LSDB) changes, OSPF recalculates the shortest path, and sets the interval to prevent frequent network changes from occupying a large number of resources  Waiting Interval: When the state changes, the timer is triggered. The delay is calculated for the first time after the timer expires. The default value is 0 ms.  Min Interval: As the number of changes increases, the time of each interval will increase according to the algorithm, and the default value is 50 ms.  Max Interval: When the calculated interval reaches the maximum interval, the subsequent interval is always equal to the maximum interval. If the time from the last calculation exceeds the maximum interval and the LSDB is not updated, the timer is
Graceful Restart	disabled.  Graceful Restart (GR) can avoid route flapping caused by traffic interruption and

Parameter	Description
	active/standby board switchover, thus ensuring the stability of key services.
	Graceful Restart Helper: The Graceful Restart Helper function is enabled when this
	switch is turned on.
	LSA Check: LSA packets outside the domain are checked when this switch is turned
	on.
	Max Wait Time: Timing starts after the device receives the GR packet from the peer
	device. If the peer device does not complete GR within Max Wait Time, the device exits
	the GR Helper mode. The default value is 1800 seconds.

## (2) Configure an interface.



**Table 11-12 Interface Configuration Parameters** 

Parameter	Description
Interface	Select the OSPF-enabled Layer 3 interface.
Area	Configure the area ID. Value range: 0-4294967295
Stub Area	If <b>Stub Area</b> is enabled, you need to configure the area type and inter-area route isolation.  Stub area: Routers at the edge of the area do not advertise routes outside the area, and the routing table in the area is small.  Not-So-Stubby Area (NSSA): A few external routes can be imported.  Inter-area route isolation: After this function is enabled, inter-area routes will not be imported to this area.
Details	Expand the detailed configuration.





Table 11-13 Parameters in the Interface Detailed Configuration

Parameter	Description
Priority	It is 1 by default.
	Broadcast
Network Type	Unicast
Network Type	Multicast
	Non-Broadcast Multiple Access
Hello Packets	Interval for periodic transmission, which is used to discover and maintain OSPF neighbor relationship. The default value is 10 seconds.
Dead Interval	Time after which the neighbor becomes invalid. The default value is 40 seconds.
LSA Transmission Delay	LSA transmission delay of the interface. The default value is 1 second.
LSA Retransmission Interval	Time after which LSA is retransmitted after LSA is lost. The default value is 5 seconds.

Parameter	Description
	No Auth: The protocol packets are not authenticated. It is the default value.
Interface Auth	Plain Text: The protocol packets are authenticated, and the authentication key is transmitted with the protocol packets in the form of plain text.  MD5: The protocol packets are authenticated, and the authentication key is MD5 encrypted and then transmitted with the protocol packets.
Ignore MTU Check	Enabled by default.


#### (3) Complete the configuration.


After completing the configuration, you can choose **Local Device** > **Routing** > **OSPFv2** and view the instance list.



## 11.5.2 Adding an OSPFv2 Interface


Choose Local Device > Routing > OSPFv2, click More in the Action column, and select V2 Interface.






# 11.5.3 Redistributing OSPFv2 Instance Routes


Choose Local Device > Routing > OSPFv2, click More in the Action column, and select V2 Instance Route Redistribution.






## 11.5.4 Managing OSPFv2 Neighbors

Choose Local Device > Routing > OSPFv2, click More in the Action column, and select V2 Neighbor Management.



## 11.5.5 Viewing OSPFv2 Neighbor Information

Choose Local Device > Routing > OSPFv2, and click Neighbor Info in the Action column.



#### 11.6 OSPFv3




This feature is supported only on the RG-NBS5200 series switches


Open Shortest Path First (OSPF) can be applied to large-scale networks. IPv4 uses OSPFv2, and IPv6 uses OSPFv3.

## 11.6.1 Configuring OSPFv3 Basic Parameters

Choose **Local Device** > **Routing** > **OSPFv3**, click **Start Setup**, and then configure an instance and an interface respectively.

(1) Configure an instance.





**Table 11-14 Instance Configuration Parameters** 

Parameter	Description
Router ID	It identifies a router in an OSPF domain.
	Caution  Router IDs within the same domain must be unique. The same configuration may cause neighbor discovery failures.
	Generate a default route and send it to the neighbor.
Advertise Default Route	After this function is enabled, you need to enter the metric and select a type.  The default metric is 1.
	Type 1: The metrics displayed on different routers vary.
	Type 2: The metrics displayed on all routers are the same.
	Redistribute routes of other protocols to the OSPF domain to interwork with other routing domains.
Import External Route	If Static Route Redistribution is selected, enter the metric, which is 20 by default.
	If <b>Direct Route Redistribution</b> is selected, enter the metric, which is <b>20</b> by default.
	If RIP Redistribution is selected, enter the metric, which is 20 by default.
Details	Expand the detailed configuration.





Table 11-15 Parameters in the Instance Detailed Configuration

Parameter	Description
Distance	It is used for protocol selection. By default, the intra-area, inter-area, and external distances are all <b>110</b> .
LSA	Frequent network changes and route flapping may occupy too much network bandwidth and device resources. The LSA generation and reception delays are specified in OSPF by default.  The default value is 1000 ms.
SPF Calculation	When the link state database (LSDB) changes, OSPF recalculates the shortest path, and sets the interval to prevent frequent network changes from occupying a large number of resources
	Waiting Interval: When the state changes, the timer is triggered. The delay is calculated for the first time after the timer expires. The default value is 0 ms.
	<b>Min Interval</b> : As the number of changes increases, the time of each interval will increase according to the algorithm, and the default value is 50 ms.
	<b>Max Interval</b> : When the calculated interval reaches the maximum interval, the subsequent interval is always equal to the maximum interval. If the time from the last calculation exceeds the maximum interval and the LSDB is not updated, the timer is disabled.
Graceful Restart	Graceful Restart (GR) can avoid route flapping caused by traffic interruption and

Parameter	Description
	active/standby board switchover, thus ensuring the stability of key services.
	Graceful Restart Helper: The Graceful Restart Helper function is enabled when this switch is turned on.
	LSA Check: LSA packets outside the domain are checked when this switch is turned on.
	Max Wait Time: Timing starts after the device receives the GR packet from the peer device. If the peer device does not complete GR within Max Wait Time, the device exits the GR Helper mode. The default value is 1800 seconds.

#### (2) Configure an interface.



**Table 11-16 Interface Configuration Parameters** 

Description
Select the OSPF-enabled Layer 3 interface.
Configure the area ID. Value range: 0-4294967295
If <b>Stub Area</b> is enabled, you need to configure the area type and inter-area route isolation.
Stub area: Routers at the edge of the area do not advertise routes outside the area, and the routing table in the area is small.  Not-So-Stubby Area (NSSA): A few external routes can be imported.
Expand the detailed configuration.





Table 11-17 Parameters in the Interface Detailed Configuration

Parameter	Description
Priority	It is 1 by default.
	Broadcast
Network Type	Unicast
Network Type	Multicast
	Non-Broadcast Multiple Access
Hello Packets	Interval for periodic transmission, which is used to discover and maintain
Tiello Fackets	OSPF neighbor relationship. The default value is 10 seconds.
Dead Interval	Time after which the neighbor becomes invalid. The default value is 40
	seconds.
LSA Transmission Delay	LSA transmission delay of the interface. The default value is 1 second.
LSA Retransmission Interval	Time after which LSA is retransmitted after LSA is lost. The default value is 5
	seconds.
	No auth:default without verification.
	MD5 auth: Verifies the protocol message. The authentication secret key is
Header Certification	encrypted through MD5 and transmitted together with the protocol message.
	SHA1 auth: Verifies the protocol message. The authentication secret key is
	encrypted through SHA1 and transmitted together with the protocol
	message.

Parameter	Description
	SHA256 auth: Verifies the protocol message. The authentication secret key is encrypted through SHA256 and transmitted together with the protocol message.  After selecting MD5, SHA1, or SHA256 authentication, you need to enter Kid and Key. Among them, Kid is the key identifier, and Key is the actual secret key used.
Tail Certification	No auth:default without verification.  MD5 auth: Verifies the protocol message. The authentication secret key is encrypted through MD5 and transmitted together with the protocol message.  SHA256 auth: Verifies the protocol message. The authentication secret key is encrypted through SHA256 and transmitted together with the protocol message.  After selecting MD5, SHA1, or SHA256 authentication, you need to enter Kid and Key. Among them, Kid is the key identifier, and Key is the actual secret key used.
Interface Auth	No Auth: The protocol packets are not authenticated. It is the default value.  Plain Text: The protocol packets are authenticated, and the authentication key is transmitted with the protocol packets in the form of plain text.  MD5: The protocol packets are authenticated, and the authentication key is MD5 encrypted and then transmitted with the protocol packets.
Ignore MTU Check	Enabled by default.


(3) Complete the configuration.




After completing the configuration, you can choose **Local Device** > **Routing** > **OSPFv**3 and view the instance list.

# 11.6.2 Adding an OSPFv3 Interface


Choose Local Device > Routing > OSPFv3, click More in the Action column, and select V3 Interface.





## 11.6.3 Viewing OSPFv3 Neighbor Information

Choose Local Device > Routing > OSPFv3, and click Neighbor Info in the Action column.




# 11.7 Routing Table Info



This feature is supported only on the RG-NBS5200 series switches


## 11.7.1 IPv4 Route Info

Choose Local Device > Routing > Route Info > IPv4, you can view IPv4 routing table details.



## 11.7.2 IPv6 Route Info

Choose Local Device > Routing > Route Info > IPv6, you can view IPv6 routing table details.



# 12 Viewing Optical Transceiver Info




#### **Specification**

The information depends on the actual product.

Choose Local Device > Optical Transceiver Monitoring > Optical Transceiver Info.

The **Optical Transceiver Info** page displays the basic information of an optical transceiver, including the port to which it is connected, DDM, temperature, voltage, current, Tx power, local Rx power, and so on. You can query the information of an optical transceiver by entering the port to which it is connected in the search box.

The data on this page is automatically updated every 5 seconds. You can also click **Refresh** to refresh the optical transceiver information.



# 13 Security

# 13.1 DHCP Snooping

#### 13.1.1 Overview

The Dynamic Host Configuration Protocol (DHCP) snooping function allows a device to snoop DHCP packets exchanged between clients and a server to record and monitor the IP address usage and filter out invalid DHCP packets, including request packets from the clients and response packets from the server. DHCP snooping records generated user data entries to serve security applications such as IP Source Guard.

#### 13.1.2 Standalone Device Configuration

Choose Local Device > Security > DHCP Snooping.


Turn on the DHCP snooping function, select the port to be set as trusted ports on the port panel and click **Save**. After DHCP Snooping is enabled, request packets from DHCP clients are forwarded only to trusted ports; for response packets from DHCP servers, only those from trusted ports are forwarded.



Note

Generally, the uplink port connected to the DHCP server is configured as a trusted port.

Option 82 is used to enhance the DHCP server security and optimize the IP address assignment policy. Option 82 information will be carried in the DHCP request packet when Option 82 is turned on.




## 13.1.3 Batch Configuring Network Switches

Choose Network-Wide > Workspace > Wired > DHCP Snooping.

Enabling DHCP Snooping on network switches can ensure that users can only obtain network configuration parameters from the DHCP server within the control range, and avoid a host on the original network obtaining an IP address assigned by an unauthorized router, so as to guarantee the stability of the network.

(1) Click Enable to access the DHCP Snooping Config page.




(2) In the networking topology, you can select the access switches on which you want to enable DHCP Snooping in either recommended or custom mode. If you select the recommended mode, all switches in the network are selected automatically. If you select the custom mode, you can manually select the desired switches. Click **Deliver Config.** DHCP Snooping is enabled on the selected switches.



(3) After the configuration is delivered, if you need to modify the effective range of the anti-private connection function, click **Configure** to reselect the switch that enables the anti-private connection in the topology. After the configuration is delivered, if you want to modify the effective range of the DHCP Snooping function, click

**Configure** to select desired switches in the topology again. Turn off **DHCP Snooping** to disable DHCP Snooping on all switches with one click.



#### 13.2 Storm Control

#### 13.2.1 Overview

When a local area network (LAN) has excess broadcast, multicast, or unknown unicast data flows, the network speed will slow down and packet transmission will have an increased timeout probability. This is called LAN storm, which may be caused by topology protocol execution errors or incorrect network configuration.

Users can perform storm control separately for the broadcast, multicast, and unknown unicast data flows. When the rate of broadcast, multicast, or unknown unicast data flows received over a device port exceeds the specified range, the device transmits only packets in the specified range and discards packets beyond the range until the packet rate falls within the range. This prevents flooded data from entering the LAN and causing a storm.

#### 13.2.2 Procedure

Choose Local Device > Security > Storm Control.


Click **Batch Edit**. In the displayed dialog box, select configuration types and ports, enter the rate limits of broadcast, unknown multicast, and unknown unicast, and click **OK**. To modify or delete the rate limit rules after completing the configuration, you can click **Edit** or **Delete** in the **Action** column.

There are two configuration types:

Storm control based on packets per second: If the rate of data flows received over a device port exceeds the
configured packets-per-second threshold, excess data flows are discarded until the rate falls within the

threshold.

Storm control based on kilobytes per second: If the rate of data flows received over a device port exceeds
the configured kilobytes-per-second threshold, excess data flows are discarded until the rate falls within the
threshold.



#### 13.3 ACL

#### 13.3.1 Overview

An access control list (ACL) is commonly referred to as packet filter in some documents. An ACL defines a series of permit or deny rules and applies these rules to device interfaces to control packets sent to and from the interfaces, so as to enhance security of the network device.


You can add ACLs based on MAC addresses or IP addresses and bind ACLs to ports.

#### 13.3.2 Creating ACL Rules

Choose Local Device > Security > ACL > ACL List.

- (1) Click Add to set the ACL control type, enter an ACL name, and click OK.
  - o Based on MAC address: To control the Layer 2 packets entering/leaving the port, and deny or permit specific Layer 2 packets destined to a network.
  - o Based on IP address: To control the IP packets entering/leaving a port, and deny or permit specific IP

packets destined to a network.



(2) Click **Details** in the **Action** column of the ACL entry, set the filtering rules in the pop-up sidebar, and click **Save** to add rules for the ACL. Multiple rules can be added.

The rules include two actions of **Allow** or **Block**, and the matching rules of packets. The sequence of a Rule in an ACL determines the matching priority of the Rule in the ACL. When processing packets, the network device matches packets with ACEs based on the Rule sequence numbers. Click **Move** in the rule list to adjust the matching order.




Table 13-1 Description of ACL Rule Configuration Parameters

Parameter	Description
	Configuring ACL Rules Action
ACL	Block: If packets match this rule, the packets are denied.
	Allow: If packets match this rule, the packets are permitted.
IP Protocol Number	Match IP protocol number The value ranges from 0 to 255. Check <b>All</b> to match all IP protocols.
Src IP Address	Match the source IP address of the packet. Check <b>All</b> to match all source IP addresses.
Dest IP Address	Match the destination IP address of the packet. Check <b>All</b> to match all destination IP addresses
EtherType Value	Match Ethernet protocol type. The value range is 0x600~0xFFFF. Check <b>All</b> to match all protocol type numbers.
Src Mac	Match the MAC address of the source host. Check <b>All</b> to match all source MAC addresses
Dest MAC	Match the MAC address of the destination host. Check <b>All</b> to match all destination MAC addresses

# Note

- ACLs cannot have the same name. Only the name of a created ACL can be edited.
- An ACL applied by a port cannot be edited or deleted. To edit, unbind the ACL from the port first.
- There is one default ACL rule that denies all packets hidden at the end of an ACL.

## 13.3.3 Applying ACL Rules


Choose Local Device > Security > ACL > ACL List.

Click Batch Add or Edit in the Action column, select the desired MAC ACL and IP ACL for ports, and click OK.




#### Note

Currently, ACLs can be applied only in the inbound direction of ports, that is, to filter incoming packets.




After an ACL is applied to a port, you can click **Unbind** in the **Action** column, or check the port entry and click **Unbind Selected** to unbind the ACL from the port.




# 13.4 Port Protection

Choose Local Device > Security > Port Protection.



In some scenarios, it is required that communication be disabled between some ports on the device. For this purpose, you can configure some ports as protected ports. Ports that enable port protection (protected ports) cannot communicate with each other, users on different ports are Layer 2-isolated. The protected ports can communicate with non-protected ports.

Port protection is disabled by default, which can be enabled by clicking to batch enable port protection for multiple ports, you can click **Batch Edit** to enable port protection, select desired port and click **OK.** 



# 13.5 IP-MAC Binding

#### 13.5.1 Overview

After IP-MAC binding is configured on a port, to improve security, the device checks whether the source IP addresses and source MAC addresses of IP packets are those configured for the device, filters out IP packets not matching the binding, and strictly control the validity of input sources.

#### 13.5.2 Procedure

Choose Local Device > Security > IP-MAC Binding.


#### 1. Adding an IP-MAC Binding Entry

Click **Add**, select the desired port, enter the IP address and MAC address to be bound, and click **OK**. At least one of the IP address and MAC address needs to be entered. To modify the binding, you can click **Edit** in the **Action** column.




#### Caution

IP-MAC Binding take effects prior to ACL, but it has the same privilege with IP Source Guard. The packet matching either configuration will be allowed to pass through.




#### 2. Searching Binding Entries

The search box in the upper-right corner supports finding binding entries based on IP addresses, MAC addresses or ports. Select the search type, enter the search string, and click **Search**. Entries that meet the search criteria are displayed in the list.



#### 3. Deleting an IP-MAC Binding Entry

- Batch Configure: In IP-MAC Binding List, select an entry to be deleted and click Delete Selected. In the displayed dialog box, click OK.
- Delete one binding entry: click **Delete** in the last **Action** column of the entry in the list. In the displayed dialog box, click **OK**.



# 13.6 IP Source Guard

# 13.6.1 Overview

After the IP Source Guard function is enabled, the device checks IP packets from DHCP non-trusted ports. You can configure the device to check only the IP field or IP+MAC field to filter out IP packets not matching the binding list. It can prevent users from setting private IP addresses and forging IP packets.



# Caution

IP Source Guard should be enabled together with DHCP snooping. Otherwise, IP packet forwarding may be affected. To configure DHCP Snooping function, see <a href="13.1">13.1</a> DHCP Snooping for details.

# 13.6.2 Enabling Port IP Source Guard

Choose Local Device > Security > IP Source Guard > Port Settings.

In Port List, click Edit in the Action column. Select Enabled and select the match rule, and click OK.

There are two match rules:


 IP address: The source IP addresses of all IP packets passing through the port are checked. Packets are allowed to pass through the port only when the source IP addresses of these packets match those in the binding list.


IP address+ MAC address: The source IP addresses and MAC addresses of IP packets passing through the port are checked. Packets are allowed to pass through the port only when both the Layer 2 source MAC addresses and Layer 3 source IP addresses of these packets match an entry in the binding list.



#### Caution

- IP Source Guard cannot be enabled on a DHCP Snooping trusted port.
- Only on a Layer 2 interface can IP Source Guard be enabled.





# 13.6.3 Configuring Exceptional VLAN Addresses

Choose Local Device > Security > IP Source Guard > Excluded VLAN.


When IP Source Guard is enabled on an interface, it is effective to all the virtual local area networks (VLANs) under the interface by default. Users can specify excluded VLANs, within which IP packets are not checked or filtered, that is, such IP packets are not controlled by IP Source Guard.

Click **Edit**, enter the Excluded VLAN ID and the desired port, and click **OK**.



#### Caution

Excluded VLANs can be specified on a port only after IP Source Guard is enabled on the port. Specified excluded VLANs will be deleted automatically when IP Source Guard is disabled on the port.




# 13.6.4 Viewing Binding List


Choose Local Device > Security > IP Source Guard > Binding List.

The binding list is the basis for IP Source Guard. Currently, data in **Binding List** is sourced from dynamic learning results of DHCP snooping binding database. When IP Source Guard is enabled, data of the DHCP Snooping binding database is synchronized to the binding list of IP Source Guard. In this case, IP packets are filtered strictly through IP Source Guard on devices with DHCP Snooping enabled.

Click Refresh to obtain the latest data in Binding List.



The search box in the upper-right corner supports finding the specified entry in **Binding List** based on IP addresses, MAC addresses, VLANs or ports. Click the drop-down list box to select the search type, enter the search string, and click **Search**.



# 13.7 Configure 802.1X authentication

#### 13.7.1 Function Introduction

#### 1. Overview of IEEE 802.1X Authentication

IEEE 802.1X, an IEEE standard for port-based network access control (PNAC), provides protected authentication for a secure access to LANs. Its main purpose is to determine port availability. When the authentication succeeds, IEEE 802.1X enables the port. Otherwise, the port is disabled.

On a traditional IEEE 802-compliant LAN, users can access network resources without authentication, posing security risks. This is where IEEE 802.1X comes in.

Compared with traditional access methods, IEEE 802.1X has the following advantages:

- Security and reliability: IEEE 802.1X authentication is performed on a user or device before they
  access the switch or LAN services. Data can pass through the Ethernet ports only after the
  authentication succeeds.
- User identification: Identity authentication prevents unauthorized users and devices from accessing LANs and WLANs, and records their login and logout time.
- Simple and efficient quality: IEEE 802.1X uses Ethernet technology to retain the connectionless nature of IP networks, reducing unnecessary overhead and redundancy.

IEEE 802.1X provides authentication, authorization, and accounting (AAA) security applications.

- Authentication: Determines whether a user can access network resources and denies unauthorized users.
- o Authorization: Authorizes users to access resources, and controls the permissions of authorized users.
- o Accounting: Records network resources used by users for subsequent accounting.

IEEE 802.1X can be deployed on networks to control user access, authenticate users, and authorize services.




RG-NBS series switches only support authentication.

#### 2. IEEE 802.1X authentication architecture

IEEE 802.1X has a typical client-server model that consists of three entities: client, network access device, and authentication server, as shown in <u>Figure 13-1 Typical IEEE 802.1X Architecture</u>. The access control, as well as authenticating and authorizing a client device can be implemented only when all three entities participate in the IEEE 802.1X authentication.

Figure 13-1 Typical IEEE 802.1X Architecture



Authentication client: Indicates a client device that connects to a network and initiates access
authentication, such as PCs. Users need to enable the IEEE 802.1X authentication clients on their devices
and enter the necessary usernames and passwords to trigger authentication. Common authentication
clients include the IEEE 802.1X authentication client software embedded in Windows, macOS, and Linux
operating systems.

- Access device: Indicates an IEEE 802.1X-capable network device, which can be switches in most cases.
  The access device provides network access for an authentication client and serves as the intermediary
  between the authentication client and the authentication server. The access device interworks with a client
  through the Extensible Authentication Protocol over LAN (EAPOL) protocol and with a server through the
  Remote Authentication Dial in User Service (RADIUS) protocol.
- Authentication server: Verifies the identity information (such as the username and password) sent by a
  client to determine whether the client has permission to access network services. The authentication server
  performs client authorization and accounting based on network requirements. Open-source FreeRADIUS
  and Ruijie SMP are typically used to provide authentication services.

#### 3. IEEE 802.1X Dynamic VLAN Assignment

IEEE 802.1X dynamic VLAN assignment means that the authentication server can specify the VLAN ID of an authenticated user. IEEE 802.1X dynamic VLAN assignment allocates a VLAN ID to the user during authentication, and automatically adds them to the corresponding VLAN after successful authentication. VLAN IDs can be allocated to different users.



#### Note

The dynamic VLAN IDs on the RG-NBS series devices must be created in advance.

#### 13.7.2 Configuration 802.1X

#### 1. Adding a Server

Choose Local Device > Security > 802.1X Authentication > RADIUS Server Management > RADIUS Server Management.

Before configuration, please confirm:

- The Radius server is fully built and configured as follows.
  - o Add username and password for client login.
  - o Close the firewall, otherwise the authentication message may be intercepted, resulting in authentication failure.
  - o A trusted IP on the Radius server.
- The network connection between the authentication device and the Radius server.
- IP addresses of the Radius server and the authentication device have been obtained.

Click Add Server Group, configure server group parameters, and click Save.




Table 13-2 Parameters of Adding a Server Group

parameter	Description
Server group name	Name of a server group. You can add multiple servers to a group. If a server with a higher priority does not respond to the request of a client, other servers in the group will perform the response according to the matching sequence.
	Note To use this function, enable server detection. For details, see 13.7.2 2. Setting up the Server.
Server IP	Radius server address.

parameter	Description
Server Name	Name of a Radius server.
Auth Port	The port number used for accessing user authentication on the Radius server.
Accounting Port	The port number used to access the accounting process on the Radius server.
Shared Password	Radius server shared key.
Match Order  The system supports adding up to 5 Radius servers. The higher matching order value is, the higher the priority is.	

# 2. Setting up the Server

Choose Local Device > Security > 802.1X Authentication > RADIUS Server Management > Server global configuration.




Table 13-3 Description of Configuring Global Server Group Parameters


Parameter	Description
Packet Retransmission Interval	Configure the interval for the device to send request packets before confirming that there is no response from RADIUS
Packet Retransmission Count	Configure the number of times the device sends request packets before confirming that there is no response from RADIUS
Server Detection	If this function is enabled, you need to set "Server Detection Period", "Server Detection Times" and "Server Detection Username". It is used to determine the status of the server, so as to decide whether to enable functions such as escape.
MAC Address Format	Configure the MAC address format of RADIUS attribute No. 31 (Calling-

Parameter	Description
	Stationg-ID).
	The following formats are supported:
	Dotted hexadecimal format, such as 00d0.f8aa.bbcc
	IETF format, such as 00-D0-F8-AA-BB-CC
	No format (default), e.g. 00d0f8aabbcc


# 3. Enabling the IEEE 802.1X Authentication

Choose Local Device > Security > 802.1X Authentication > Auth Config.

(1) Toggle on Global 802.1X, the system prompts to confirm whether to enable it, click OK.



(2) Select a server group. If no server group is created, click **Edit** to go to the **RADIUS Server Management** page and add a server group. For details, see 13.7.2 1. Adding a Server.



(3) Click Advanced Settings to configure parameters such as Guest VLAN.




Table 13-4 Description of Parameters in the Advanced IEEE 802.1X Settings

parameter	Description	
Server Escape	If the server disconnection is detected, all users will be allowed to access the Internet	
Re-authentication	Require clients to re-authenticate at certain intervals to ensure network security	
Guest VLAN	Provide a VLAN for unauthenticated clients to restrict their access	
EAP-Request Packet Retransmission Count		
Quiet Period	During the authentication process, the idle time between the client and the server does not exchange authentication messages, value range: 0-65535 seconds	
Client Packet Timeout Duration	The time limit for the server to wait for the response from the client.  Exceeding this time will be regarded as an authentication failure. Value range: 1-65535 seconds	
Client Packet Timeout Duration  The time limit for the client to wait for the server to respond, except this time will be considered as an authentication failure, value rates 65535 seconds		

parameter	Description
EAP-Request Packet Interval	Define the time interval between sending EAP request messages to control the rate of the authentication process, value range: 1-65535 seconds

# 4. Configuring the Effective Interface

Choose Local Device > Security > 802.1X Authentication > Port.

Click **Edit** for an individual interface or **Batch Config** to edit authentication parameters for interfaces.




Table 13-5 Description of Port Configuration Parameters


Parameter	Description	
802.1X Authentication	When enabled, the selected interface will enable 8.02.1x authentication.	
	<ul> <li>disable: Turn off the authentication method, which has the same effect as turning off the 802.1X authentication switch</li> </ul>	
	force-auth: Mandatory authentication, the client can directly access the     Internet without a password	
Auth Method	force-unauth: force no authentication, the client cannot authenticate and cannot access the Internet	
	auto: automatic authentication, the device needs to be authenticated, and can access the Internet after passing the authentication	
	It is recommended to select the auto authentication method.	

Parameter	Description		
	multi-auth: Supports multiple devices using the same port for authentication, but each device needs to be authenticated independently		
Auth Mode	<ul> <li>multi-host: Multiple devices are allowed to share the same port. As long as one user passes the authentication, subsequent users can access the Internet</li> </ul>		
	single-host: Each port only allows one device to be authenticated, and can access the Internet after successful authentication		
	When enabled, devices that fail authentication will be dynamically assigned to the specified Guest VLAN		
Guest Vlan	▲ Caution		
	You need to create a VLAN ID first and apply it to the interface, then in		
	Security > 802.1X Authentication > Auth Config > Advanced Settings in the authentication configuration enable Guest VLAN and enter the ID.		
	Limit the number of users under the interface		
	i Note		
User Count Limit per	The maximum number of users supported by an RG-NBS3100 series		
Port	switch and its single port both ranges from 1 to 256 users. The maximum		
	number of users supported by other series switches and their single ports both ranges from 1 to 1000 users.		

# 13.7.3 View the list of wired authentication users

8.02.1x function is configured on the entire network and a terminal is authenticated and connected to the network, you can view the list of authenticated users.

Choose Local Device > Security > 802.1X Authentication > Wired User List to obtain specific user information.



Click **Refresh** to get the latest user list information.

If you want to disconnect a certain user from the network, you can select the user and click **Offline** in the "Operation" column; you can also select multiple users and click **Batch Offline**.

# 13.8 Anti-ARP Spoofing

# 13.8.1 Overview

Gateway-targeted ARP spoofing prevention is used to check whether the source IP address of an ARP packet through an access port is set to the gateway IP address. If yes, the packet will be discarded to prevent hosts from receiving wrong ARP response packets. If not, the packet will not be handled. In this way, only the uplink devices can send ARP packets, and the ARP response packets sent from other clients which pass for the gateway are filtered out.

# 13.8.2 Procedure


Choose Local Device > Security > Anti-ARP Spoofing.


#### 1. Enabling Anti-ARP Spoofing

Click **Add**, select the desired port and enter the gateway IP, click **OK**.



Generally, the anti-ARP spoofing function is enabled on the downlink ports of the device.






# 2. Disabling Anti-ARP Spoofing

Batch disable: Select an entry to be deleted in the list and click **Delete Selected**.

Disable one port: click **Delete** in the last **Action** column of the corresponding entry.



# **14** Advanced Configuration

# 14.1 STP

The RG-NBS series switches support the following spanning tree modes:

- Spanning Tree Protocol (STP) is a Layer 2 management protocol that eliminates Layer 2 loops by selectively blocking redundant links over the network and provides the link backup function.
- Building on STP, Rapid Spanning Tree Protocol (RSTP) achieves fast convergence of network topology.
   However, like STP, MSTP also has the defect that all VLANs share one spanning tree and load sharing cannot be achieved.
- Multiple Spanning Tree Protocol (MSTP) can overcome the previous defect. It can achieve fast convergence and forward traffic of different VLANs along their respective paths, thereby providing a better load balancing mechanism for redundant links.

# 14.1.1 STP Global Settings

Choose Local Device > Advanced > STP > STP Settings.


#### 1. STP Global Configurations

(1) Click to enable the STP function, and click OK in the displayed box. The STP function is disabled by default.

#### A

#### Caution

- After enabling the STP configuration of the device, the ERPS configuration cannot take effect normally.
- Enabling the STP or changing the STP mode will initiate a new session. Do not refresh the page during the configuration.



(2) Configure the STP global parameters, and click Save.




Table 14-1 Description of STP Global Configuration Parameters

Parameter	Description	Default Value
STP	Whether to enable the STP function. It takes effect globally. STP attributes can be configured only after STP is enabled.	Disable
Priority	Bridge priority. The device compares the bridge priority first during root bridge selection. A smaller value indicates a higher priority.	32768
Hello Time	Interval for sending two adjacent BPDUs	2 seconds
Max Age	The maximum expiration time of BPDUs The packets expiring will be discarded. If a non-root bridge fails to receive a BPDU from the root bridge before the aging time expires, the root bridge or the link to the root bridge is deemed as faulty	20 seconds
Forward Delay	The interval at which the port status changes, that is, the interval for the port to change from Listening to Learning, or from Learning to Forwarding.	15 seconds
Recovery Time	Network recovery time when redundant links occur on the network.	30 seconds
STP Mode	The versions of Spanning Tree Protocol. Currently the device supports STP (Spanning Tree Protocol), RSTP (Rapid Spanning Tree Protocol) and MSTP (Multiple Spanning Tree Protocol).	RSTP
Bridge ID	STP identifies a switch by a bridge ID, which consists of the bridge priority and bridge MAC address.	NA
Root Bridge ID	As the root node of an STP tree, the root bridge is identified by the root bridge ID and functions as the logical center of the entire Layer 2 network.	NA
Root Port	A root port exists on a non-root bridge and has the smallest path cost to the root bridge. Each non-root bridge has only one root port.	NA

# 2. Applying STP to a Port

Choose Local Device > Advanced > STP > STP Settings.

Configure the STP properties for a port. Click **Batch Edit** to select ports and configure STP parameters, or click **Edit** in the **Action** column in **Port List** to configure designated ports.




Table 14-2 Description of STP Configuration Parameters of Ports

Parameter	Description	Default Value
Role	Root: A port with the shortest path to the root	
	Alternate: A backup port of a root port. Once the root port fails, the alternate port becomes the root port immediately.	NA NA
	Designated (designated ports): A port that connects a root bridge or an upstream bridge to a downstream device.	INA
	Disable (blocked ports): Ports that have no effect in the spanning tree.	

Parameter	Description	Default Value
	<ul> <li>Disable: The port is closed manually or due to a fault, does not participate in spanning tree and does not forward data, and can be turned into a blocking state after initialization or opening.</li> <li>Blocking: A port in the blocking state cannot forward data packets or learn addresses, but can send or receive configuration BPDUs and send</li> </ul>	
Status	<ul> <li>them to the CPU.</li> <li>Listening: If a port can become the root port or designated port, the port will enter the listening state. Listening: A port in the listening state does not forward data or learn addresses, but can receive and send configuration BPDUs.</li> </ul>	NA
	<ul> <li>Learning: A port in the learning state cannot forward data, but starts to learn addresses, and can receive, process, and send configuration BPDUs.</li> </ul>	
	Forwarding: Once a port enters the state, it can forward any data, learn addresses, and receive, process, and send configuration BPDUs.	
Priority	The priority of the port is used to elect the port role, and the port with high priority is preferentially selected to enter the forwarding state	128
Port Cost Attribute	It can be set to Auto or Manual:  Auto: The port cost is automatically calculated based on the port rate.  Manual: The configured value is used as the port cost.	Auto
Port Cost Path Cost	Actual path cost.	NA
Link Status Config Status	Configure the link type, the options include: Shared, Point-to-Point and Auto. In auto mode, the interface type is determined based on the duplex mode. For full-duplex ports, the interface type is point-to-point, and for half-duplex ports, the interface type is shared.	Auto
Link Status Actual Status	Actual link type: Shared, Point-to-Point	NA
BPDU Guard	Whether to enable the BPDU guard function. After the function is enabled, if Port Fast is enabled on a port or the port is automatically identified as an edge port connected to an endpoint, but the port receives BPDUs, the port will be disabled and enters the Error-disabled state. This indicates that an unauthorized user may add a network device to the network, resulting in network topology change.	Disable

Parameter	Description	Default Value
Port Fast	Whether to enable the Port Fast function. After Port Fast is enabled on a port, the port will neither receive nor send BPDUs. In this case, the host directly connected to the port cannot receive BPDU.s. If a port, on which Port Fast is enabled exits the Port Fast state automatically when it receives BPDUs, the BPDU filter feature is automatically disabled.  Generally, the port connected to a PC is enabled with Port Fast.	Disable

# Note

- It is recommended to enable Port Fast on the port connected to a PC.
- A port switches to the forwarding state after STP is enabled more than 30 seconds. Therefore transient disconnection may occur and packets cannot be forwarded.

# 14.1.2 MSTP Settings

Choose Local Device > Advanced > STP > MSTP Settings.

# 1. MSTP Global Configurations

The MSTP configuration takes effect only when STP Mode in STP global configurations is set to MSTP.



**Table 14-3 Description of Parameters in MSTP Global Configurations** 

Parameter	Description	Default Value
MST Region Name	Name of an MST region. The name is an identifier, ranging from 1 to 32 characters, and distinguishes different MST regions.	NA
Revision Number	Revision level of an MST region, which is used to distinguish different MST regions.	0
Max. Hop Count	Maximum hops of BPDU packets in an MST region. It also refers to the maximum hops from the root bridge to other bridges or terminal devices.	20


# 2. Applying MSTP

Click Edit in the Action column of a specified instance, set Priority and VLAN List, and click OK.




#### Note

If you want to add multiple VLAN IDs, separate them with commas (,). If you attempt to add consecutive VLANs, separate them with a hyphen (-), for example, 14-15.



The bridge ID, root bridge ID, and root port number of the instance can be displayed in the list only after the VLAN ID is added.




# 0


# Note

If a device acts as the root bridge, it has no root port, and no port number is displayed in the **Root Port** column.

Click the drop-down button before an instance to display the corresponding port configuration.



Click **Edit** in the **Action** column to modify the port priority and cost.



# 14.2 LLDP


#### 14.2.1 Overview

LLDP (Link Layer Discovery Protocol) is defined by IEEE 802.1AB. LLDP can discover devices and detect topology changes. With LLDP, the web interface can learn the topological connection status, for example, ports of the device that are connected to other devices, port rates at both ends of a link, and duplex mode matching status. An administrator can locate and troubleshoot faults quickly based on the preceding information.

# 14.2.2 LLDP Global Settings

Choose Local Device > Advanced > LLDP > LLDP Settings.

(1) Click to enable the LLDP function, and click **OK** in the displayed box. The STP function is enabled by default. When the LLDP is enabled, this step can be skipped.



(2) Configure the global LLDP parameters and click Save.



Table 14-4 Description of LLDP Global Configuration Parameters

Parameter	Description	Default Value
LLDP	Indicates whether the LLDP function is enabled.	Enable
Hold Multiplier	TTL multiplier of LLDP  In LLDP packets, TTL TLV indicates the TTL of local information on a neighbor. The value of TTL TLV is calculated using the following formula: TTL TLV = TTL multiplier × Packet transmission interval + 1.  The TTL TLV value can be modified by configuring the TTL multiplier and LLDP packet transmission interval.	4
Transmit Interval	Transmission interval of LLDP packets, in seconds  The value of TTL TLV is calculated using the following formula: TTL  TLV = TTL multiplier × Packet transmission interval + 1. The TTL TLV  value can be modified by configuring the TTL multiplier and LLDP  packet transmission interval.	30 seconds


Parameter	Description	Default Value	
	Number of packets that are transmitted rapidly		
	When a new neighbor is discovered, or the LLDP working mode is		
	changed, the device will start the fast transmission mechanism in		
	order to let the neighboring devices learn the information of the		
Fast Count	device as soon as possible. The fast transmission mechanism	3	
	shortens the LLDP packet transmission interval to 1s, sends a certain		
	number of LLDP packets continuously, and then restores the normal		
	transmission interval. You can configure the number of LLDP packets		
	that can be transmitted rapidly for the fast transmission mechanism.		
Reinitialization	Port initialization delay, in seconds You can configure an initialization		
Delay	delay to prevent frequent initialization of the state machine caused by	2 seconds	
Delay	frequent changes of the port work mode.		
	Delay for sending LLDP packets, in seconds.		
	When local information of a device changes, the device immediately		
	transmits LLDP packets to its neighbors. You can configure a		
	transmission delay to prevent frequent transmission of LLDP packets		
Forward Delay	caused by frequent changes of local information.	2 seconds	
Torward Boldy	If the delay is set to a very small value, frequent change of the local		
	information will cause frequent transmission of LLDP packets. If the		
	delay is set to a very large value, no LLDP packet may be transmitted		
	even if local information is changed. Set an appropriate delay		
	according to actual conditions.		


# 14.2.3 Applying LLDP to a Port

Choose Local Device > Advanced > LLDP > LLDP Management.

In **Port List**, Click **Edit** in the **Action** column, or click **Batch Edit**, select the desired port, configure the LLDP working mode on the port and whether to enable LLDP-MED, and click **OK**.

- Send LLDPDU: After Send LLDPDU is enabled on a port, the port can send LLDPDUs.
- Receive LLDPDU: After Receive LLDPDU is enabled on a port, the port can receive LLDPDUs.
- **LLDPMED**: After **LLDPMED** is enabled, the device is capable of discovering neighbors when its peer endpoint supports LLDP-MED (the Link Layer Discovery Protocol-Media Endpoint Discovery).





# 14.2.4 Displaying LLDP information

Choose Local Device > Advanced > LLDP > LLDP Info.

To display LLDP information, including the LLDP information of the local device and the neighbor devices of each port. Click the port name to display details about port neighbors.

You can check the topology connection through LLDP information, or use LLDP to detect errors. For example, if two switch devices are directly connected in the network topology. When an administrator configures the VLAN, port rate, duplex mode, an error will be prompted if the configurations do not match those on the connected neighbor.





# 14.3 RLDP

# 14.3.1 Overview

The Rapid Link Detection Protocol (RLDP) is an Ethernet link failure detection protocol, which is used to rapidly detect unidirectional link failures, bidirectional link failures, and downlink loop failures. When a failure is found, RLDP automatically shuts down relevant ports or asks users to manually shut down the ports according to the configured failure handling methods, to avoid wrong forwarding of traffic or Ethernet Layer 2 loops.

Supports enabling the RLDP function of the access switches in the network in a batch. By default, the switch ports will be automatically shut down when a loop occurs. You can also set a single switch to configure whether loop detection is enabled on each port and the handling methods after a link fault is detected

# 14.3.2 Standalone Device Configuration

#### 1. RLDP Global Settings

Choose Local Device > Advanced > RLDP > RLDP Settings.

(1) Enable the RLDP function and click **OK** in the displayed dialog box. The RLDP function is disabled by default.



(2) Configure RLDP global parameters and click Save.




Table 14-5 Description of RLDP Global Configuration Parameters

Parameter	Description	Default Value
RLDP	Indicates whether the RLDP function is enabled.	Disable
Hello Interval	Interval for RLDP to send detection packets, in seconds	3 seconds
Errdisable Recovery	After it is enabled, a port automatically recovers to the initialized state after a loop occurs.	Disable
Errdisable Recovery Interval	The interval at which the failed ports recover to the initialized state regularly and link detection is restarted, in seconds.	30 seconds

#### 2. Applying RLDP to a Port

Choose Local Device > Advanced > RLDP > RLDP Management.


In **Port List**, click **Edit** in the Action column or click **Batch Edit**, select the desired port, configure whether to enable loop detection on the port and the handling method after a fault is detected, and click **OK**.

There are three methods to handle port failures:

- Warning: Only the relevant information is prompted to indicate the failed port and the failure type.
- Block: After alerting the fault, set the faulty port not to forward the received packets
- Shutdown port: After alerting the fault, shutdown the port.

#### Caution


- When RLDP is applied to an aggregate interface, the **Action** can only be set to **Warning** and **Shutdown**.
- When performing RLDP detection on an aggregate interface, if detection packets are received on the same device, even if the VLANs of the port sending the packets and the port receiving them are different, it will not be judged as a loop failure.



# 3. Displaying RLDP information

Choose Local Device > Advanced > RLDP > RLDP Info.

You can view the detection status, failure handling methods, and ports that connect the neighbor device to the local device. You can click **Reset** to restore the faulty RLDP status triggered by a port to the normal state.




# 14.3.3 Batch Configuring Network Switches


Choose Network-Wide > Workspace > Wired > RLDP

(1) Click **Enable** to access the **RLDP Config** page.


Configuration Guide Advanced Configuration



(2) In the networking topology, you can select the access switches on which you want to enable RLDP in either recommended or custom mode. If you select the recommended mode, all access switches in the network are selected automatically. If you select the custom mode, you can manually select the desired access switches. Click **Deliver Config**. RLDP is enabled on the selected switches.



(3) After the configuration is delivered, if you want to modify the effective range of the RLDP function, click Configure to select desired switches in the topology again. Turn off RLDP to disable RLDP on all the switches with one click.



# 14.4 ERPS



#### Note

This feature is supported only on the RG-NBS3100 and RG-NBS3200 series switches.

#### 14.4.1 Overview

Ethernet Ring Protection Switching (ERPS), also known as G.8032, is a ring protection protocol developed by the International Telecommunication Union (ITU). It is a data link layer protocol specially designed for Ethernet rings. ERPS prevents broadcast storms caused by data loops when an Ethernet ring network is intact, and can rapidly perform link switching and recover the communication between nodes when a link is disconnected in the Ethernet ring, so as to implement data link redundancy.

Currently, the Spanning Tree Protocol (STP) is another solution to the Layer 2 network loop problem. STP is at mature application stage but requires a relatively long (within seconds) convergence time. Compared with STP, ERPS provides faster convergence, with the Layer 2 convergence time less than 50 ms.

#### 14.4.2 Control VLAN and Data VLAN

ERPS supports two types of virtual local area networks (VLANs): control VLANs and data VLANs.

Control VLAN: Also known as the Ring Auto Protection Switching VLAN (R-APS VLAN) for transmitting ERPS

protocol packets. On a device, the ports connecting to an ERPS ring belong to a control VLAN, and only such ports can be added to a control VLAN.

 Data VLAN: A data VLAN is used to transmit data packets. Both ERPS ports and non-ERPS ports can be assigned to a data VLAN. A data VLAN is also known as a protected VLAN.


# 14.4.3 Basic Model of an Ethernet Ring

A group of interconnected devices in the same control VLAN (R-APS VLAN) constitute an Ethernet ring (ERPS ring), in which each device is called a node. ERPS rings can be classified into major rings and subrings based on whether a ring is closed.

#### 1. Major Ring and Subring

- Major ring and major ring link: A major ring is a topology of a closed network connected in a ring, such as the blue rings shown in <u>Figure 14-1</u>. In an ERPS ring, links that belong to and are controlled by a major ring are called major ring links.
- Subring and subring link: A subring is a topology of a non-closed network attached to a major ring, such as
  the green ring shown in <u>Figure 14-1</u>. In an ERPS ring, links that belong to and are controlled by a subring
  are called subring links.
- R-APS virtual channel of a subring: As shown in Figure 14-1, all the links on the major ring can be regarded
  as R-APS virtual channels of subrings, which are used to forward subring protocol packets. They belong to
  the major ring instead of the subring. The major ring must associate with the control VLAN of the subring and
  allow packets from this VLAN to pass through.

Figure 14-1 Basic Topologies of Ethernet Rings



# 2. Basic Topologies

Major rings, subrings, and nodes can form basic topologies with different characteristics, depending on the connection modes, as shown in <u>Figure 14-1</u>.

- Single ring: Major ring ERPS 1 (node 1-2-3-4) constitutes a single-ring topology.
- Tangent rings: A topology in which two ERPS rings share one device is called tangent rings. Major ring ERPS
   2 (node 5-6-7) and major ring ERPS 3 (node 7-8-9) constitute a tangent-ring topology, and are tangent to each other on one node, namely, node 7.
- Intersecting rings: A topology in which two ERPS rings share two devices is called intersecting rings. Major ring ERPS 4 (node 13-10-11-12) and subring ERPS 5 (node 13-15-14-12) constitute an intersecting-ring topology, and intersect on two directly connected intersecting nodes, namely, node 13 and node 12.

In practice, a network is a combination of multiple basic topologies, with multiple major rings and multiple subrings.

#### 3. Node

According to the different topological relationships between nodes and Ethernet rings, nodes are classified into single-ring nodes, tangent nodes, and intersecting nodes by role.

- Single-ring node: In an Ethernet ring, the nodes that belong to only one Ethernet ring (either major ring or subring) are called single-ring nodes. Two interfaces need to be provided on a single-ring node so that the node can be added to one ERPS ring. As shown in <a href="Figure 14-1">Figure 14-1</a>, nodes 1-4 in the single-ring topology, nodes 5, 6, 8, and 9 in the tangent-ring topology, and nodes 10, 11, 14, and 15 in the intersecting-ring topology are all single-ring nodes.
- Tangent node: A device shared in tangent rings is called a tangent node. Four interfaces need to be provided
  on each tangent node, with two added to a major ring and the other two added to another major ring. As
  shown in <u>Figure 14-1</u>, node 7 in the tangent-ring topology is a tangent node.
- Intersecting node: The nodes in intersecting rings that belong to multiple rings are called intersecting nodes. Three interfaces need to be provided on a tangent node, with two added to a major ring and the other added to a subring. As shown in <a href="Figure 14-1">Figure 14-1</a>, nodes 12 and 13 in the intersecting-ring topology are intersecting nodes. ERPS rings can intersect with other multiple ERPS rings and share links to implement data link redundancy. Services can be quickly switched from a failed link in one ERPS ring to a normal link.

#### 4. Ring Member Port

An Ethernet ring has two ring member ports on each node that it passes through: the **west** and **east** ports. As shown in Figure 14-1:

- If an ERPS ring is a closed major ring, each node that the ring passes through has two interfaces used as the **west** and **east** ports for adding the node to the ERPS ring. For example, on node 7, GigabitEthernet 0/1 and 0/2 are added to the major ring ERPS 2, and GigabitEthernet 0/3 and 0/4 are added to the major ring ERPS 3. On node 13, GigabitEthernet 0/5 and 0/6 are added to the major ring ERPS 4.
- If an ERPS ring is a non-closed subring (in an intersecting-ring topology), a non-intersecting node has two interfaces used as the west and east ports for adding the node to the ERPS subring, such as node 15. On an intersecting node, only one physical port is added to the ERPS subring as a ring member port, and the other ring member port is a virtual channel (indicated by virtual-channel). For example, on node 13, only GigabitEthernet 0/7 is added to the subring ERPS 5.

There are two states for a port running the ERPS protocol: forwarding and block. Their functions are listed in Table 14-6.

Table 14-6 ERPS Protocol Port States

Port State	Receiving Protocol Packets	Sending Protocol Packets	Address Learning	Receiving Data Packets	Sending Data Packets
Block	Yes	Yes	No	No	No
Forwarding	Yes	Yes	Yes	Yes	Yes

#### 14.4.4 RPL and Nodes

An Ethernet ring can be in either of the following two states regardless of whether it is a major ring or subring:

- Idle state: The physical links in the entire ring network are connected.
- **Protection** state: A physical link in the ring network is disconnected.


Ring protection link (RPL): When the physical links in a ring network are connected, the ERPS ring is in the idle state, and the links in the logic blocking state are RPLs. Each Ethernet ring has only one RPL. For example, the links indicated by the orange lines shown in <u>Figure 14-2</u> are RPLs, the link between node 3 and node 4 is the RPL of the Ethernet ring ERPS 1 (node 1-2-3-4), and the link between node 5 and node 6 is the RPL of the Ethernet ring ERPS 2 (node 3-5-6).

A node that is adjacent to an RPL and is used to block the RPL to prevent loops when the Ethernet ring is free of faults is called an RPL **owner** node. As shown in <u>Figure 14-2</u>, node 4 is the RPL owner node of the Ethernet ring ERPS 1 (node 1-2-3-4) and node 6 is the RPL owner node of the ERPS 2 (node 3-5-6).

Any nodes other than the RPL owner node in an Ethernet ring are non-RPL owner nodes. As shown in <u>Figure 14-2</u>, nodes except node 4 and node 6 are non-RPL owner nodes of the rings.


Blocked ports on RPLs are RPL ports, and RPL ports do not forward data packets to prevent loops. RPL ports are on RPL owner nodes, and the RPL owner nodes block the RPL ports. Each Ethernet ring has only one RPL owner node.

Figure 14-2 Typical Topology of Tangent Rings



As shown in <u>Figure 14-2</u>, the link between node 3 and node 4 is the RPL of the Ethernet ring ERPS 1. As the RPL owner node of ERPS 1, node 4 blocks the RPL port. The link between node 5 and node 6 is the RPL of the Ethernet ring ERPS 2. As the RPL owner node of ERPS 2, node 6 blocks the RPL port. ERPS 1 (node 1-2-3-4) and ERPS 2 (node 3-5-6) share node 3, forming a tangent-ring topology. Node 3 is the tangent node.

Figure 14-3 Typical Topology of Intersecting Rings



As shown in Figure 14-3, ERPS 1 (node 1-2-3-4) is a major ring, and ERPS 2 (node 3-4-5) is a subring. ERPS 1 and ERPS 2 share node 3 and node 4, forming an intersecting-ring topology. The links between node 4 and node 5, and between node 3 and node 5 are links of the subring ERPS 2 and are controlled by ERPS 2. The link between node 3 and node 4 belongs to the major ring not the subring, and is not controlled by the subring. However, the protocol packets of the subring are transmitted through the direct link between node 3 and node 4. This direct link is the R-APS virtual channel of the subring ERPS 2. Node 2 only belongs to the major ring ERPS 1, and is called a single-ring node. Node 6 only belongs to the subring ERPS 3, and is also called a single-ring node. Node 3 and node 4 are tangent nodes.

#### 14.4.5 ERPS Packet

ERPS packets (also called R-APS packets) are classified into Signal Fail (SF) packets, No Request (NR) packets, No Requests-RPL Blocked (NR-RB) packets, and Flush packets.

- SF packet: When the link of a node is down, the node sends an SF packet to notify other nodes of its link failure.
- NR packet: When the failed link is restored, the node sends an NR packet to notify the RPL owner node of its link recovery.
- NR-RB packet: When all nodes in an ERPS ring function properly, the RPL owner node sends NR-RB packets periodically.
- Flush packet: In intersecting rings, when a topology change occurs in a subring, the intersecting nodes send
  flush packets to notify other devices in the Ethernet ring to which the subring is connected.

#### 14.4.6 ERPS Timer

ERPS supports three timers: Holdoff timer, Guard timer, and Wait-To-Restore (WTR) timer.

- **Holdoff** timer: The timer is used to minimize frequent ERPS topology switching due to intermittent link failures. After you configure the Holdoff timer, ERPS performs topology switching only if the link failure still persists after the timer times out.
- Guard timer: The timer is used to prevent a device from receiving expired R-APS PMDU packets. When a

device detects that a link failure is cleared, it sends link recovery packets and starts the **Guard** timer. Before the timer expires, all packets except Flush packets indicating a subring topology change will be discarded.

WTR timer: The timer is effective only for RPL owner nodes. It is used to avoid ring status misjudgment by the RPL owner node. When an RPL owner node detects that a failure is cleared, it will not perform topology switching immediately but only if the Ethernet ring is recovered after the WTR timer times out. If a ring failure is detected again before the timer expires, the RPL owner node cancels the timer and does not perform topology switching.

# 14.4.7 Ring Protection

The ring protection function prevents broadcast storms caused by data loops and can rapidly recover the communication between nodes when a link is disconnected in the Ethernet ring.

#### Normal state

- o All nodes in the physical topology are connected in ring mode.
- ERPS blocks the RPL to prevent loops.
- o ERPS detects failures on each link between adjacent nodes.

#### Link fault

A node adjacent to a failed node detects the fault.

The node adjacent to the failed link blocks the failed link and sends SF packets to notify other nodes in the same ring.

An SF packet triggers the RPL owner node to enable the RPL port, and also triggers all nodes to update their MAC address entries and ARP/ND entries and enter the protection state.

# Link recovery

When a failed link is restored, an adjacent node still blocks the link and sends NR packets indicating that no local fault exists.

When the RPL owner node receives the first NR packet, it starts the WTR timer.

When the WTR timer times out, the RPL owner node blocks the RPL and sends an NR-RB packet.

After receiving this NR-RB packet, other nodes update their MAC address entries and ARP/ND entries, and the node that sends the NR packet stops sending the NR packet and enables the blocked ports.

o The ring network is restored to the normal state.


#### 14.4.8 Protocols and Standards

ITU-T G.8032/Y.1344: Ethernet ring protection switching

# 14.4.9 Configuring ERPS


# 1. Adding and Deleting an ERPS Ring

Choose Local Device > Advanced > ERPS



- (1) Click Add on the ERPS Ring List page.
- (2) As shown in Figure 14-4, configure the parameters on the page based on the service requirements.

Figure 14-4 Adding an ERPS Ring




**Table 14-7 Parameter Description** 

Parameter	Description	Default Value
ID	Specifies the ID of an ERPS instance.	N/A
Control VLAN	It is used to forward ERPS protocol packets.	N/A
Туре	Indicates the type of the ERPS ring. The ring can be a major ring or a sub ring.	N/A
West Port/Role	Specifies the west port in the ERPS ring and its role. The values of a port role include:  NORMAL: Indicates a normal node.  RPL OWNER: Indicates an RPL owner node.  RPL NEIGHBOR: Indicates an RPL neighbor node.	N/A
East Port/Role	Specifies the east port in the ERPS ring and its role.  The values of a port role include:  NORMAL: Indicates a normal node.  RPL OWNER: Indicates an RPL owner node.  RPL NEIGHBOR: Indicates an RPL neighbor node.	N/A
Sub Ring VLAN	Specifies the control VLAN of a sub ring.	N/A
WTR Timer	Specifies the interval of the WTR timer.	5 min
Guard Timer	Specifies the interval of the Guard timer.	500 ms
Hold-off Timer	Specifies the interval of the Hold-off timer.	0 ms, indicating a topology switch is performed immediately after a link failure is detected.
MEL Level	Indicates the maintenance entity group (MEG) level. The MEL level of devices in the same ERPS ring must be consistent.	7
Revertive Mode	When this switch is toggled on, once the condition causing a switch has cleared, traffic is blocked on the RPL.	Enabled.

(3) (Optional) As shown in Figure 14-5, select existing ERPS rings, and then click **Delete Selected** to delete selected ERPS rings.

Figure 14-5 Deleting Selected ERPS Rings




### 2. Link Switch

Choose Local Device > Advanced > ERPS

- (1) Click Link Switch on the ERPS Ring List page.
- (2) As shown in Figure 14-6, configure the parameters on the page based on the service requirements.

Figure 14-6 Link Switch



**Table 14-8 Parameter Description** 


Parameter	Description	Default Value
ID	Specifies the ID of an ERPS instance.	N/A
Port	Specifies the port in the ERPS ring. The values include West Port and East Port.	N/A
	Specifies the link state of the selected port. The values include Clear and Block.	
Link State	<ul> <li>Clear: Indicates that the port is blocked by a forced switch operation.</li> </ul>	N/A
	<ul> <li>Block: Indicates that the port is blocked by a manual switch operation.</li> </ul>	

# 14.4.10 ERPS Typical Configuration Examples

# 1. Requirements

There are three devices on the user's network that need to form an ERPS ring. The specific topology is shown below.

# 2. Topology



### 3. Notes

To prevent loops, configure ERPS before performing cable connections.


For an ERPS ring, only one interface can be the RPL Owner, and its peer interface must be the RPL Neighbor.

# 4. Procedure


(1) Choose Network-Wide > Workspace > Wired > ERPS Ring to access the ERPS Ring configuration page.



(2) Click +Add on the page to add an ERPS ring.




(3) As shown in the following figure, set the ERPS ring parameters (only **ID** and **Control VLAN** are mandatory, and should be configured according to the user's network setup. Other parameters can be left at their default values). Then, click **Next**.




Configuration Guide Advanced Configuration


(4) As shown in the following figure, select a device for the ERPS ring, set the Gi5 to RPL OWNER, and Gi6 to NORMAL. Click Next.




(5) As shown in the following figure, click **Save** to save the configuration.




(6) As shown in the following figure, choose **Network-Wide** > **Workspace** > **Wired** > **ERPS Ring**. On the page that opens, click **Edit**.




(7) As shown in the following figure, click Next to access the ERPS Ring Configuration page.



(8) As shown in the following figure, add the remaining devices on the ERPS Ring Configuration page. Select the optical ports on the devices and configure the interfaces connected to the RPL OWNER as RPL NEIGHBOR, following the example of Gi52 in the figure below. Configure other interfaces as NORMAL. After completing the configuration, click Next.



(9) As shown in the following figure, click **Save** to apply all configurations.



(10) As shown in the figure below, after all cables are connected according to the topology, the devices will automatically form an ERPS ring.



# 14.5 QoS

### 14.5.1 Overview

Quality of service (QoS) can meet users' requirements for different applications and different levels of service quality. It allocates and schedules resources based on users' requirements and provides different levels of service quality for different packets.

On a traditional IP network, a device treats all the packets in the same way, in which the device processes packets based on their arrival time according to the queuing strategy of first in first out (FIFO), and transmits the packets to the destination on a best-effort basis. When the network bandwidth is abundant, all the packets are properly processed; when the network is congested, all the packets may be discarded.

QoS assigns a transmission priority to the packets of a type to highlight the importance of the packets. Then, the devices provide special transmission services for these packets according to forwarding policies for different priorities, congestion avoidance, and other mechanisms. With QoS, a device processes real-time and important packets preferentially, processes non-real-time and common packets with lower priorities and even discards the packets upon network congestion.

QoS enhances the network performance predictability, effectively allocates network bandwidth, and reasonably utilizes network resources.

# 14.5.2 Principles

### 1. Basic Concepts

# DiffServ model

The differentiated services (DiffServ) model classifies all packets transmitted on a network into different types. The classification information related to QoS priority marking is recorded in some fields of Layer 2 or Layer 3 packets, for example, the PRI field of IEEE 802.1Q frames, type of service (ToS) field of IPv4 packets,


traffic class (TC) field of IPv6 packets, and the MPLS experimental bits (EXP) field of multiprotocol label switching (MPLS) packets.

In the network of DiffServ model, the classification information of packets can be assigned by hosts or other network devices or based on different application policies or different packet contents. A device applies the same transmission service policy to packets containing the same classification information and applies different transmission service policies to packets containing different classification information. Based on the classification information carried by packets, a device may provide different transmission priorities for different packets, reserve bandwidth for a kind of packets, discard certain packets with lower priorities, or take some other actions.

### PRI field of the IEEE 802.1q frames


The PRI field of IEEE 802.1Q frames (namely, the IEEE 802.1p priority) is located in the header of a Layer 2 packet containing an IEEE 802.1Q tag header, as shown in <u>Figure 14-7</u>.

Figure 14-7 Format of a Layer 2 Frame with an IEEE 802.1Q Tag Header



The 4-byte IEEE 802.1Q tag header contains the 2-byte tag protocol identifier (TPID) and 2-byte tag control information (TCI). TCI contains the 3-bit PRI field, as shown in <u>Figure 14-8</u>.

Figure 14-8 PRI Field of the IEEE 802.1q Frames




The PRI field represents eight priorities for packet transmission, and the priority values from high to low are 7, 6, ..., 1, and 0. The IEEE 802.1p priority is applicable to scenarios where Layer 3 headers do not need to be analyzed and QoS needs to be implemented only at Layer 2.

### ToS field of the IPv4 packets

IPv4 packets use the ToS field in the IP header to indicate the priority of the packets, as shown in <u>Figure 14-9</u>.

Figure 14-9 ToS Field in the IP Header




The ToS field contains eight bits, of which the first three bits are the IP PRE (precedence) field and represent eight priorities for packet transmission, with the priority values from high to low being 7, 6, ..., 1, and 0.

RFC 2474 redefines the ToS field of the IP header, in which the first 6 bits (bits 0 to 5) represent the differentiated services code point (DSCP). DSCP is used to classify packets into a maximum of 64 different categories.

ToS field of the IPv6 packets

IPv6 packets use the TC field in the IPv6 header to indicate the packet priority, as shown in Figure 14-10.

Figure 14-10 TC Field in the IPv6 Header



The TC field contains eight bits and provides the same function as the ToS field of IPv4 packets. The first six bits of the TC field indicate DSCP.

### 2. Priority Mapping

Priorities are used to identify the scheduling weights or forwarding priority of packets. Different priority types are defined for different packet types: IEEE 802.1q frames use the IEEE 802.1p priority, IP packets use the DSCP, and so on.

After a packet enters a device interface, the packet priority is mapped to the CoS according to the trust mode configured for the interface. <u>Table 14-9</u> shows the mappings between trust mode configured for an interface and the priorities.

Table 14-9 Interface Trust Mode and Priority Mapping

Trust Mode	Priority Mapping	
	The device does not trust any priority information carried in the packet.	
	<ul> <li>A packet received by the interface is assigned to a queue based on the 802.1p-queue mapping table using the 802.1p value (interface priority) configured for the interface.</li> </ul>	
Untrusted	• For a packet with a VLAN tag sent by the interface, the device re-marks the 802.1p value of the packet based on the queue-802.1p mapping table.	
	<ul> <li>For a packet without a VLAN tag sent by the interface, the device does not re-mark the 802.1p value of the packet.</li> </ul>	
	If the packet sent by the interface is an IP packet, the device re-marks the DSCP value of the packet based on the queue-DSCP mapping table.	
	After an interface receives a packet:	
	o If the packet carries a VLAN tag, the 802.1p value carried by the packet will be used as the input for mapping, and the packet will be assigned to a queue based on the 802.1p-queue mapping table.	
802.1p	<ul> <li>If the packet does not carry any VLAN tag, it will be processed by the device in the same way as that in untrusted mode.</li> </ul>	
	<ul> <li>For a packet with a VLAN tag sent by the interface, the device re-marks the 802.1p value of the packet based on the queue-802.1p mapping table.</li> </ul>	
	<ul> <li>For a packet without a VLAN tag sent by the interface, the device does not re-mark the 802.1p value of the packet.</li> </ul>	
	If the packet sent by the interface is an IP packet, the device re-marks the DSCP value of the packet based on the queue-DSCP mapping table.	
	After an interface receives a packet:	
	<ul> <li>If the packet is not an IP packet, it will be processed by the device in the same way as that in 802.1p mode.</li> </ul>	
DSCP	<ul> <li>If the packet is an IP packet, the DSCP value of the packet will be used as the input for mapping, and the packet will be assigned to a queue based on the DSCP-queue mapping table.</li> </ul>	
	If the packet sent by the interface is an IP packet, the device re-marks the DSCP value of the packet based on the queue-DSCP mapping table.	
	If the packet sent by the interface is not an IP packet, the packet is processed depending on whether it carries a VLAN tag:	
	<ul> <li>If the packet carries a VLAN tag, the device re-marks the 802.1p value of the packets based on the queue-802.1p mapping table.</li> </ul>	
	<ul> <li>If the packet does not carry a VLAN tag, the device does not re-mark the 802.1p value of the packet.</li> </ul>	

# 3. Congestion Management

When the receiving rate of packets exceeds the sending rate, congestion occurs on the sending interface. If no sufficient buffer is provided to store these packets, packet loss may occur. The congestion management mechanism determines the sending order of packets based on their local priorities. The congestion management function controls congestion and improves the local priorities of packets for some important data. When congestion occurs, the packets of higher priorities are sent first to ensure that key services are provided in time.

Congestion management adopts the queue scheduling mechanism. The processing is as follows:

- (1) Each packet is assigned to a queue based on priority-to-queue mappings.
- (2) The outbound interface selects the packets in a queue for sending according to various queue scheduling policies (such as SP, WRR, and SP+WRR).

### SP scheduling policy

In strict-priority (SP) scheduling, packets are scheduled strictly based on their queue priorities from high to low (a larger queue ID indicates a higher priority). Before sending a packet, check whether there is a packet to be sent in a high-priority queue. If there is, send it. If not, check whether there is a packet to be sent in the next-level queue, and so on.

The weakness of SP scheduling is that, when congestion occurs, if the packets in a higher priority queue exist for a long time, the packets in a lower priority queue have no opportunity of being scheduled.

### WRR scheduling policy

Weighted Round Robin (WRR) ensures that all queues are scheduled in turn. Taking eight output queues as an example, the device allocates bandwidth resources based on the weight of each queue. For example, if the WRR weights of a 1000 Mbps port are set to 50, 50, 30, 30, 10, 10, 10, and 10, WRR ensures that at least 50 Mbps of bandwidth is allocated to the queue with the lowest priority. WRR also allows for efficient use of bandwidth by immediately switching to the next queue when a queue is empty.

### SP+WRR scheduling policy

SP scheduling is configured for one or more sending queues, and the other queues are scheduled in the WRR mode. Among SP queues, only after all the packets in an SP queue with a higher priority are sent, can the packets in an SP queue with a next higher priority be sent. Among SP and WRR queues, only after the packets in all SP queues are sent, can the packets in WRR queues be sent.

# 14.5.3 Configuring QoS


### 1. Global Configuration

In local device mode, choose Advanced > QoS > Global Config.

In the **Global Config** page, you can configure the trust mode, modify the 802.1p-Queue Mapping Table for inbound packets, modify the DSCP-Queue Mapping Table for inbound packets, modify the Queue-802.1p Mapping Table for outbound packets, and modify the Queue-DSCP Mapping Table for outbound packets.

Click Batch Config to batch configure these mapping tables.

Click Reset to restore a mapping table to default values.



**Table 14-10 Global Configuration Parameter Description** 

Parameter	Description	Default Value
	Priority designations of an inbound packet:  Untrusted Mode: The device does not trust any priority information carried in the packet, and uses the interface priority as the 802.1p value of the packet. The device assigns the packet into a queue based on the 802.1p-queue mapping table. If Untrusted Mode is selected, any packets received by any interface on the device will be assigned to queues based on the interface priority regardless of the trust mode status configured in the Port Settings page.	
Trusted Mode	802.1p: The device trusts the 802.1p value carried in the packet, and use the 802.1p value to assign the packet to a queue based on the 802.1p-queue mapping table. If the packet does not carry an 802.1p value, that is, the packet does not carry a VLAN tag, the device will process the packet in the same way as that in untrusted mode. If 802.1p is selected, and the designated interface is in untrusted mode in the Port Settings page, the device will process the packet in the same way as that in untrusted mode.	Untrusted Mode
	<b>802.1p-DSCP</b> : The device trusts the 802.1p value (for non-IP packets) or DSCP value (for IP packets) of the packet, and assigns the packet to a queue based on the 802.1p-queue mapping table or the DSCP-queue mapping table depending on the 802.1p value or DSCP value of the packet. If <b>802.1p-DSCP</b> is selected, and the designated interface is in untrusted mode in the <b>Port Settings</b> page, the device will process the packet in the same way as that in untrusted mode.	
802.1p-Queue Mapping Table	An input queue mapping table, which contains the mappings between the 802.1p value and the queue ID. For example, if the 802.1p value is 0, and the queue ID is 1, packets with the 802.1p value 0 will be assigned to queue 1.	As shown in <u>Table</u> 14-11
DSCP-Queue Mapping Table	An input queue mapping table, which contains the mappings between the DSCP value and the queue ID. For example, if the DSCP value falls within 0 to 7, and the queue ID is 0, packets with a DSCP value between 0 and 7 will be assigned to queue 0.	As shown in <u>Table</u> 14-12
Queue-802.1p Mapping Table	An output queue mapping table, which contains the mappings between the queue ID and the 802.1p value. The 802.1p value of an outgoing packet in a queue is re-marked based on the mapping. For example, if the queue ID is 0, and the packets carrying a VLAN tag in queue 0 have an 802.1p value, then the 802.1p value of the packets in queue 0 are re-marked to 2. If a packet does not carry any 802.1p value, that is, the packet does not carry any VLAN tag, the device does not re-mark the 802.1p value of the packet.	As shown in <u>Table</u> 14-13

Parameter	Description	Default Value
Queue-DSCP Mapping Table	An output queue mapping table, which contains the mappings between the queue ID and the DSCP value. The DSCP value of packets in the output queue is re-marked based on the mapping. For example, if the queue ID is 0, and the mapped DSCP value is 8, then the DSCP value of packets in queue 0 is re-marked to 8.	As shown in <u>Table</u> 14-14

Table 14-11 Default 802.1p-Queue Mapping Table of the Device

802.1p Value	Queue ID
0	0
1	1
2	2
3	3
4	4
5	5
6	6
7	7

Table 14-12 Default DSCP-Queue Mapping Table of the Device

DSCP Value	Queue ID
0–7	0
8–15	1
16–23	2
24–31	3
32–39	4
40–47	5
48–55	6
56–63	7

Table 14-13 Default Queue-802.1p Mapping Table of the Device

Queue ID	802.1p Value After Remarking
0	0
1	1
2	2
3	3
4	4
5	5
6	6
7	7


Table 14-14 Default Queue-DSCP Mapping Table of the Device

Queue ID	DSCP Value After Re-marking
0	0
1	8
2	16
3	24
4	32
5	40
6	48
7	56

# 2. Port Settings

In local device mode, choose Advanced > QoS > Port Settings.

In the **Port Settings** page, you can set the priority, trust mode, 802.1p remarking, DSCP remarking, queue algorithm, and queue ID/weight for a designated interface.



**Table 14-15 Port Configuration Parameter Description** 

Parameter	Description	Default Value
Priority	Interface priority. When the device is in untrusted mode, packets are assigned to a queue based on this priority, which is equivalent to the 802.1p value of a packet.	0
Trusted Mode	Priority designations of an inbound packet:  Disable: The device does not trust any priority information carried in the packet, and uses the interface priority as the 802.1p value of the packet. The device assigns the packet into a queue based on the 802.1p-queue mapping table.  Enable: The device trusts the 802.1p value (for non-IP packets) or DSCP value (for IP packets) of the packet, and assigns the packet to a queue based on the 802.1p-queue mapping table or the DSCP-queue mapping table depending on the 802.1p value or DSCP value of the packet.  If Untrusted Mode is selected in the Global Config page, any packets received by any interface on the device will be assigned to queues based on the interface priority regardless of the trust mode status configured in the Port Settings page.  If 802.1p or 802.1p-DSCP is selected in the Global Config page, the device will only process packets received by the specified interface in the same way as that in trusted mode when the Trusted Mode of the designated interface is set to Enable in the Port Settings page.	Disable

Parameter	Description	Default Value
802.1p Remarking	Enable: The 802.1p value of packets in the queue is re-marked based on the Queue-802.1p Mapping Table.  Disable: The device does not re-mark the 802.1p value of packets in the queue based on the Queue-802.1p Mapping Table, and marks the priority of the outgoing packets based on the priority of the input queue.	Enable
DSCP Remarking	Enable: The DSCP value of packets in the queue is re-marked based on the DSCP-802.1p Mapping Table.  Disable: The device does not re-mark the DSCP value of packets in the queue based on the Queue-802.1p Mapping Table, and marks the priority of the outgoing packets based on the priority of the input queue.	Enable
Queue Algorithm	The queue algorithm adopted by the interface.	SP+WRR
Queue ID/Weight	WRR weight of a queue. The value 0 indicates that the SP algorithm is adopted for the queue. After all packets in all SP queues are sent, the device will send packets in WRR queues. Among SP queues, the queue with a larger ID is scheduled first.	As shown in <u>Table</u> 14-16

Table 14-16 Default Interface Queue ID/Weight of the Device

Queue ID	WRR Weight
0	1
1	2
2	3
3	4
4	5
5	9
6	13
7	15

# 14.6 Configuring Smart Hot Standby

Smart hot standby enables multiple switches to act as a hot standby device for each other, ensuring uninterrupted data forwarding in the event of a single point failure.



### **Specification**

Smart hot standby is supported only on RG-NBS5200 Series switches.

# 14.6.1 Configuring Hot Standby


View or modify selected hot standby interfaces, device IDs and priorities. The switch with a higher priority is elected as the active switch in a hot standby group.



### Caution


The devices in a hot standby group must have unique device IDs and priorities configured.

Choose Local Device > Advanced > Smart Hot Standby.




# 14.6.2 Configuring DAD Interfaces

After selecting the DAD interfaces of both the active and standby switches, connect these DAD interfaces with a network cable to prevent network failures caused by dual active devices.



# 14.6.3 Active/Standby Switchover

Active/Standby Switchover allow manual switching between the active and standby supervisor engines. Clicking the **Switch** button will restart the supervisor engine. Please exercise caution.



# 14.7 Voice VLAN

# 14.7.1 Overview

A voice virtual local area network (VLAN) is a VLAN dedicated to voice traffic of users. By creating a voice VLAN and adding ports connected to voice devices to the voice VLAN, you can have voice data transmitted in the voice VLAN and deliver specified policy of the quality of service (QoS) for voice streams, to improve the transmission priority of voice traffic and ensure the call quality.

# 14.7.2 Voice VLAN Global Configuration

Choose Local Device > Advanced > Voice VLAN > Global Settings.

Turn on the voice VLAN function, configure global parameters, and click Save.




Table 14-17 Description of VLAN Global Configuration Parameters

Parameter	Description	Default Value
Voice VLAN	Whether to enable the Voice VLAN function	Disable
VLAN	VLAN ID as Voice VLAN	NA
Max Age	Aging time of voice VLAN, in minutes. In automatic mode, after the MAC address in a voice packet ages, if the port does not receive any more voice packets within the aging time, the device removes this port from the voice VLAN	1440 minutes
CoS Priority	The Layer 2 Priority of voice stream packets in a Voice VLAN. The value range is from 0 to 7. A greater value indicates a higher priority. You can modify the priority of the voice traffic to improve the call quality.	6

# 14.7.3 Configuring a Voice VLAN OUI

# Choose Local Device > Advanced > Voice VLAN > OUI.


The source MAC address of a voice packet contains the organizationally unique identifier (OUI) of the voice device manufacturer. After the voice VLAN OUI is configured, the device compares the voice VLAN OUI with the source MAC address in a received packet to identify voice data packets, and sends them to the voice VLAN for transmission.



### Note

After the voice VLAN function is enabled on a port, when the port receives LLDP packets sent by IP phones, it can identify the device capability fields in the packets, and identify the devices with the capability of **Telephone** as voice devices. It also extracts the source MAC address of a protocol packet and processes it as the MAC address of the voice device. In this way, the OUI can be added automatically.


Click Add. In the displayed dialog box, enter an MAC address and OUI, and click OK.



# 14.7.4 Configuring the Voice VLAN Function on a Port

Choose Local Device > Advanced > Voice VLAN > Port Settings.

Click **Edit** in the port entry or click **Batch Edit** on the upper -right corner. In the displayed dialog box, select whether to enable the voice VLAN function on the port, voice VLAN mode to be applied, and whether to enable the security mode, and Click **OK**.






Table 14-18 Description of the Voice VLAN Configuration Parameters on a Port

Parameter	Description	Default Value
Voice VLAN Mode	<ul> <li>Based on different ways the Voice VLAN function is enabled on the port, the Voice VLAN Mode can be Auto Mode or Manual Mode:</li> <li>Auto Mode: In this mode, the device checks whether the permit VLANs of a port contain the voice VLAN after the voice VLAN function is enabled on the port. If yes, the device deletes the voice VLAN from the permit VLANs of the port until the port receives a voice packet containing a specified OUI. Then, the device automatically adds the voice VLAN to the port's permit VLANs. If the port does not receive a voice packet containing the specified OUI within the global aging time, the device removes the Voice VLAN from the permit VLANs of the port.</li> <li>Manual Mode: If the permit VLANs of a port contains the voice VLAN, voice packets can be transmitted in the voice VLAN.</li> </ul>	Auto Mode
Security Mode	When the security mode is enabled, only voice traffic can be transmitted in the voice VLAN. The device checks the source MAC address in each packet. When the source MAC address in the packet matches the voice VLAN OUI, the packet can be transmitted in the voice VLAN. Otherwise, the device discards the packet.  When the security mode is disabled, the source MAC addresses of packets are not checked and all packets can be transmitted in the voice VLAN.	Enable

### Caution

- The voice VLAN mode of the port can be set as the auto mode only when the VLAN mode of the port is Trunk mode. When the voice VLAN mode of the port work in the auto mode, the port exits the voice VLAN first and is automatically added to the voice VLAN only after receiving voice data.
- After the voice VLAN function is enabled on a port, do not switch the Layer 2 mode (trunk or access mode) of the port to ensure normal operation of the function. If you need to switch the Layer 2 mode of the port, disable the voice VLAN function on the port first.
- It is not recommended that both voice data and service data be transmitted over the voice VLAN. If you want to transmit both voice data and service data over the voice VLAN, disable the voice VLAN function in security mode.


• The voice VLAN function is unavailable on Layer 3 ports or aggregate interfaces.

# 14.8 Configuring the Local DNS

The local DNS server is optional. The device obtains the DNS server address from the connected uplink device by default.

Choose Local Device > Advanced > Local DNS.

Enter the DNS server address used by the local device. If multiple addresses exist, separate them with spaces. Click **Save**. After configuring the local DNS, the device first use the DNS of the management IP address for parsing domain names. If the device fail to parse domain names, then use this DNS address instead.



# 15 Diagnostics




### Caution

If the issue persists despite following the troubleshooting methods provided in this section, you may require remote support from a technician who will enable developer mode to resolve the issue. We will ensure your data is protected during this process.

# 15.1 Info Center

Choose Local Device > Diagnostics > Info Center.

In Info Center, you can view port traffic, VLAN information, routing information, client list, ARP list, MAC address, DHCP snooping, IP-MAC binding, IP Source Guard, and CPP statistics of the device and relevant configurations.



# 15.1.1 Port Info


Choose Local Device > Diagnostics > Info Center > Port Info.

Port Info displays the status and configuration information of the port. Click the port icon to view the detailed information of the port.



### Note

- To configure the flow control of the port or the optical/electrical attribute of a combo port, see 7.2 Port
- To configure the Layer 2 mode of the port and the VLAN to which it belongs, see <u>5.3 Configuring Port</u> VLAN.




### 15.1.2 VLAN Info

Choose Local Device > Diagnostics > Info Center > VLAN Info.

Display SVI port and routed port information, including the port information included in the VLAN, the port IP address, and whether the DHCP address pool is enabled.



- To configure VLAN, see <u>5 VLAN</u>.
- To configure SVI ports and routed ports, see <a href="10.1">10.1</a> Setting a Layer 3 Interface.



# 15.1.3 Routing Info



**Specification** 

The RG-NBS3100 series switches do not support this feature.

 $\label{eq:choose Local Device} \textbf{Choose Local Device} > \textbf{Diagnostics} > \textbf{Info Center} > \textbf{Routing Info}.$ 

Displays the routing information on the device. The search box in the upper-right corner supports finding route entries based on IP addresses.



Note

To set up static routes, see 11.1 Configuring Static Routes.



# 15.1.4 DHCP Clients



**Specification** 


This feature is supported only on the RG-NBS5200 series switches

Choose Local Device > Diagnostics > Info Center > DHCP Clients.

Displays the IP address information assigned to endpoints by the device as a DHCP server.



To configure DHCP server related functions, see 10.3.2 Viewing the DHCP Client.



# 15.1.5 ARP List


Choose Local Device > Diagnostics > Info Center > ARP List.

The ARP List displays dynamically learned and statically configured ARP entries on the device. You can view the reachability, type, IP address, MAC address, and the physical interface corresponding to each MAC address.



Note

To bind dynamic ARP or manually configure static ARP, see <a href="10.6">10.6</a> Configuring a Static ARP Entry.




# 15.1.6 MAC Address

Choose Local Device > Diagnostics > Info Center > MAC address.

Displays the MAC address information of the device, including the static MAC address manually configured by the user, the filtering MAC address, and the dynamic MAC address automatically learned by the device.



To configure and manage the MAC address, see <u>6.2</u> <u>Clients Management</u>.




# 15.1.7 DHCP Snooping

Choose Local Device > Diagnostics > Info Center > DHCP Snooping.

Displays the current configuration of the DHCP snooping function and the user information dynamically learned by the trust port.



To modify DHCP Snooping related configuration, see <a href="13.1">13.1</a> <a href="DHCP Snooping">DHCP Snooping</a>.




# 15.1.8 IP-MAC Binding

Choose Local Device > Diagnostics > Info Center > IP-MAC Binding.

Displays the configured IP-MAC binding entries. The device checks whether the source IP addresses and source MAC addresses of IP packets match those configured for the device and filters out IP packets not matching the binding.



To add or modify the IP-MAC binding, see 13.5 IP-MAC Binding.




# 15.1.9 IP Source Guard

Choose Local Device > Diagnostics > Info Center > Source Guard.


Displays the binding list of the IP Source Guard function. The IP Source Guard function will check the IP packets from non-DHCP trusted ports according to the list, and filter out the IP packets that are not in the binding list.



To configure IP Source Guard function, see 13.6 IP Source Guard.




# 15.1.10 PoE



Only PoE switches (model name containing -P, -LP, -HP, and -UP) support this function.


Choose Local Device > Diagnostics > Info Center > PoE.



# 15.1.11 CPP Info

Choose Local Device > Diagnostics > Info Center > CPP.

Displays the current total CPU bandwidth and statistics of various packet types, including the bandwidth, current rate, and total number of packets.



# 15.2 Network Tools


The Network Tools page provides three tools to detect the network status: Ping, Traceroute, and DNS Lookup.

# 15.2.1 Ping

Choose Local Device > Diagnostics > Network Tools.

The Ping command is used to detect the network connectivity.

Select **Ping** as the diagnosis mode, enter the destination IP address or website address, configure the ping count and packet size, and click **Start** to test the network connectivity between the device and the IP address or website. If "Ping failed" is displayed, the device is not reachable to the IP address or website.




# 15.2.2 Traceroute

Choose Local Device > Diagnostics > Network Tools.

The **Traceroute** function is used to identify the network path from one device to another. On a simple network, the network path may pass through only one routing node or none at all. On a complex network, packets may pass through dozens of routing nodes before reaching their destination. The traceroute function can be used to judge the transmission path of data packets during communication.

Select **Traceroute** as the diagnosis mode, enter a destination IP address or the maximum TTL value used by the URL and traceroute, and click **Start**.




# 15.2.3 DNS Lookup

Choose Local Device > Diagnostics > Network Tools.

DNS Lookup is used to query the information of network domain name or diagnose DNS server problems. If the device can ping through the IP address of the Internet from your web page but the browser cannot open the web page, you can use the DNS lookup function to check whether domain name resolution is normal.


Select DNS Lookup as the diagnosis mode, enter a destination IP address or URL, and click Start.



# 15.3 Fault Collection

Choose Local Device > Diagnostics > Fault Collection.

When an unknown fault occurs on the device, you can collect fault information by one click on this page. Click **Start**. The configuration files of the device will be packed into a compressed file. Download the compressed file locally and provide it to R&D personnel for fault locating.




# 15.4 Cable Diagnostics

Choose Local Device > Diagnostics > Cable Diagnostics.

The cable diagnostics function can detect the approximate length of a cable connected to a port and whether the cable is faulty.

Select the port to be detected on the port panel and click Start. The detection results will be displayed below.



### $\mathbf{A}$

### Caution

- The SFP port does not support the function.
- If a detected port contains an uplink port, the network may be intermittently disconnected. Exercise caution when performing this operation.

# 15.5 Alerts

Choose Local Device > Diagnostics > Alarms.



# Note

Click an alert in the **Alert Center** to view the faulty device, problem details, and description.

Displays possible problems on the network environment to facilitate fault prevention and troubleshooting. You can view the alert occurrence time, port, alert impact, and handling suggestions, and rectify device faults according to handling suggestions.

All types of alerts are concerned by default. You can click **Unfollow** to unfollow this type of alert. The system will no longer display this type of alert. To enable the notification function of a type of alert again, follow the alert type on the **Removed Alert** page.



### Caution

After unfollowing an alert, the system will not issue an alert prompt for this type of fault, and users cannot find and deal with the fault in time. Exercise caution when performing this operation.




Table 15-1 Alert Types and Product Support

Alert Type	Description	Support Description
The IP address of the local device conflicts with that of another device.	The IP address of the local device conflicts with that of another client on the LAN.	NA
An IP address conflict occurs on downlink devices connected to the device.	Among the devices connected to the current device on the LAN, an IP address conflict occurs on one or more devices.	NA
The MAC address table is full of entries.	The number of Layer 2 MAC address entries is about to reach the hardware capacity limit of the product.	NA
The ARP table is full of	The number of ARP entries on the network	NA

Alert Type	Description	Support Description
ARP entries.	exceeds the ARP capacity of the device.	
The PoE process is not running.	The PoE service of the device fails and no power can be supplied.	It is applicable only to NBS Series Switches that support the PoE function.  (The device models are marked with "-P".)
The total PoE power is overloaded.	The total PoE power of the device is overloaded, and the new connected PD cannot be powered properly.	It is applicable only to NBS Series Switches that support the PoE function.  (The device models are marked with "-P".)
The device has a loop alarm.	A network loop occurs on the LAN.	NA

# 16 System Configuration

# 16.1 System Logs

On medium- and large-sized network projects, the network administrator usually uses third-party software to connect to all devices, monitor each data indicator of the system, and determine whether any abnormal behavior exists, thereby securing the system. The devices typically run network management protocols, such as Simple Network Management Protocol (SNMP) and Syslog, to connect to third-party software.

## 16.1.1 Viewing logs

Choose Network Wide > System > Syslog > View Log.




Specification


The system logs can be displayed or configured only when the software version of the switch's uplink gateway or router is ReyeeOS 2.320 or later.

#### Choose Local Device > System > Syslog > View Log.


The log list displays the operation logs of the local device. On the **View Log** page, you can specify a duration or module to view logs, or export the log list and log file to the local device for backup or viewing.



 View logs in a specified duration. Click Start Time, select the start and end dates, and click OK to filter logs by date.




 View logs of a specified module. Enter a module name in the search box to view the operation logs of a specified module.



Download the log file and export the log list. Click Download Local Log File to download the compressed
package of log files to the local device for storage and backup. Click Export Log List to download the log
list in .csv format to the local device for viewing.




The **Download Local Log File** button is displayed only on certain products. The actual interface prevails.




# 16.1.2 Setting Logs

Choose Network-Wide > System > Syslog. Click Batch Config.




Choose Local Device > System > Syslog > Log Settings.



# 1. Enabling Syslog

After **SYSLOG** is enabled, the switch can interconnect with the remote log server through Syslog and send log information to the remote log server over the network.





# 2. Configuring Local Logs

The log storage of the local device is enabled by default. Click **Edit**, and then click **Add** to add a filtering rule for the device operation logs. For example, you can filter the debugging information of all modules to prevent them from being displayed in the log list.



If the logging function of the local device is disabled, no operation performed on the device will be displayed in the log list. Exercise caution when disabling log storage of the local device.





# 3. Configuring the Remote Log Server

Click Add next to a remote server to add the basic information of the remote server.





Table 16-1 Description of Configuring Remote Server Parameters

Parameter	Description	Default Value
Enable	Whether to enable the remote server. If so, the device will send the operation logs of the local device to the remote server.	Enabled by default.
IP/Domain	IPv4 address, IPv6 address, or domain name of the remote server.	N/A
Port	Port number of the remote server.	N/A
Protocol	Protocols used by the device to communicate with a remote server.  Currently, only UDP is supported.	UDP by default.


Parameter	Description	Default Value
Rate Limiting	Maximum transmission rate used by the device to send log information to the remote server.	No rate limit by default.
Log Format	Format of device logs sent to the remote log server.      RFC3164: <priority> Local time in seconds Host name Module name%message identifier: Log content      RFC5424: <priority> UTC time in microseconds Host name Module name Process ID Message flag - Log content</priority></priority>	RFC3164
Filter Rule	Filtering rules for device operation logs. The operation logs that are filtered out will not be sent to the log server.	default is selected.

### 4. Batch Configuration

On the **Log Settings** page in Network-Wide mode, select the targeted devices and configure the log settings. Then, click **Save** to apply the settings to the selected devices.




After the log settings are successfully applied, click **View Configuration** to view the log settings of individual devices.



# 16.2 Setting the System Time

Choose Local Device > System > System Time.


You can view the current system time. If the time is incorrect, check and select the local time zone. If the time zone is correct but time is still incorrect, click **Edit** to manually set the time. In addition, the device supports Network Time Protocol (NTP) servers. By default, multiple servers serve as the backup of each other. You can add or delete the local server as required.



Click **Current Time** when modifying the time, and the system time of the currently logged-in device will be automatically filled in.



Choose Network-Wide > System > System Time.



# 16.3 Setting the Web Login Password


Choose Local Device > System > Login > Password.

Enter the old password and new password. After saving the configuration, use the new password to log in.



## Caution


When self-organizing network discovery is enabled, the login password of all devices in the network will be changed synchronously.



# 16.4 Setting the Session Timeout Duration

Choose Local Device > System > Login > Session Timeout.

If you do not log out after login, the web interface allows you to continue the access without authentication on the current browser within one hour by default. After one hour, the web interface automatically refreshes the page and you need to relog in before continuing your operations. You can change the session timeout duration.




# 16.5 Configuration Backup and Import

Choose Local Device > System > Backup > Backup & Import.

Configure backup: Click Backup to generate the backup configuration and download it locally.

Configure import: Click **Browse**, select a backup configuration file locally, and click **Import** to apply the configuration specified by the file to the device After importing the configuration, the device will restart.



# 16.6 Reset

# 16.6.1 Resetting the Device

Choose Local Device > System > Backup > Reset.

Click Reset, and click OK to restore factory settings.





#### $\mathbf{A}$


#### Caution

Resetting the device will clear current settings and reboot the device. If a useful configuration exists in the current system, you can export the current configuration (see <a href="Months:16.5">16.5</a> Configuration Backup and Import) before restoring the factory settings. Exercise caution when performing this operation.

# 16.6.2 Resetting the Devices in the Network

Choose Network-Wide > System > Reset.

Select **All Devices** and choose whether to **Unbind Account**, click **Reset All Devices** and all devices in the current network will be restored to their factory settings.



#### A

#### Caution

Resetting the network will clear current settings of all devices in the network and reboot the devices. Exercise caution when performing this operation.

# 16.7 Configuring SNMP

#### 16.7.1 Overview

The Simple Network Management Protocol (SNMP) is a protocol for managing network devices. Based on the client/server model, it can achieve remote monitoring and control of network devices.

SNMP uses a manager and agent architecture. The manager communicates with agents through the SNMP protocol to retrieve information such as device status, configuration details, and performance data. It can also be used to configure and manage devices.

SNMP can be used to manage various network devices, including routers, switches, servers, firewalls, etc. You can achieve user management through the SNMP configuration interface and monitor and control devices through the third-party software.

## 16.7.2 Global Configuration

#### 1. Overview

The purpose of global configuration is to enable the SNMP service and make the SNMP protocol version (v1/v2c/v3) take effect, so as to achieve basic configuration of local port, device location, and contact information.

SNMP v1: As the earliest version of SNMP, SNMP v1 has poor security, and only supports simple community string authentication. SNMP v1 has certain flaws, such as plaintext transmission of community strings and vulnerability to attacks. Therefore, SNMP v1 is not recommended for modern networks.


SNMP v2c: As an improved version of SNMP v1, SNMP v2c supports richer functions and more complex data types, with enhanced security. SNMP v2c performs better than SNMP v1 in terms of security and functionality, and is more flexible. It can be configured according to different needs.

SNMP v3: As the newest version, SNMP v3 supports security mechanisms such as message authentication and encryption compared to SNMP v1 and SNMP v2c. SNMP v3 has achieved significant improvements in security and access control.

# 2. Configuration Steps


Choose Local Device > System > SNMP > Global Config

(1) Enable the SNMP service.



When it is enabled for the first time, SNMP v3 is enabled by default. Click OK.

(2) Set SNMP service global configuration parameters.



**Table 16-2 Global Configuration Parameters** 

Parameter	Description
SNMP Service	Indicates whether SNMP service is enabled.
SNMP Version	Indicates the SNMP protocol version, including v1, v2c, and v3 versions.
Local Port	The port range is 1 to 65535.
Device Location	1-64 characters. Chinese characters, full-width characters, question marks, and spaces are not allowed.

Parameter	Description
Contact Info	1-64 characters. Chinese characters, full-width characters, question marks, and spaces are not allowed.

#### (3) Click Save.


After the SNMP service is enabled, click **Save** to make basic configurations such as the SNMP protocol version number take effect.

# 16.7.3 View/Group/Community/Client Access Control

#### 1. Configuring v1/v2c Users

#### Overview

When the SNMP version is set to v1/v2c, user configuration is required.




# Note

Select the SNMP protocol version, and click **Save**. The corresponding configuration options will appear on the **View/Group/Community/User Access Control** page.

### Configuration Steps

Choose Local Device > System > SNMP > View/Group/Community/Client Access Control.

(1) Click Add in the SNMP v1/v2c Community Name List pane.



# (2) Add a v1/v2c user.




Table 16-3 v1/v2c User Configuration Parameters

Parameter	Description
Community Name	At least 8 characters.  It must contain at least three character categories, including uppercase and lowercase letters, digits, and special characters.  Admin, public or private community names are not allowed.  Question marks, spaces, and Chinese characters are not allowed.
Access Mode	Indicates the access permission (read-only or read & write) for the community name.
MIB View	The options under the drop-down box are configured views (default: all, none).

#### $\Lambda$

## Caution

- Community names cannot be the same among v1/v2c users.
- Click Add View to add a view.

### (3) Click OK.


#### 2. Configuring v3 Groups

#### Overview

SNMP v3 introduces the concept of grouping to achieve better security and access control. A group is a group of SNMP users with the same security policies and access control settings. With SNMP v3, multiple groups can be configured, each with its own security policies and access control settings. Each group can have one or more users.

#### Prerequisites

When the SNMP version is set to v3, the v3 group configuration is required.




# Note

Select the SNMP protocol version, and click **Save**. The corresponding configuration options will appear on the **View/Group/Community/User Access Control** page.

#### Configuration Steps

Choose Local Device > System > SNMP > View/Group/Community/Client Access Control.

(1) Click Add in the SNMP v3 Group List pane to create a group.



(2) Configure v3 group parameters.




Table 16-4 v3 Group Configuration Parameters

Parameter	Description
Group Name	Indicates the name of the group.  1-32 characters.  Chinese characters, full-width characters, question marks, and spaces are not allowed.
Security Level	Indicates the minimum security level (authentication and encryption, authentication but no encryption, no authentication and encryption) of the group.
Read-Only View	The options under the drop-down box are configured views (default: all, none).
Read & Write View	The options under the drop-down box are configured views (default: all, none).
Notification View	The options under the drop-down box are configured views (default: all, none).


## Caution

- A group defines the minimum security level, read and write permissions, and scope for users within the group.
- The group name must be unique. To add a view, click **Add View**.
- (3) Click **OK**.

# 3. Configuring v3 Users

Prerequisites

When the SNMP version is set to v3, the v3 group configuration is required.




Note

Select the SNMP protocol version, and click **Save**. The corresponding configuration options will appear on the **View/Group/Community/User Access Control** page.

Configuration Steps

Choose Local Device > System > SNMP > View/Group/Community/Client Access Control

(1) Click Add in the SNMP v3 Client List pane to add a v3 user.



(2) Configure v3 user parameters.




Table 16-5 v3 User Configuration Parameters

Parameter	Description
	Username
	At least 8 characters.
Username	It must contain at least three character categories, including uppercase
Osemanie	and lowercase letters, digits, and special characters.
	Admin, public or private community names are not allowed.
	Question marks, spaces, and Chinese characters are not allowed.
Group Name	Indicates the group to which the user belongs.
Security Level	Indicates the security level (authentication and encryption, authentication
Occurry Level	but no encryption, and no authentication and encryption) of the user.
	Authentication protocols supported:
	MD5/SHA/SHA224/SHA256/SHA384/SHA512.
	Authentication password: 8-31 characters. Chinese characters, full-width
Auth Protocol, Auth Password	characters, question marks, and spaces are not allowed. It must contain
	at least three character categories, including uppercase and lowercase
	letters, digits, and special characters.
	Note: This parameter is mandatory when the security level is
	authentication and encryption, or authentication but no encryption.
	Encryption protocols supported: DES/AES/AES192/AES256.
	Encryption password: 8-31 characters. Chinese characters, full-width
Encryption Protocol, Encryption	characters, question marks, and spaces are not allowed.
Password	It must contain at least three character categories, including uppercase
i assworu	and lowercase letters, digits, and special characters.
	Note: This parameter is mandatory when the security level is
	authentication and encryption.

#### Catuion

- The security level of v3 users must be greater than or equal to that of the group.
- There are three security levels, among which authentication and encryption requires the configuration of authentication protocol, authentication password, encryption protocol, and encryption password.
   Authentication but no encryption only requires the configuration of authentication protocol and encryption protocol, while no authentication and encryption does not require any configuration.
- (3) Click OK.
- 4. View/Group/Community/Client Access Control
- Overview

Management Information Base (MIB) can be regarded as a database storing the status information and performance data of network devices. It contains a large number of object identifiers (OIDs) to identify the status information and performance data of these network devices.


Views in SNMP can limit the range of MIB nodes that the management system can access, thereby improving the security and reliability of network management. Views are an indispensable part of SNMP and need to be configured or customized according to specific management requirements.

A view can have multiple subtrees. The management system can only access MIB nodes in these subtrees, and cannot access other unauthorized MIB nodes. This can prevent unauthorized system administrators from accessing sensitive MIB nodes, thereby protecting the security of network devices. Moreover, views can also improve the efficiency of network management and speed up the response from the management system.

#### Configuration Steps

Choose Local Device > System > SNMP > View/Group/Community/Client Access Control.

Click Add under the View List to add a view.



(2) Configure basic information of a view.




Table 16-6 View Configuration Parameters

Parameter	Description
View Name	Indicates the name of the view.

Parameter	Description
	1-32 characters. Chinese or full width characters are not allowed.
OID	Indicates the range of OIDs included in the view, which can be a single OID or a subtree of OIDs.
	There are two types of rules: included and excluded rules.
Туре	The included rule only allows access to OIDs within the OID range. Click Add Included Rule to set this type of view.
	Excluded rules allow access to all OIDs except those in the OID range. Click Add Excluded Rule to configure this type of view.



#### Note

At least one OID rule must be configured for a view. Otherwise, an alarm message will appear.

(3) Click OK

# **16.7.4 SNMP Service Typical Configuration Examples**

## 1. Configuring SNMP v2c

Application Scenario

You only need to monitor the device information, but do not need to set and deliver it. A third-party software can be used to monitor the data of nodes like 1.3.6.1.2.1.1 if v2c version is configured.

Configuration Specification


According to the user's application scenario, the requirements are shown in the following table:

Table 16-7 User Requirement Specification


Item	Description
View range	Included rule: the OID is .1.3.6.1.2.1.1, and the custom view name is "system".
Version	For SNMP v2c, the custom community name is "public", and the default port number is 161.
Read & write permission	Read-only permission.

# Configuration Steps


(1) Choose Local Device > System > SNMP > Global Config, select v2c and set other settings as default. Then, click Save.



- (2) Choose Local Device > System > SNMP > View/Group/Community/Client Access Control. Add a view on the View/Group/Community/Client Access Control interface.
  - a Click Add in the View List pane.
  - b Enter the view name and OID in the pop-up window, and click **Add Included Rule**.
  - c Click OK.



(3) Click **Add** in the SNMP v1/v2c community name list, fill in the community name, access mode and view in the pop-up window, and click **OK** after the operation is completed.



# 2. v3 version SNMP service configuration

Application Scenario

You need to monitor and control devices, and use the third-party software to monitor and deliver device information to public nodes (1.3.6.1.2.1). The security level of v3 is authentication and encryption.


Configuration Specification

According to the user's application scenario, the requirements are shown in the following table:


Table 16-8 User Requirements Description Form

Item	Description
View range	Included rule: the OID is .1.3.6.1.2.1, and the custom view name is "public_view".
	Group name: group
	Security level: authentication and encryption
Group configuration	Select public_view for a read-only view.
	Select public_view for a read & write view.
	Select none for a notify view.
	User name: v3_user
	Group name: group
Configuring v3 Users	Security level: authentication and encryption
	Authentication protocol/password: MD5/Ruijie123
	Encryption protocol/password: AES/Ruijie123
Version	For SNMP v3, the default port number is 161.


- Configuration Steps
- (1) Choose **Local Device** > **System** > **SNMP** > **Global Config**, select v3, and change the port number to 161. Set other settings to defaults. Then, click **Save**.




- (2) Choose Local Device > System > SNMP > View/Group/Community/Client Access Control. Add a view on the View/Group/Community/Client Access Control interface.
  - a Click Add in the View List pane.
  - b Enter the view name and OID in the pop-up window, and click Add Included Rule.
  - c Click OK.



(3) Click Add in the SNMP v3 group list, fill in the group name and security level in the pop-up window, the user has read and write permissions, select public \_view for the readable view and read and write view, and set the notification view to none. After the operation is complete, click **OK**.



(4) Click Add in the SNMP v3 user list, fill in the user name and group name in the pop-up window, the user security level adopts authentication and encryption mode, fill in the corresponding authentication protocol, authentication password, encryption protocol, and encryption password, and click **OK**.



# 16.7.5 Trap service configuration


Trap is a notification mechanism of the SNMP (Simple Network Management Protocol) protocol, which is used to report the status and events of network devices to managers, including device status reports, fault reports, performance reports, configuration reports and security management. Trap can provide real-time network monitoring and fault diagnosis to help administrators find and solve network problems in time.

#### 1. Trap open settings

Enable the trap service and select the effective trap protocol version, including v1, v2c, and v3.

Choose Local Device > System > SNMP > Trap Settings.

(1) Enable the trap service switch.



When the first open is turned on, the system pops up a prompt message. Click **OK**.



(2) Set the trap version.

The trap protocol version number includes v1 version, v2c version, and v3 version.

(3) Click Save.

After the trap service is enabled, you need to click **Save**, and the configuration of the trap protocol version number will take effect.

# 2. Trap v1/v2c user configuration

#### Introduction

A trap is a notification mechanism used to send an alert to administrators when important events or failures occur on a device or service. Trap v1/v2c are two versions of SNMP protocol, used for network management and monitoring.

Trap v1 is the first version in the SNMP protocol, which supports basic alarm notification functions. trap v2c is the second version in the SNMP protocol, which supports more alarm notification options and more advanced security.

By using trap v1/v2c, the administrator can know the problems in the network in time and take corresponding measures.


Prerequisites

When the trap service version selects v1 or v2c, a trap v1v2c user needs to be created.

Configuration Steps

Choose Local Device > System > SNMP > Trap Settings.

(1) Click Add in the Trap v1v2c Client List to create a trap v1v2c user.



(2) Configure trap v1v2c user-related parameters.




Table 16-9 Trap v1/v2c user information description table

Parameter	Description
Dest Host IP	IP address of the trap peer device. An IPv4 or IPv6 address is supported.

Parameter	Description
Version Number	Trap version, including v1 and v2c.
Port Receiving Trap Message	The port range of the trap peer device is 1 to 65535.
Community name/User name	Community name of the trap user.  At least 8 characters.  It must contain at least three character categories, including uppercase and lowercase letters, digits, and special characters.  Admin, public or private community names are not allowed.  Question marks, spaces, and Chinese characters are not allowed.

### Caution

- The destination host IP address of trap v1/ v1/v2c users cannot be the same.
- Community names of trap v1/ v1/v2c users cannot be the same.
- (3) Click **OK**.

#### 3. trap v3 user configuration

Introduction

Trap v3 is a network management mechanism based on SNMP protocol, which is used to send alarm notifications to management personnel. Unlike previous versions, trap v3 provides more secure and flexible configuration options, including authentication and encryption.

Trap v3 can be customized to choose the conditions and methods to send alerts, as well as who receives alerts and how to be notified. This enables administrators to understand the status of network devices more accurately and take timely measures to ensure network security and reliability.

Prerequisites

When v3 is selected as the trap service version, a trap v3 user needs to be created.

Configuration Steps

Choose Local Device > System > SNMP > Trap Settings.

(1) Click Add in the Trap v3 Client List to create a trap v3 user.



(2) Configure parameters related to t rap v3 users.




Table 16-10 trap v3 user information description table

Parameter	Description
Dest Host IP	IP address of the trap peer device. An IPv4 or IPv6 address is supported.
Port Receiving Trap Message	The port range of the trap peer device is 1 to 65535.
	Name of the trap v3 user.
	At least 8 characters.
Username	It must contain at least three character categories, including uppercase
Osemanie	and lowercase letters, digits, and special characters.
	Admin, public or private community names are not allowed.
	Question marks, spaces, and Chinese characters are not allowed.
	Indicates the security level of the trap v3 user. The security levels include
Security Level	authentication and encryption, authentication but no encryption, and no
	authentication and encryption.
	Authentication protocols supported:
	MD5/SHA/SHA224/SHA256/SHA384/SHA512.
	Authentication password: 8-31 characters. Chinese characters, full-width
Auth Protocol, Auth Password	characters, question marks, and spaces are not allowed. It must contain
	at least three character categories, including uppercase and lowercase
	letters, digits, and special characters.
	Note: This parameter is mandatory when the security level is
	authentication and encryption, or authentication but no encryption.
	Encryption protocols supported: DES/AES/AES192/AES256.
Encryption Protocol, Encryption Password	Encryption password: 8-31 characters. Chinese characters, full-width
	characters, question marks, and spaces are not allowed.
	It must contain at least three character categories, including uppercase
	and lowercase letters, digits, and special characters.

Parameter	Description
	Note: This parameter is mandatory when the security level is
	authentication and encryption.

#### Caution

IP of t rap v1/v2c/v3 users cannot be repeated.

# 16.7.6 Typical configuration examples of the trap service

### 1. v2c version trap configuration

Application Scenarios

When the user is monitoring the device, if the device is suddenly interrupted or abnormal, the third-party monitoring software cannot detect and deal with the abnormal situation in time, so configure the device with the destination IP 192.1 68.110.85 and port number 166, so that the device sends a trap of the v2c version in case of an exception.


Configuration Specification

According to the analysis of the user's usage scenario, the requirements are shown in the table:

Table 16-11 User Requirements Description Form

Item	Description
IP address and port number	The destination host IP is 192.168.110.85, and the port number is 166.
Version	Select the v2c version.
Community name/User name	Trap_user


- Configuration Steps
- (1) Choose **Local Device** > **System** > **SNMP** > **Trap Settings**, select the v2c version on the trap setting interface, click **Save**.



(2) Click Add in the "Trap v1/v2c Client List".



(3) Fill in the target host IP, version number, port number, user name and other information, and click **OK** after the configuration is complete.



## 2. V3 version trap configuration

Application Scenarios

When the user is monitoring the device, if the device is suddenly interrupted or abnormal, the third-party monitoring software cannot detect and deal with the abnormal situation in time, and the device with the destination IP of 192.1 68.110.87 and the port number of 167 is configured, and use the more secure v3 version to send traps.


Configuration Specification

According to the analysis of the user's usage scenario, the requirements are shown in the table:

**Table 16-12 User Requirements Description Form** 

Item	Description
IP address and port number	The destination host IP is 192.168.110.87, and the port number is 167.
Version and user name	Select the v3 version and trapv3_user for the user name.
Authentication protocol/authentication password	Authentication protocol/password: MD5/Ruijie123
Encryption protocol/encryption password	Encryption protocol/password: AES/Ruijie123


- Configuration Steps
- (1) Choose Local Device > System > SNMP > Trap Settings, select the v3 version on the trap setting interface, and click Save.



(2) Click Add in the trap v3 client list.



(3) Fill in the target host IP, port number, user name and other information, and click **OK** after the configuration is complete.



# 16.8 Upgrade



#### Caution

- It is recommended to back up the configuration before software upgrade.
- Version upgrade will restart the device. Do not refresh or close the browser during the upgrade process.


# 16.8.1 Online Upgrade

Choose Local Device > System > Upgrade > Online Upgrade.

The current page displays the current system version and allows you to detect whether a later version is available. If a new version is available, click **Upgrade Now** to perform online upgrade. If the network environment does not support online upgrade, click **Download File** to download the upgrade installation package locally and then perform local upgrade.

# Note


- Online upgrade will retain the current configuration.
- Do not refresh the page or close the browser during the upgrade process. After successful upgrade, you
  will be redirected to the login page automatically.



# 16.8.2 Local Upgrade

Choose Local Device > System > Upgrade > Local Upgrade.

Displays the device model and current software version. You can choose whether to keep the configuration upgrade or not. Click **Browse** to select the local software installation package, click **Upload** to upload the installation package and upgrade.




# 16.9 Rebooting the Device

# 16.9.1 Rebooting the Device

Choose Network-Wide > System > Reboot > Reboot.

Choose Local Device > System > Reboot.


Do not refresh the page or close the browser during the reboot. After the device is successfully rebooted and the Web service becomes available, the device automatically jumps to the login page.



# 16.9.2 Rebooting the Devices in the Network

Choose Network-Wide > System > Reboot > Reboot.

Select All Devices, and click Reboot to reboot all devices in the current network.



#### $\Lambda$


#### Caution

It will take some time for the network to reboot, please be patient. The network operation will affect the entire network. Therefore, exercise caution when performing this operation.

#### 16.9.3 Rebooting Specified Devices in the Network

Choose Network-Wide > System > Reboot > Reboot.

Click **Specified Devices**, select desired devices from the **Available Devices** list, and click **Add** to add devices to the **Selected Devices** list on the right. Click **Reboot**. Specified devices in the **Selected Devices** list will be rebooted.



# 16.10 Configuring Scheduled Reboot

avoid network interruption caused by device reboot at wrong time.

Choose Network-Wide > Network > Reboot > Scheduled Reboot.

Choose Local Device > System > Scheduled Reboot.

Click Enable, and select the date and time of scheduled reboot every week. Click Save. When the system time matches the scheduled reboot time, the device will restart.



#### Caution

Once enable scheduled reboot in the network mode, all devices in the network will reboot when the system time matches to the timed time. Therefore, exercise caution when performing this operation.



#### **Cloud Service** 16.11

#### **16.11.1 Overview**

The Cloud Service feature provides powerful remote network management and operation capabilities, making it convenient and efficient to manage geographically dispersed networks with diverse device types. This feature supports wireless devices, switches, and gateways, enabling unified network management and visualized monitoring and operation. Additionally, it also offers various components such as real-name authentication, dedicated Wi-Fi, and passenger flow analysis, allowing for flexible expansion of network services.

By configuring Cloud Service, you can conveniently mange networks through Ruijie Cloud or the Ruijie Reyee app.

# 16.11.2 Configuration Steps

Choose One-Device > System > Cloud Service.

If the device is not currently associated with a cloud account, simply follow the on-screen instructions to add it to the network. Open up the Ruijie Reyee app, click the scan icon at the upper left corner on the Project page, and enter the device's management password.



Once the device is associated with a cloud account, it will automatically be bound to a cloud server based on its geographic location.



#### Caution

Exercise caution when modifying cloud service configurations as improper modifications may lead to connectivity issues between the device and the cloud service.

# 

To change the Cloud Service configurations, select the cloud server from the **Cloud Server** drop-down list, enter the domain name and IP address, and click **Save**.



If the server selected is not **Other Cloud**, the system automatically fills in the domain name and IP address of the cloud server. When **Other Cloud** is selected, you need to manually configure the domain name and IP address and upload the cloud server certificate.

**Table 16-13 Cloud Server Description** 

Parameter	Description
Cloud Server	Geographic location of the cloud server, including China Cloud, Asia Cloud, Europe Cloud, America Cloud, and Other.
Domain Name	Domain name of the cloud server.
IP Address	IP address of the cloud server.

# 16.11.3 Unbinding Cloud Service

Choose One-Device > System > Cloud Service.

You can click **Unbind** to unbind the account if you no longer wish to manage this project remotely.

#### Project Name:radio

Account:

Unbind the account if you no longer wish to manage this project remotely.

It is used to unbind all devices throughout the network. To unbind a single device, remove the device from the network and restore its default settings.

Unbind